


CABINET PARTS

For Model: EF42DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Model: EF42DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	11	2209090	Clamp, Filter Housing	31		Extension Arm, Door Closer
	W10159566	Use & Care Guide	12	3400525	Screw		2307857	Right
	W10165111	Energy Guide	13	W10168990	Filter, Water		2302765	Left
	W10180103	Service & Wiring Sheet	14	489399	Screw	32		Grille Bottom, Front
	2306424	Icemaker and Ingredient Care Center Service Sheet	15	3400230	Screw, Door Stop		2209428B	Black
	W10180893	Main Control Service Sheet	16	2257644	Hinge (Top)	33	2005921	Screw
	W10159564	Installation Instructions	17	2307582	Bracket, Mtg (Water Filter)	34		Bracket, Support Base (Front)
2		Cabinet (Not A Serviceable Part)	18	489464	Screw		2006616	Left
4	W10138054	Roller, Front & Rear (4)	19	2004994	Lock, Adjustable Bushing		2006556	Right
5		Support, Leveler Assembly	20	2300082	Bushing	35	1157158	Screw
	2318194	Refrigerator Side	21	2004514	Clip, Conduit	36	2006617	Bracket, Support Base (Rear) (2)
	2318193	Freezer Side	22		Spring, Door Closure	37	2006346	Washer
6		Cap, Water Filter		2221242	Right Side	38	2266880	Bushing, Extension Arm
	2186494B	Black		2004517	Left Side	39	1163283	Screw
7	2325157	Bracket, Grill Mounting	23	486194	Screw	40		Connector, Water Tube
8	2307584	Grommet, Crossover Tube	24	2005008	Retaining Ring, Adjustable Bushing		2209709	5/16-1/4"
9	2005783	Cam, Door Closer	25	W10129069	Wire Clip (5)		2300868	1/4"
10	2209022	Housing, Water Filter	26	2006342	Gap, Cover Assembly (Bottom)	41	8281163	Screw
			27		Hinge (Bottom)	42		Switch, Rocker Arm
				2006780	Freezer Side		1118894	Refrigerator Door Side
				2006779	Refrigerator Side		1115373	Freezer Door Side
			28	2302876	Bushing, Adjustable	43	2215938	Cover, Switch (2)
			29	8533913	Screw 1/4-20 x 5/8	44	487415	Screw (2)
			30		Skirt-Grille, Bottom	45		Bracket, Switch
				2209025B	Black		2221097	Right
							2221096	Left
						46	2215612	Cover, Rear

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET TRIM PARTS

For Model: EF42DBSS
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1		Cabinet, Trim (Right Side)
	W10132472	Stainless Steel
2		Screw
	1163283	Stainless Steel
3	2316687	Cabinet, Trim (Bottom)
4	486194	Screw
5	2314017	Cabinet, Trim Top
6		Cabinet Trim (Left Side)
	W10132541	Stainless Steel
7	W10121451	Nutsert (4)
8	2005925	Seal-Trim, Side
9	489464	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER SHELF PARTS

For Model: EF42DBSS
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2302868	Wire, Shelf
2	2302883	Shelf, Fixed (2)
3	2259082	Basket
4	2256270	Front, Basket
5	2259317	Slide, Basket Right Side
	2259318	Left Side
6	8533928	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Model: EF42DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS


For Model: EF42DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2306010	Thermistor
3	2208970	Air Duct
4	2259077	Ladder, Shelf (2)
5	520965	Screw Support, Ladder (8)
6	2006475	Screw
7	487539	Screw
8	2302937	Thermistor
9	2302986	Lid, Meat Pan Baffle
10	W10169528	Baffle Control Assembly
11	2171846	Release Valve
12	2310205	Jumper, Air Baffle
13	488357	Screw
14	486194	Screw
15	2221296	Air Baffle Assembly
16	2327509	Reservoir
17	488280	Screw
18	2309222	Diffuser Assembly
19	2317105	Cover, Thermistor
20	2188820	Thermistor
21	2302992	Spacer, Air- Baffle
22	2309087	Cover, Diffuser
23	2259412	Seal, Air Duct (Round Hole)
24	2259398	Seal, Air Duct (Square Hole)
25	2003577	Guard, Return Air
26	W10159487	Diverter, Crisper Cover

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Model: EF42DBSS
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2302772	Control Box
2	2215670	Insert, Control Box
3	2310197	Wire, Jumper
4	W10165120	Circuit Board, Housing Control
5	2221121	Support, Control Box
6	487539	Screw (2)
7	W10151210	Display, Ingredient Care Center
8	2162085	Socket, Light
9	2255743	Light Bulb (2)
10	8281185	Screw
11	W10165030	Overlay, Control Box
12	2302717	Shield, Light
13	486194	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP GRILLE AND UNIT COVER PARTS

For Model: EF42DBSS
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1		Panel, Decorative Assembly Stainless Steel
2	W10161693	Cover, Unit
3	486194	Screw
4	2256466	Back Panel
5	W10121229	Cover, Unit Front
6	487415	Screw
7	2310194	Wire Assembly RC/FC Light Switch
8	12989001	Badge, Dacor
9	489348	Clamp
11	2215910	Grommet-Flexible

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Model: EF42DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


REFRIGERATOR SHELF PARTS

For Model: EF42DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10165103	Shelf Assembly
2	2179404	Rack, Wine
3	W10165091	Assembly, Meat Pan Cover
4	W10165085	Assembly, Crisper Cover
5	2257582	Trim, Glass Rear
6	2252412	Crisper Pan (2)
7		Slide, Meat Pan
	2302954	Left Side
	2302955	Right Side
8	2302831	Trim, Glass Front
9	2256254	Trim, Glass Rear
10	2256248	Front, Crisper Pan
11	2252255	Trim, Glass Side Crisper Pan
12	2256250	Trim, Glass Side Meat Pan
13		Spacer, Crisper
	2256222	Right Side (2)
	2256223	Left Side (2)
14		Slide, Crisper
	2302956	Right Side
	2302957	Left Side
15		Spacer, Meat Pan
	2256243	Left Side
	2256244	Right Side
16		Screw
	8533929	Right Side— (8-18 x 1.375)
	8533928	Left Side— (8-18 x .750)
17	2256369	Pan Assembly Meat
18	2256366	Front, Meat Pan

FREEZER LINER AND AIR FLOW PARTS

For Model: EF42DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER AND AIR FLOW PARTS


For Model: EF42DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	2259385	Fan Motor	18		Block, Fan Scroll	32	2220904	Gasket (2)
2	2198665	Tube, P.C. Board		2209480	Right			Evaporator Cover
3	2169142	Fan Blade		2209066	Left	33	W10151208	Cover, Receiver
4	2223733	Retainer, Fan Motor	19	W10151205	Cover, Emitter	34	W10139189	Harness, Evap Fan (Includes Item 55)
5	2302817	Gasket, Cover	20		Liner (Not A Serviceable Part)	35	2306010	Thermistor
6	2223986	Grommet	21	2259025	Cover, Air Outlet	36	2317105	Cover, Thermistor
7	486194	Screw	22	2307751	Light Shield	37	2006475	Screw
8	2259464	Wedge, Air Duct	23	W10158003	Cover, Evaporator	38	2259032	Ladder, Shelf
9	488500	Screw, Ground	24	2302850	Support, Air Duct	39	2259445	Support, Screw
10	2223857	Socket, Light (2)	25	487539	Screw	40	2198634	Pin
11	488937	Clamp, Nylon	26	2198635	Spring	41	2220398	P.C. Board
12	2326255	Light Bulb	27	2309283	Deflector, Air Duct	42	2198633	Flipper
13	489214	Screw	28	1112260	Support, Evaporator	43	2315398	Slide, Ice maker Shut Off
14	2182120	Scroll, Fan	29	2196483	Shelf, Stud (20)	44	2255114	P.C. Board, Receiver
15	2259465	Wedge, Air Duct	30	8281158	Screw	45	W10160570	Defrost, Bi-Metal
16	2307774	Air Duct	31		Evaporator, Cover Rail	46	8281185	Screw
17	2198643	Lens		2221107	Left Side			
				2259355	Right Side			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Model: EF42DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS


For Model: EF42DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2222965	Ice Bin
2	W10151247	Crusher Bin
3	W10140642	Auger
4	2258220	Washer, Auger
5	1119007	Spacer, Flat (6)
6	2317248	Cover, Crusher
7	2257024	Blade, Rotary
8	1119005	Spacer, Step (2)
9	2257020	Blade, Fixed
10	2257023	Blade, Rotary
11	2317239	Block, Blade
12	489229	Roll Pin
13	2257022	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2188918	Coupling, Top
17	8281164	Screw
18	3400065	Screw
19	2266800	Button, Bin
20	W10134783	Latch, Bin
21	2198608	Spring, Latch
22	2198671	Screw (2)
23	8281163	Screw
24	2188919	Holder
25	2198628	Seal
26	2318030	Drive Shaft
27	2318011	Enclosure, Motor
28	2315546	Dispenser, Motor
29	2318028	Cover
30	2315559	Sleeve, Coupling
31	2317250	Divider-Chamber
32	2317243	Wiper

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Model: EF42DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS


For Model: EF42DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2252330	Refrigerator Door Panel (Includes Item #9)
2	2258951	Brace, Door Corner
3	2266854	Hinge Assembly, Top
4	2316804	Spacer-Door, Top & Bottom
5	489282	Screw
6	2302878	Hinge Assembly, Bottom
7	2222796	Rail, Lid
8	2222982	Gasket, Utility Bin
9	2222811	Door Gasket, Magnetic
10		Skin, Door
	W10144969	Stainless Steel
11	W10127710	Plate, Door
		Handle (4)
12		Spacer, Door-Skin (Handle Side)
	2309060	For Stainless Steel Model
13	488568	Screw
14		Screw, 8-15 x .500
	8281250	Stainless Steel
15	2005433	Spacer, Door-Skin (Top)
16	308544	Screw, Handle
17	2005030	Spacer, Door-Skin (Hinge Side)
18	2004934	Spacer, Door-Skin (Bottom)
19	2005326	Filler, Door
20		End Cap
	2222919	Right Side
	2222920	Left Side
21	2222922	Bin, Utility Center
22	2257616	Door, Utility Bin
23	2222773	Bin, Door (3)
24	2222770	Bin, Door
25	W10153450	Stud, Handle (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Model: EF42DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


FREEZER DOOR PARTS

For Model: EF42DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door Panel (Includes Item #14)
	W10165041	Stainless
2	2302879	Hinge, Bottom
3	489282	Screw
4	2266854	Hinge, Top
5	2316804	Spacer-Door, Top & Bottom
6	2222814	Door Gasket, Magnetic
7	W10127710	Plate, Door Handle (4)
8		Spacer, Door-Skin (Handle Side)
	2309060	For Stainless Steel Model
9		Skin, Door
	W10165044	Stainless Steel
10		Screw
	8281250	Stainless Steel
11	2005433	Spacer, Door-Skin (Top)
12	488568	Screw
13	2257385	Spacer, Door-Skin (Bottom)
14	2005030	Spacer, Door-Skin (Hinge Side)
15	308544	Screw, Handle
16		Filler, Door
	W10159585	Top
	W10159582	Bottom
17	2258951	Brace, Door Corner
18	2222776	Bin, Door (3)
19	W10153450	Stud, Mounting (4)
20	2252354	Spacer

DISPENSER FRONT PARTS

For Model: EF42DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


DISPENSER FRONT PARTS

For Model: EF42DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	2195051	Strain Relief
3	W10139147	Wire Assembly
4		Cover, Dispenser (Not Serviced)
5	2304772	Spring, Torsion
6	2196195	Pin
7	2304355	Ice Door Mechanism
8	2180353	Door, Ice
9	489000	Screw
10	2259396B	Lever, Ice Dispenser
11		Switch Assembly (Not Available Order #25)
12	2259395B	Lever, Water Dispenser
13	2194719	Spring, Lever
14	2205686	Delay Mechanism
15	2183771	Bracket, Control
16	2162361	Switch (2)
17	2259209	Bracket, Anti Drip Valve
18	2180200	Lamp Holder
19	488500	Screw
20	2310198	Harness, Switch
21	2180224	Guide, Ice
22	3406124	Light Bulb
23	2302944B	Grill, Overflow
24		Overlay, Cover (Not Serviced)
25		Front Cover Assembly (Includes Items 4,11,20 & 24)
26	2306077	Spacer, Dispenser Cover
27	2320669	Valve, Anti Drip
28	2252127	Sleeve, Delay Mechanism

UPPER UNIT PARTS

For Model: EF42DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER UNIT PARTS


For Model: EF42DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10133449	Inverter Box	19	489399	Screw	39	2309432	Gasket, Condenser
2	489373	Screw, Compressor Mounting (4)	20	2155774	Wire Tie	40	2259350	Power Supply, Ingredient Care Center
3	2302967	Compressor (Includes Items 6 & 9)(Also Order 876765 Tube Kit)	21	2317982	Drier	<hr/> Following Parts Not Illustrated and Optional Parts Not Included		
4	2318087	Housing, Control Board	22	W10136614	Bracket, Fan Motor (Condenser Fan)			
6	1100826	Grommet, Mounting	23	2188875	Motor, Fan	978025	Valve, Access (1/4")	
7	2309002	Support, Condenser	24	W10139483	Blade, Fan	978026	Valve, Access (5/16")	
8	2307693	Tube, Transiton (Cond/Ht Loop) (Right)	25	2003169	Orifice, Fan	978027	Valve, Access (3/8")	
9	2215676	Terminal Cover	26	8533993	Screw	978028	Valve, Access (1/2")	
10	2309001	Support, Condenser (Left)	27	2317031	Bracket, Vibration (Condenser)	978029	Valve, Access (5/8")	
11	2307028	Control Board, Gemini	28	2317030	Arm, Vibration (Condenser)	978030	Valve, Access (3/4")	
12	2203075	Spacer (5)	29	2307566	Tube, Transition (Condenser/Drier)	876764	Valve, Access (3/16")	
13	2256328	Bracket, Inverter Box	30	2194319	Tube, Process	<hr/> REFRIGERANT CHARGE		
15	1157158	Screw	31	486194	Screw			
16	2307998	Condenser	32	2309000	Cover, Condenser	7.50 oz.		
17	2309431	Grommet (2)	33	2310251	Service Cord	(R-134A)		
18	2310207	Wire, Jumper	34	2307684	Bracket, Mounting (Power Switch)			
			35	549193	Clamp, Cord			
			36	2266802	Switch, Power Disconnect			
			37	487294	Screw, Ground			
			38	W10167450	Wiring Harness, Unit Compartment			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER UNIT AND TUBE PARTS

For Model: EF42DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER UNIT AND TUBE PARTS


For Model: EF42DBSS
(Stainless Steel)

Illus.	Part	
No.	No.	DESCRIPTION
1	2215648	Dampener
2	486194	Screw
3	W10157752	Bracket
4	2309076	Suction Tube
5	2309070	Tube, Connect (Drier/Restrictor)
6	2320615	Drain Pan Assy.
7	W10151288	Cover, Wiring
8	W10153595	Cover, Box
9	W10121371	Tube, Discharge
10	2188820	Thermistor
11	2306093	Evaporator
12	W10140161	Heater, Defrost
13	1113048	Clamp, Heater (2)
14	W10139908	Cover Seal, Evaporator Tubes
15	2220832	Gasket, Evaporator
16	2155774	Wire Tie
17	W10169509	Clip, Heat Exchanger
18	2320554	Support, Drain Pan
19	9791833	Clip, Thermistor
20	W10160981	Bracket Assembly, Air Return

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Model: EF42DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Model: EF42DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10129655	Shield, Valve	16	W10122527	Mold & Heater (Also Order 542638 Silicone Grease)	27	W10151255	Cover, Icemaker
2	2310191	Wire Assembly, Icemaker				28	626680	Module Assembly (Includes Items 17 & 29)
3	628379	Clip, Fuse	17		Motor, (Not Serviceable Order Item 28)	29	489136	Screw (2)
4	2325170	Tube, Filter Inlet				30	489464	Screw
5	2320658	Water Tube	18	628356	Cup-Water Fill	31	486194	Screw
6	2302758	Seal Gasket	19	627843	Ejector	32	2252228	Bracket, Icemaker Mounting
7	2317912	Tube, Filter Outlet	20	2198598	Ice Striper	100	2320636	Complete Icemaker Assembly
8	2317883	Valve, Solenoid	21	2194712	Support			
9	2221070	Clamp, Tube	22	2315522	Retainer			
10	2320559	Support, Valve			Thermostat (2)			
11	2198641	Bracket, Icemaker Cover	23	628397	Thermostat (Also Order 542639 Cement Alumilastic)			
12	2305274	Clamp, Nylon Valve						
13	2302756	Tube, Water Inlet	24	8533917	Screw			
14	2257538	Cover	25	W10139193	Wire Assembly, Water Valve			
15	488500	Screw	26	489276	Screw			

Following Parts Not Illustrated
(Optional Parts Only)

8537055 Cleaner,
Stainless Steel
W10151245 Ice Container
Assembly