


Section: CABINET

Model: EF48BDCBSS




## EF48BDCBSS

<b>Cabinet</b>			
<b>Ref #</b>	<b>Vendor Part #</b>	<b>Dacor Part #</b>	<b>Description</b>
1	67006258	103249	Trim, Cabinet Upper (SLV
**	67001330	102916	Screw, Trim
2	67006161	103250	Trim, Cabinet Side (LT SLV)
**	67001328	102915	Screw, Trim
3	67006162	103251	Trim, Cabinet Side (RT SLV)
**	67001328	102915	Screw, Trim
4	67001539	103235	Kickplate
**	67001540	103463	Screw, Kickplate
5	67003441	103252	Wheel Assy, LT
**	400022-1	103257	Screw, Wheel Assy
**	67002819	102895	Screw, Wheel Assy
6	67003442	103350	Gear Assy., Wheel (FRT)
**	61002819	102895	Screw, Gear Assy
7	67003443	103351	Gear Assy., Wheel (REAR)
8	67001518	103029	Arm, Door Closer
9	67001519	103030	Screw, Closer Arm
10	67001520	101031	Bushing, Closer Arm
11	67001521	103032	Spring W/Damper, Door Closer
12	67003444	103464	Wheel Assy, RT
**	400022-1	103199	Screw, Wheel Assy
**	61002819	102895	Screw, Wheel Assy
13	67003445	103466	Gear Assy., Wheel (FRT)
**	61002819	102895	Screw, Gear Assy
14	67003446	103467	Gear Assy, Wheel (Rear)
**	61002819	102895	Screw, Gear Assy
15	67001518	103029	Arm, Door Closer
16	67001519	103030	Screw, Closer Arm
17	67001520	101031	Bushing, Closer Arm
18	67001526	101032	Spring W/Damper, Door Closer
19	67001527	101033	Bracket Assy., Anti Tip

Section: COMPRESSOR

Model: EF48BDCBSS



## EF48BDCBSS


<b>Compressor</b>			
<b>Ref #</b>	<b>Whirlpool Part #</b>	<b>Dacor Part #</b>	<b>Description</b>
1	12002741	103449	Compressor Kit (includes Compressor, Terminal Cover and
**	67001333	102918	Screw, Compressor Mtg.
2	61005241	102906	Grommet, Compressor
3	67001368	102941	Light Switch
**	67002538	109097	Shim, Light Switch
4	61002138	102894	Terminal Cover
5	67001334	102919	Compressor Rail
**	400017-1	103263	Screw, Rail
6	67001335	102920	Pan, Compressor MTG
7	61006190	102913	Motor, Condensor Pan
**	61005324	102907	Screw, Motor
8	61001414	102891	Bracket, Fan Motor
9	61004743	102805	Grommet, Bracket
10	61005325	102908	Adapter, Fan Motor
**	67001336	102921	Screw, Adapter
11	61006191	102914	Blade, Condensor Fan
12	67006172	102622	Nameplate
13	67001894	103078	Heat Exchange Assy
14	13900-1	103264	Drier
15	67005115	103354	Condenser
16	67001339	102992	Baffle, Condenser Seal
17	67001340	102923	Extension, Condense
**	61002819	102895	Extension Screw
18	67001341	102924	Thermister Clip
19	67001342	102925	Thermister
	65275-33	103266	Screw, Thermister
20	67001343	102926	Drain Pan
**	61002819	102895	Screw, Pan (FRT)
21	67002534	103094	Condensation Wick
22	67002535	103095	Power Cord W/Harness
23	67001347	102927	Bracket, Filter Switch
**	61002819	102895	Bracket Screw
24	67003198	103356	Water Filter Sense Switch
25	67003198	103357	Water Shut Off Sense Switch
26	67001349	102928	Bracket, Water Filter
**	67002819	103358	Screw, Bracket to Wall
**	67001350	102929	Screw, Bracket to Head
27	67001352	102931	Head, Water Filter
28	61003791	102901	Plug, Filter Bypass
29	67001351	102930	Fitting, Water Filter
30	67001351	102930	Fitting, Water Filter

## EF48BDCBSS

31	67006273	103629	Water Filter
32	67001353	102932	Valve Assy., Pressure Relief
**	61002819	102895	Screw, Relief Assy
**	67001904	103083	Screen
33	67001354	102933	Divider, Machine Compartment
34	67001355	102934	Electrical Bracket
**	61002819	102895	Screw, Bracket
35	67001356	102935	Switch, Main Shutoff
36	67001357	102936	Switch C/F Temp Display
37	67006163	103361	Board, Compressor (Inverter)
38	67006252	103271	Retainer, Upper
**	61002819	102895	Screw, Retainer
39	67001360	102937	Power Supply
40	67006259	103363	Main Display Board
41	67001528	103034	Circuit Board Standoffs
42	67006164	103364	Circuit Board Cover
**	61002819	102895	Screw, Cover
43	67006260	103365	Cover, Machine Compt. (STNLS)
**	67006261	103366	Protector Edge
44	67001367	102940	Trim, Cabinet Top (SLV)
**	61002819	102895	Screw, Trim
45	67006169	103367	Hinge, (LT)
**	67006170	103368	Hinge, (RT)
**	61002819	102895	Screw, Hinge to Cover (HEX)
**	67001328	102915	Screw, Hinge to Cabinet (PHIL)
46	67006171	103369	Bracket, Hinge
47	67006254	103176	Retainer, Lower
**	61002819	102895	Retainer Screw
48	67006256	103280	Bracket, Comp. Pan Rear
**	61001885	102892	Screw, Bracket
**	61001363	103450	Wire Harness, Compressor
**	67001365	102938	Wire Harness, Power Supply
**	67001366	103451	Wire Harness, Temp Switch
**	67006166	103372	Wire Harness, Comp. Board
**	67006167	103373	Wire Harness, PC Board

Section: CONTROLS

Model: EF48BDCBSS




## EF48BDCBSS

<b>Controls</b>			
<b>Ref #</b>	<b>Whirlpool Part #</b>	<b>Dacor Part #</b>	<b>Description</b>
1	67003241	103374	Fan Motor
**	400022-1	103257	Screw, Motor
2	67001370	102942	Fan Blade
3	61005341	102910	Fan Bushing
4	67001371	102943	Fan Bracket
**	61005240	102905	Screw, Bracket
5	67006173	103375	Retainer Fan
6	67001372	102944	Diverter, Discharge (Top)
7	67001373	102945	Diverter, Discharge (Bottom)
8	67001374	102946	Housing Contro
**	61002819	102895	Screw, Housing
9	61001945	102893	Bulb Receptacle
10	67003883	102690	Light Bulb
11	67001376	102947	Display Bracket
**	400022-1	103257	Screw, Bracket
**	67001377	102948	Screw Bracket
12	67006262	103376	Main Display Assy
13	67001379	102949	Light Shield
**	67001380	102950	Screw, Shield
**	67003449	103377	Wire Harness Control Hsg

Section: SHELVES & ACCESSORIES (FRESH FOOD)

Model: EF48BDCBSS






## EF48BDCBSS

<b>Shelves and Accy's (Fresh Food)</b>			
<b>Ref #</b>	<b>Whirlpool Part #</b>	<b>Dacor Part #</b>	<b>Description</b>
1	67001385	102951	Rail, Shelf Support
**	61002819	102895	Screw, Rail (Rear)
**	67001386	102952	Screw, Rail (FRT)
2	67001387	102953	End Cap, Rail (LT)
**	67001388	102954	Screw, End Cap
3	67001389	102955	End Cap, Rail (RT)
**	67001388	102954	Screw, End Cap
4	67001390	102659	Thermister
**	61002819	102895	Screw, Thermister
5	67006084	103378	Pan Assy, Crisper
6	61003725	102900	Retainer Duct
7	67006266	103379	Diverter, Air (UPR Crisper)
8	67006263	103381	Spillproof Shelf
9	67001394	102957	Shelf Frame
10	67006263	103381	Deli Shelf
11	67001398	102961	Frame, Deli Shelf
12	67001397	102960	Cradle, Deli Pan
13	67001395	102958	Pan, Deli (Snack Tray)
14	67001396	102959	Front, Deli Pan
**	67002798	103297	Screw, Front
15	67001399	102692	Glide, Deli Pan (LT)
**	67001388	102954	Screw, Glide
16	67001400	102963	Glide, Deli Pan (RT)
**	67001388	102954	Screw, Glide
17	67001401	102964	Shelf, Spillproof
18	67006264	103383	Crisper Assy (LWR-4 Button)
**	67006265	103384	Crisper Assy (UPR-3 Button)
**	67001492	103028	Blanket, LWR Crisper

Section: EVAPORATOR COMPARTMENT

Model: EF48BDCBSS




## EF48BDCBSS

<b>Evaporator Compartment</b>			
<b>Ref #</b>	<b>Whirlpool Part #</b>	<b>Dacor Part #</b>	<b>Description</b>
1	67001895	103473	Evaporator Assy
2	67001404	102965	Thermostat, Defrost
**	61002819	102895	Screw, Thermostat
3	67001422	102976	Heater, Defrost
4	67005457	103385	Clip, Defrost Heater
5	67001637	103062	Shield, Defrost Heater
6	67003237	103386	Tray Assy., Evaporator Drain
**	67001407	102966	Seal, Tray Assy
7	67001408	102967	Clamp, Drain Tube
8	67001409	102268	Drain Tube
9	67003241	103387	Motor Pan
**	400022-1	103257	Screw Motor
10	61005341	102910	Fan Bushing
11	67001371	102943	Fan Bracket
**	61005240	102905	Bracket Screw
12	67006173	103388	Retainer Fan
13	67001410	102969	Fan Blade
14	67001896	103080	Cover Assy., Evaporator
15	67006267	103389	Air Diffuser
**	67001388	102954	Diffuser Screw
**	67001412	102970	Diffuser Gasket
16	67001995	103087	Thermister
17	67001414	102971	Velora Insulation
**	61003316	102899	Insulation Retaine
18	61001945	102893	Bulb Receptacle
19	67003883	102690	Light Bulb
20	67001416	102972	Light Shield
**	67001380	102950	Shield Screw
21	67006268	103390	Façade
**	67001377	102948	Façade Screw
22	67001418	102973	Façade Bracket
**	61002819	102895	Bracket Screw
23	67001900	103081	Auto Damper Assy
**	67002798	103297	Screw, Damper Assy
**	67003456	103392	Freezer Wire Harness

Section: SHELVES & ACCESSORIES (FREEZER)

Model: EF48BDCBSS




## EF48BDCBSS

<b>Shelves and Accy's (Freezer)</b>			
<b>Ref #</b>	<b>Whirlpool Part #</b>	<b>Dacor Part #</b>	<b>Description</b>
1	67001535	103231	Rail, Shelf Support
**	61002819	102895	Screw, Rail (Rear)
**	67001386	102952	Screw, Rail (FRT)
2	67001387	102953	End Cap, Rail (LT)
**	67001388	102954	Screw, End Cap
3	67001389	102955	End Cap Rail, (RT)
**	67001388	102954	Screw, End Cap
4	67001537	102233	Thermister
**	61002819	102895	Screw, Thermister
5	61003237	102896	Receptacle, Bulb
6	67001419	102974	Adapter, Receptacle
**	61002819	102895	Screw, Adapter
7	67006179	103299	Bulb, Light
8	67001420	102975	Shield, Light
**	61002819	102895	Screw, Shield
9	67001425	102977	Frame, Shelf
10	67002537	103096	Grommet, Fill Tube
11	67001426	102978	Shelf, Freezer
12	67003245	103393	Frame, Basket
13	67004869	103301	Basket, Freezer
14	67001429	102797	Front, Basket
**	61005481	103297	Screw, Front
15	67001399	102962	Glide, Basket (LT)
**	67001388	102954	Screw, Glide
16	67001400	102963	Glide, Basket (RT)
**	67001388	102954	Screw, Glide

Section: FRESH FOOD DOOR

Model: EF48BDCBSS




## EF48BDCBSS

<b>Fresh Food Door</b>			
<b>Ref #</b>	<b>Whirlpool Part #</b>	<b>Dacor Part #</b>	<b>Description</b>
1	67002043	103088	Door Assy., Fresh Food (STNLS)
2	67001457	103153	Seal, F.F. Door
3	67006180	103302	Handle Assy. (Incl. End Caps, Stand Offs, Set Screws and Allen
**	67006181	102618	Set Screw (End Cap)
**	67006182	103394	Set Screw (Stand Off and End Cap)
**	67006184	103303	Screw, Stand Off to Handle
4	67006189	103395	Handle Mount
5	67001464	103396	Shelf, Pick Off
6	67006269	103397	Wire, Pick Off Shelf
7	67001461	103398	Compartment, Dairy
8	67001462	103399	Seal, Dairy Door
9	67001901	103474	Door Assy, Dairy
10	67001446	102996	Hinge, Upper
**	67001447	102997	Screw, Hinge to Cover (HEX)
**	67001466	103012	Screw, Hinge
11	67001448	102998	Plate, Upper Hinge
**	67001449	102998	Screw, Plate
12	67001450	103000	Bushing, Upper Hinge
13	67003244	103400	Hinge, Lower
**	67001447	102997	Screw, Hinge
**	67001466	103012	Screw, Hinge
14	67001452	103001	Plate, Lower Hinge
**	67001531	103035	Screw, Plate
15	67001453	103455	Shim, Lower Hinge
16	67001454	103003	Bushing, Lower Hinge
17	67001456	103005	Stud, Lower Hinge
**	67001455	103004	Nut, Hinge Stud
18	67001458	101153	Bushing, Closer
19	67001459	103007	Spacer, Closer
20	67001460	103008	Retainer, Closer Extension
21	67002547	103099	Wire, Dairy Compartment
22	67001626	103098	Stop Assy., Door
23	67006190	103401	Screw, Handle Mount

Section: FREEZER DOOR

Model: EF48BDCBSS






## EF48BDCBSS

<b>Freezer Door</b>			
<b>Ref #</b>	<b>Whirlpool Part #</b>	<b>Dacor Part #</b>	<b>Description</b>
1	67002041	103246	Door Assy., Freezer (STNLS)
2	67001468	103013	Seal, FRZ Door
3	67006180	103302	Handle Assy. (Incl. End Caps, Stand Offs, Set Screws and Allen
**	67006181	102618	Screw Set (End Cap)
**	67006182	102619	Screw Set (Stand Off & End Cap)
**	67006184	103304	Screw, Stand Off to Handle
4	67006189	103305	Mount, Handle
5	67001476	103017	Frame, Basket
6	67002549	103402	Basket, Tilt
7	67001474	103016	Shelf, Pick Off
8	67001626	103057	Stop Assy., Door
9	67006270	103403	Wire, Pick Off Shelf
10	67001471	103014	Hinge, Upper
**	67001447	102997	Screw, Hinge
**	67001466	103012	Screw, Hinge
11	67001448	102998	Plate, Upper Hinge
**	67001449	102998	Screw, Plate
12	67001450	103000	Bushing, Upper Hinge
13	67003242	103404	Hinge, Lower
**	67001447	102997	Screw, Hinge
**	67001466	103012	Screw, Hinge
14	67001473	103015	Plate, Lower Hinge
**	67001531	103035	Screw, Plate
15	67001453	103002	Shim, Lower Hinge
16	67001454	103030	Bushing, Lower Hinge
17	67001456	103005	Stud, Lower Hinge
**	67001455	103004	Nut, Hinge Stud
18	67001458	101153	Bushing, Closer
19	67001459	103007	Spacer, Closer
20	67001460	103008	Retainer, Closer Extensior
21	67006190	103405	Screw, Handle Mount
22	67001972	103245	Conduit, Pivoting
23	67001971	103244	Bearing, Conduii
**	61002819	102895	Screw, Bearing

Section: FOUNTAIN

Model: EF48BDCBSS




## EF48BDCBSS

<b>Fountain</b>			
<b>Ref #</b>	<b>Whirlpool Part #</b>	<b>Dacor Part #</b>	<b>Description</b>
1	67001964	103469	Door Assy, Ice
2	67001837	103070	Strike, Center
3	61004388	103216	Spring, FTN Return
4	67001835	103069	Solenoid
**	61003297	102898	Screw, Solenoid
5	61003803	102902	Bracket, Fountain (BLK)
	415013-35	103309	Screw, Bracket
**	61004757	102904	Foam Seal
6	61005520	102912	Switch, Limit
**	415041-35	103310	Screw, Switch
7	61003291	102897	Receptacle, Bulb
8	63179-1	103311	Bulb, Light
9	67001549	103036	Actuator
10	67001550	103037	Holder, Actuator
11	67001553	103039	Liner, Pad Assy (BLK)
**	67001969	103085	Screw, Liner
12**	67001551	103038	Grill, (BLK)
13**	67006192	103171	Escutcheon Assy (BLK)
**	415014-35	103313	Screw, Escutcheon
14	67001881	103071	Guard, Chip (BLK)
**	67001970	103086	Screw, Guard
15	67001893	103077	Coil Assy, Water
**	61002819	102895	Screw, Coil
16	61001266	103470	Union, Reducing (5/16" - 3/8")
17	67002955	103409	Collar, Escutcheon (BLK)
**	67001640	103471	Wire Harness, FRN Bracket
**	67001641	103064	Wire Harness, FTN
	67001642	103240	Wire Harness, FTN Switch

Section: ICE MAKER

Model: EF48BDCBSS




## EF48BDCBSS

<b>Ice Maker</b>			
<b>Ref #</b>	<b>Whirlpool Part #</b>	<b>Dacor Part #</b>	<b>Description</b>
1	67001557	103040	Ice Maker Assy (115V)
	415013-35	103309	Screw, Ice Maker
2	67001486	103026	Cover, Ice Maker
3	95100-1	102843	Inlet, Water
4	95101-1	102841	Inlet, Water
5	95102-1	102842	Ice Stripper
6	95104-1	102849	Thermostat, Retainer
7	95092-1	103315	Thermostat
**	95093-1	103316	Cement, Alumilastic (4oz)
8	95107-1	102847	Bracket, Module & Heater
**	95108-1	102848	Screw, Bracket
9	67001538	103234	Sensor Arm
10	67001639	103317	Wire Harness, Ice Maker
11	67001484	103024	Tube Copper Inlet
12	54267-1	103412	Union, Compression
13	67001478	103018	Water Valve (Filter)
**	61002819	102895	Valve Screw
14	67001435	103227	Water Valve (Ice Maker)
**	61002819	102895	Screw, Valve
15	67001480	103020	Bracket, Water Valve
**	61002819	102895	Screw, Bracket
16	67001485	103025	Nut and Sleeve Assy
17	67001493	103228	Tubing, Valve to Ice Maker
**	61001161	103457	Clamp, Tubing
18	67001482	103022	Tubing, Valve to Filter Outle
19	67001483	103023	Tubing, Valve to Filter Inle
20	67187-25	103319	Tubing, Valve to Coi

Section: ICE BIN

Model: EF48BDCBSS



## EF48BDCBSS

<b>Ice Bin</b>			
<b>Ref #</b>	<b>Whirlpool Part #</b>	<b>Dacor Part #</b>	<b>Description</b>
1	67001533	103229	Ice Bin
2	67001542	103236	Front Ice Bin
	415013-35	103309	Screw, Bin Front
3	67001536	103232	Door, Ice Access
4	61004804	103217	Housing, Crusher
	415013-35	103309	Screw, Housing
	61004869	103220	Seal, Housing
5	69704-1	103320	Ring, Snap
6	69703-1	103321	Washer, Retainer
7	61003336	103210	Ring, Drive
8	12001773	103472	Motor Assy., Auger (W/Yoke)
	61003324	103439	Screw, Motor
9	63052-1	103323	Yoke
10	67001534	103230	Auger
11	69699-1	103418	Cone, Ice Deflector
12	69698-1	103419	Washer, Cone Stop
13	70036-1	103420	Impeller
14	69755-1	103421	Plate Drive
15	69709-1	103422	Nut, Auger
16	69697-1	103423	Bearing, Spacer
17	69696-1	103424	Spacer, Blade
18	69696-2	103425	Spacer, Blade
19	69701-1	103426	Plate, Impeller
20	67006271	103427	Enclosure
**	400022-1	103199	Screw, Enclosure
21	61005080	103221	Support, Enclosure
**	400022-1	103429	Screw, Support
22	69715-1	103430	Guide, Yoke
	400026-12	103334	Screw, Guide
23	69702-3	103432	Blade, Crusher
24	69702-2	103433	Blade, Crusher
25	69706-1	103434	Blade, Crusher
26	69702-1	103338	Blade, Crusher
27	69708-1	103339	Lock, Fixed Blade
28	69705-1	103340	Pin, Blade Lock
29	69718-1	103341	Door, Ice Crusher
30	67001543	103342	Rod, Crusher Control
31	61004808	103218	Spring, Control Rod
32	61004809	103344	Bracket, Control Rod
33	61005253	103345	Solenoid
	61003324	103439	Screw, Solenoid
34	61005844	103347	Yoke Assy
35	67006272	103440	Cover, Solenoid
	67004873	103441	Cover, Ice Maker Bottom
	67004875	103442	Spacer, Cover
	67004876	103346	Screw, Cover