

**MODEL IH4227 PARTS LIST**

| <u>Ref #</u> | <u>Part #</u> | <u>Description</u>            | <u>Ref #</u> | <u>Part #</u> | <u>Description</u>              |
|--------------|---------------|-------------------------------|--------------|---------------|---------------------------------|
| 1            | 803662        | Damper Assembly               | 9            | 803704        | Decorative Flue Bottom          |
| 2            | 803665        | User Interface Switch Assy    | 10           | 803705        | Decorative Flue Top             |
| 3            | 803670        | Halogen Lamp Assy (incl bulb) | 11           | 803712        | Lampholder Support              |
| 4            | 803816        | Light Bulb                    | 12           | 803712        | Lampholder Support              |
| 5            | 803672        | Control Assembly              | 13           | 803716        | Transformer with Wires (IH4227) |
| 6            | 803677        | Heat Sentry                   | 14           | 803706        | Telescopic Skeleton Bottom      |
| 7            | 803678        | Grease Filter                 | 15           | 803707        | Telescopic Skeleton Top         |
| 8            | 803679        | Outlet                        |              |               |                                 |

MODEL IH4227 EXPLODED VIEW

