

**15" ELECTRIC GRILL COOKTOP PARTS LIST**

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	805454	Panel, Control Box
2	802563	Grill Power Supply Harness
3	800906	Screw, 6-32X1/2" W/Lockwasher
4	801542	Screw, 8-18X3/8" B H/W/Hd
5	804222	Triac, Steamer,Fryer, Grill
6	805549	Baffle, Grill Heat
7	730227	Nut, 10-24 Keps Lock
8	805588	Insulation, Grill Socket
9	803313	Pan, Electric Grill Module (IG15/G)
10	802551	Ceramic Element Socket, Grill
11	805484	Pem Assy, Receptacle Bracket
12	805453	Control Assy, Grill
13	802557	Glass, Grill Assy
14	805639	Weld Assy, Grill Drip Pan
15	802524	Grate, Grill Module
16	805546	Element, Grill Module 2800w - 240v
	805810	Element, Grill 2800 w - 208v
17	801804	Plate, Electric Grill Radiator
18	805455	Insulation, Grill Burner Box
19	805587	Insulation, Grill Side
20	805450	Burner Box, Grill
21	800418	#8-32 Hex Nut W/Lock Washer
22	805456	Insulation, Grill Receptacle
23	805457	Insulation, Grill Control
24	801913	Strain Relief, Metal
25	805451	Control Box, Grill
26	802554	Transformer, Module
27	802563	Grill Power Supply Harness
28	805459	Harness, Grill Module Cover
29	805176	Grill Module Triac Harness
30	804412	Harness, Grill Element
31	805177	Grill Module Power Conduit

**Not Shown**

804555 Hold Down Clamp Hdw, Module

**15" ELECTRIC GRILL COOKTOP EXPLODED VIEW**

