




Service Parts List


6GARM



HINGE PARTS DIAGRAM



Parts for a
Right Hand
Hinged Door




Parts for a
Left Hand
Hinged Door

HINGE PARTS LIST


Item No.	Description	Qty. Req.	Service Assembly
1	Top Hinge Pin	1	42245707
2	Lower Hinge Pin	1	42245708
3	10-32 x 3/4" PH Countersunk Screw Taptite ZN	6	42248052
4	Door Closer Cam Follower	1	42248269
5	Upper Hinge Pin Bearing	1	42248135
6	Chrome Upper Door Hinge, Right Hand	1	42248277
6	Black Upper Door Hinge, Right Hand	1	42248762
7	Chrome Upper Door Hinge, Left Hand	1	42248276
7	Black Upper Door Hinge, Left Hand	1	42248763
8	Chrome Bottom Door Hinge, Right Hand	1	42248275
8	Black Bottom Door Hinge, Right Hand	1	42248764
9	Chrome Bottom Door Hinge, Left Hand	1	42248274
9	Black Bottom Door Hinge, Left Hand	1	42248765

GLASS DOOR PARTS DIAGRAM



R.H. Door

L.H. Door




GLASS DOOR PARTS LIST

ITEM NO	PART DESCRIPTION	QTY	SERVICE ASSEMBLY NUMBER
1	Door Assembly, Black, Right Hand	1	42248665
1	Door Assembly, Black, Left Hand	1	42248664
1	Door Assembly, Black, With Lock, Right Hand	1	42248667
1	Door Assembly, Black, With Lock, Left Hand	1	42248666
1	Door Assembly, Stainless Steel, Right Hand	1	42248669
1	Door Assembly, Stainless Steel, Left Hand	1	42248668
1	Door Assembly, Stainless Steel, With Lock, Right Hand	1	42248671
1	Door Assembly, Stainless Steel, With Lock, Left Hand	1	42248670
2	Hinge Adapter Bottom, Right Hand	1	42248273
2	Hinge Adapter Bottom, Left Hand	1	42248272
3	Door Closer Cam Follower	1	42248269
4	Hinge Adapter Top, Black, Right Hand	1	42248541
4	Hinge Adapter Top, Black, Left Hand	1	42248542
4	Hinge Adapter Top, Stainless Steel, Right Hand	1	42248270
4	Hinge Adapter Top, Stainless Steel, Left Hand	1	42248271
5	Upper Hinge Bushing	1	42248135
6	Hinge Adapter Screw, Black	4	42248134
6	Hinge Adapter Screw, Stainless Steel	4	42247427
7	Door Handle, Black	1	42245084*
7	Door Handle, Stainless Steel	1	42242939**
8	Door Handle Stand Off, Black	2	42245084*
8	Door Handle Stand Off, Stainless Steel	2	42242939**
9	Door Handle Screw	2	42248546
10	Set Screw	2	42247631
11	Marvel Nameplate	1	42248015
12	Door Gasket, Black	1	42248686
13	Door Switch Magnet	1	42248447
14	Magnet Retainer	1	42247549
15	Kappet Screw	2	42248687
16	Kappet Snap-Cap, Black	2	42248688
17	Lock Assembly	1	42244620

* 42245084 is a complete black handle assembly consisting of parts 7 thru 10.


** 42242939 is a complete stainless steel handle assembly consisting of parts 7 thru 10.

GLASS DOOR PRO+ PARTS DIAGRAM



R.H. Door

L.H. Door




GLASS DOOR PRO+ PARTS LIST

ITEM NO	PART DESCRIPTION	QTY	SERVICE ASSEMBLY NUMBER
1	Door Assembly, Black, Right Hand, Pro Plus-Chrome Handle	1	42248689
1	Door Assembly, Black, Left Hand, Pro Plus- Chrome Handle	1	42248690
1	Door Assembly, Cranberry, Right Hand, Pro Plus- Chrome Handle	1	42248691
1	Door Assembly, Cranberry, Left Hand, Pro Plus- Chrome Handle	1	42248692
1	Door Assembly, Ivory, Right Hand, Pro Plus- Chrome Handle	1	42248693
1	Door Assembly, Ivory, Left Hand, Pro Plus- Chrome Handle	1	42248694
1	Door Assembly, Stainless Steel, Right Hand, Pro Plus- Chrome Handle	1	42248695
1	Door Assembly, Stainless Steel, Left Hand, Pro Plus- Chrome Handle	1	42248696
1	Door Assembly, Black, Right Hand, Pro Plus- Brushed Nickel Handle	1	42248697
1	Door Assembly, Black, Left Hand, Pro Plus- Brushed Nickel Handle	1	42248698
1	Door Assembly, Cranberry, Right Hand, Pro Plus- Brushed Nickel Handle	1	42248699
1	Door Assembly, Cranberry, Left Hand, Pro Plus- Brushed Nickel Handle	1	42248700
1	Door Assembly, Ivory, Right Hand, Pro Plus- Brushed Nickel Handle	1	42248701
1	Door Assembly, Ivory, Left Hand, Pro Plus- Brushed Nickel Handle	1	42248702
1	Door Assembly, Stainless Steel, Right Hand, Pro Plus- Brushed Nickel Handle	1	42248703
1	Door Assembly, Stainless Steel, Left Hand, Pro Plus- Brushed Nickel Handle	1	42248704
2	Hinge Adapter Top, Black, Right Hand	1	42248541
2	Hinge Adapter Top, Black, Left Hand	1	42248542
2	Hinge Adapter Top, Stainless Steel, Right Hand	1	42248270
2	Hinge Adapter Top, Stainless Steel, Left Hand	1	42248271
3	Upper Hinge Bushing	1	42248135
4	Hinge Adapter Bottom, Right Hand	1	42248273
4	Hinge Adapter Bottom, Left Hand	1	42248272
5	Door Closer Cam Follower	1	42248269
6	Hinge Adapter Screw, Black	4	42248134
6	Hinge Adapter Screw, Stainless Steel	4	42247427
7	Marvel Nameplate	1	42248015
8	Stud Screw	2	42248546
9	Stud, Handle Standoff	2	42247006
10	Handle And End Caps, Pro Plus- Chrome (Complete)	1	42248058*
10	Handle And End Caps, Pro Plus- Brushed Nickel (Complete)	1	42248648**
11	Standoff, Pro Plus- Chrome	2	42248705
11	Standoff, Pro Plus- Brushed Nickel	2	42248706
12	Standoff Screw	2	42248229
13	Set Screw	2	42247631
14	Gasket, Black	1	42248686
15	Door Switch Magnet	1	42248447
16	Magnet Retainer	1	42247549
17	Kappet Screw	2	42248687
18	Kappet Snap-Cap, Black	2	42248688

* 42248058 is a complete chrome handle assembly consisting of parts 8 thru 13.


** 42248648 is a complete stainless steel handle assembly consisting of parts 8 thru 13.

GLASS OVERLAY DOOR PARTS DIAGRAM



L.H. Door


R.H. Door



GLASS OVERLAY DOOR PARTS LIST

ITEM NO	PART DESCRIPTION	QTY	SERVICE ASSEMBLY NUMBER
1	Door Assembly, Black, Right Hand	1	42248707
1	Door Assembly, Black, Left Hand	1	42248708
1	Door Assembly, Black, With Lock, Right Hand	1	42248709
1	Door Assembly, Black, With Lock, Left Hand	1	42248710
2	Hinge Adapter Bottom, Right Hand	1	42248273
2	Hinge Adapter Bottom, Left Hand	1	42248272
3	Door Closer Cam Follower	1	42248269
4	Hinge Adapter Screw, Black	4	42248134
5	Hinge Adapter Top, Black, Right Hand	1	42248541
5	Hinge Adapter Top, Black, Left Hand	1	42248542
6	Upper Hinge Bushing	1	42248135
7	Gasket, Black	1	42248686
8	Door Switch Magnet	1	42248447
9	Magnet Retainer	1	42247549
10	Kappet Screw	2	42248687
11	Kappet Snap-Cap, Black	2	42248688
12	Lock Assembly	1	42244620


SOLID OVERLAY DOOR PARTS DIAGRAM



SOLID OVERLAY DOOR PARTS LIST

ITEM NO	PART DESCRIPTION	QTY	SERVICE ASSEMBLY NUMBER
1	Door Assembly, Black, Right Hand	1	42248711
1	Door Assembly, Black, Left Hand	1	42248712
1	Door Assembly, Black, With Lock, Right Hand	1	42248713
1	Door Assembly, Black, With Lock, Left Hand	1	42248714
2	Hinge Adapter Bottom, Right Hand	1	42248273
2	Hinge Adapter Bottom, Left Hand	1	42248272
3	Door Closer Bushing	1	42248269
4	Hinge Adapter Screw, Black	4	42248134
5	Hinge Adapter Top, Black, Right Hand	1	42248541
5	Hinge Adapter Top, Black, Left Hand	1	42248542
6	Upper Hinge Bushing	1	42248135
7	Gasket, Black	1	42243906
8	Retainer Spacer	1	42247223
9	Door Switch Magnet	1	42248447
10	Magnet Retainer	1	42247549
11	Kappet Screw	2	42248164
12	Kappet Snap-Cap	2	42248688
13	Lock Assembly	1	42244430


CABINET PARTS DIAGRAM



CABINET PARTS LIST

ITEM NO	PART DESCRIPTION	QTY	SERVICE ASSEMBLY NUMBER
1	Back Panel	1	42247046
2	Access Cover	1	42248138
3	Heyco Bushing	1	42247144
4	#10 X 1/2 Hex Head Screw	24	42248047
5	U/I Display- Complete (Glass Door Models)	1	42248716
	U/I Display- Complete (Solid Door Models)	1	42248766
6	Electronic Control	1	42248684
7	Switch Display Light	1	42246921
8	Light Switch	1	42248717
9	Light Socket	1	42244648
10	Light Bulb	1	2240004A
11	Light Switch Shim	1	42248715
12	#10 X 1/2 Hex Head Screw	3	42248047
13	Wire Conduit	1	42248767
14	Evaporator	1	42248524
15	Thermistor (Compartment/Defrost)	2	42248649
16	Heat Exchanger	1	42248768
17	Adjustable Grille, Rh, Black	1	42248408
17	Adjustable Grille, Lh, Black	1	42248409
18	#12 X 3/4 Ph Hd Screw- Black	2	42248140
19	#10 Lockwasher	1	42248049
20	Washer- Black	2	42248769
21	Cover- Coil	1	42248720
22	Tuflok Fastener	4	42248521
23	Evaporator Fan Assembly	1	42248774
24	Evaporator Fan Wire Harness	1	42248775
25	Light Wire Harness	1	42248776
26	Light/Thermistor Wire Harness	1	42248777
27	Main Wire Harness	1	42248778
28	Shelf Mounting Rail	2	42248721
29	Shelf Mounting Ladder	1	42248722
30	#8 X 1 Kappet Screw	8	42248164
31	Kappet Snap Cap, Black	8	42248688
32	Shelf Glass- Split Shelf	1	42248723
33	Split Shelf Frame	1	42248724
34	Wood Shelf Front	1	42248725
35	#6 Screw	8	42246263
36	Shelf Bumper	12	42248726
37	Shelf Glass- Full Width	2	42248727
38	Shelf Frame- Full Width	2	42248728
39	Wood Shelf Front	2	42248729
40	Bottle Cradle	1	42244618
41	#8 X 1.25 Screw- Black	2	42248290

MECHANICAL PARTS DIAGRAM



MECHANICAL PARTS LIST

ITEM NO	PART DESCRIPTION	QTY	SERVICE ASSEMBLY NUMBER
1	Baseplate	1	42248730
2	1/4-20 X 1-1/4 Carriage Bolt	3	42248155
3	Leg Leveler	4	42243808
4	#10-24 X 1/2 Carriage Bolt	2	42243618
5	Trim- Base Front	1	42248731
6	#10-32 X 3/4 Ph Countersunk Hd Screw	4	42248052
7	#10 Countersunk Flat Washer	4	42248153
8	Tube And Wire Condenser	1	42248167
9	Air Baffle	1	42246937
10	Condenser Bracket	2	42248166
11	Washer 1" O.D., 7/32 I.D.	2	42248165
12	#8-18 X 1 Kappet Screw	2	42248164
13	#10-24 Hex Nut	2	42247454
14	Condenser Fan Shroud	1	42248163
15	Power Supply, Fan	1	42248735
16	#6-20 X 1/2 Ph Hd Screw	1	42248452
17	Condenser Fan Motor	1	42248161
18	Condenser Fan Bracket	1	42248159
19	Wire Harness Clip	1	42248736
20	#10 X 1/2 Hx Hd Screw	5	42248047
21	Condenser Fan Blade	1	42248160
22	Foam Pad	1	42248162
23	Drip Pan	1	42241926
24	Drier Assy	1	42248154
25	Power Cord Clamp	1	42247348
26	Power Cord Clamp Screw	2	42247348
27	Compressor	1	42248732
28	1/4-20 Locknut	3	42248048
29	5/16 I.D. Flat Washer	3	42248046
30	Grommet	4	42247479
31	Sleeve	3	42247479
32	Compressor Ground Wire	1	42243623
33	#10 Ext Tooth Lockwasher	3	42248049
34	#8-32 X 3/8 Hx Hd Screw	1	42243240
35	Wire Harness- Compressor	1	42248150
36	5Sp Electrical Pkg	1	42248733
37	Run Capacitor	1	42248156
38	Bail Strap- 5Sp	1	42248734
39	Power Cord	1	42248149