



Parts Manual Gas Range

RCS30SBV2




Table of Contents

Page	Description
1-2	Cabinet Assembly RCS30
3-4	Burner Cavity Assembly RCS30
5-6	Burner Bowl Assembly RCS30
7-8	Burner Assembly RCS30
9-10	Cooktop Assembly RCS30
11-12	Control Panel Assembly RCS30
13-14	Oven Bottom Assembly RCS30
15-16	Cavity Back Assembly RCS30
17-18	Cavity Top Assembly RCS30
19-20	Oven Door Assembly RCS30




RCS30SB Cabinet Assembly



RCS30SB Cabinet Assembly

Ref Number	Part Number	Part Name	Quantity
1	118401	BACKGUARD GRATE HGT V2 30	1
2	905311	ASM COOKTOP SB V2 30	1
3	113213	BODY SIDE RIGHT 30-36	1
4	602123	SA DEFLECTOR SHIELD 30	1
5	905384	ASM CONTROL PANEL RCS30SBV2	1
6	113540	KICK PANEL NO LOUVER 30	1
7	101416	KICK PNL CHANNEL	1
8	723101	SS Leg, 2" Diameter 2-1/2"	4
9	921001	ASM TUBE BURNER CAVITY V2 30	1
10	600345	SA OVEN DOOR RCS RNB 30	1
11	128006	BACK SIDE CONNECTION	1
12	118752	MAIN BACK 30	1
13	113212	BODY SIDE 30 LEFT	1


RCS30SB Burner Cavity Assembly



RCS30SB Burner Cavity Assembly

Reference Number	Part Number	Part Name	Quantity
1	600029	ASM ANGLED 2 SLOPE FLUE	1
2	118775	BACK INSULATION RETAINER 30	1
3	611002	ASM CAVITY BACK V2 30	1
4	174751	FRONT FRAME V2 30	1
5	742802	Hinge Receiver Keystone	2
6	703304	SHORT IGNITOR	1
7	101410	SHORT BURNER SUPPORT	1
8	703203	SHORT OVEN BURNER	1
9	187817	CAVITY STRIP 30	2
10	620004	ASM COMBUSTION CHAMBER V2 30	1
11	905310	ASM OVEN BOTTOM V2 30	1
12	501003	WA BASE 30	1
13	187832	CAVITY SIDE V2	2
14	118773	SIDE INSUL RET V2	2
15	189207	BACK INSULATION RETAINER V2 30	1

RCS30SB Burner Bowl Assembly




RCS30SB Burner Bowl Assembly

Reference Number	Part Number	Part Name	Quantity
1	196236	BURNER BOWL 30	1
2	198405	BURNER BOWL SUPPORT	2

GUARANTEEDPARTS.COM



RCS30SB Burner Assembly




RCS30SB Burner Assembly

Reference Number	Part Number	Part Name	Quantity
1	743204	CENTER FILLER GRATE	2
2	752203	REAR ORIFICE AND TUBE	2
3	198404	GRATE SUPPORT SB	2
4	752201	FRONT ORIFICE AND TUBE	2
5	752001	BURNER BASE REIGNITION 15K SEALED	3
6	752105	BURNER CAP MATTE 15/18 K SB	3
7	500130	WA BURNER BOWL SB 30	1
8	752003	BURNER BASE REIGNITION 5K SEALED	1
9	752107	BURNER CAP MATTE 5 K SB	1
10	735801	SB MATTE GRATE	4

GUARANTEEDPARTS.COM



RCS30SB Cooktop Assembly




RCS30SB Cooktop Assembly

Reference Number	Part Number	Part Name	Quantity
1	905357	AS BURNER RCSSB 30	1
2	905379	ASM BURNER BOX V2 30	1
3	905393	ASM 4-PT SPARK MODULE	1
4	601108	SA MANIFOLD 4B 30	1

GUARANTEEDPARTS.COM



RCS30SB Control Panel Assembly




RCS30SB Control Panel Assembly

Reference Number	Part Number	Part Name	Quantity
1	735003	Switch-Rocker, SPDT w/BlueStar	2
2	101411	CONTROL PANEL TRIM RCS 30 SB	1
3	799487	Oven Thermostat	1
4	305201	Screw 6-32x3/16 Pan Taptite ZP	10
5	732101	LARGE BEZEL - CHROME	5
6	728102	Indicator Lamp - Blue	1
7	500245	WA CONTROL PANEL RCSSB30	1

GUARANTEEDPARTS.COM



RCS30SB Oven Bottom Assembly




RCS30SB Oven Botttom Assembly

Reference Number	Part Number	Part Name	Quantity
1	188803	OVEN BOTTOM V2 30	1
2	188903	FLAME DIVERter V2 30	1
3	310104	RIVET 3-16 X 1/2 Dome HD Steel	10

GUARANTEEDPARTS.COM



RCS30SB Cavity Back Assembly




RCS30SB Cavity Back Assembly

Reference Number	Part Number	Part Name	Quantity
1	187912	CAVITY BACK V2 30	1
2	199256	OVEN FAN SHIELD ELECTRIC	1
3	303201	SCR. #10 X 1/2" PH TRUSS HD ZP	4
4	600033	SA CONVECTION FAN	1
5	741201	1" SNAP BUSHING	3
6	748104	Lamp Assy - 25 W Halogen - Narrow	2

GUARANTEEDPARTS.COM



RCS30SB Cavity Top Assembly




RCS30SB Cavity Top Assembly

Reference Number	Part Number	Part Name	Quantity
1	105201	IR TRIM LONG 2 PT	1
2	105202	BOILER TRIM, REAR FRAME	1
3	105301	IR TRIM SHORT 2 PT	1
4	105302	BROILER IGNITER MOUNT	1
5	187811	CAVITY TOP 36	1
6	303201	SCR. #10 X 1/2" PH TRUSS HD ZP	18
7	703301	OVEN BURNER IGNITER	1
8	735501	INFRARED BROILER BURNER 3/8"	1

GUARANTEEDPARTS.COM



Oven Door Assembly RCS30SB



RCS30SB Oven Door Assembly

Reference Number	Part Number	Part Name	Quantity
1	610035	GLASS PACK 30	1
2	303201	10 x 1-2 Phillips Truss Head	14
3	174851	DOOR PANEL BLUESTAR V2 30	1
4	703118	TUBE DOOR HANDLE 30	1
5	703001	Handle End	2
6	703523	STENCILED SHORT DOOR GLASS 30	1
7	742705	HINGE KEYSTONE RED	1
8	174946	DOOR LINER V2 30	1

GUARANTEEDPARTS.COM

