



Parts Manual Gas Range

RNB364CBPMV2

RNB364FTPMV2


RNB364GPMV2



Table of Contents

Page	Description
1-2	Cabinet Assembly RNB364
3-4	Burner Cavity Assembly RNB364
5-6	Cooktop Assembly RNB364CB
7-8	Charbroiler Assembly RNB364CB
9-10	Cooktop Assembly RNB364FT
11-12	French Top Assembly RNB364FT
13-14	Cooktop Assembly RNB364G
15-16	Griddle Assembly RNB364G
17-18	Burner Box Assembly RNB364
19-20	Cavity Back Assembly RNB364
21-22	Cavity Top Assembly RNB364
23-24	Control Panel Assembly RNB364CB
25-26	Grease Pan Assembly RNB364
27-28	Oven Bottom Assembly RNB364
29-30	Oven Left Door Assembly RNB364
31-32	Oven Right Door Assembly RNB364
33-34	Oven Flue
35-36	Front 18K 22K Burner Assembly
37-38	Front 15K Burner Assembly
39-40	Rear 15K Burner Assembly
41-42	Rear Simmer Burner Assembly
43	Orifice Chart


RNB366BPM Cabinet Assembly



RNB366BPM Cabinet Assembly

Reference Number	Part Number	Part Name	Quantity
1	198936	ISLAND TRIM 36" PM	1
2	907313	ASM COOKTOP RNB6B36MS	1
3	113626	113626 RIGHT SIDE TRIM PM V2	1
4	907303	ASM CONTROL PANEL RNB6B36MS	1
5	113231	RIGHT BODY SIDE PM V2	1
6	960006	SA OVEN DOOR	1
7	188548	KICK PANEL 36 PM	1
8	101425	KICK PANEL HEAT SHIELD	1
9	907301	ASM TUBE BURNER CAVITY V2 36 PM	1
10	723101	SS LEG 2" DIA. 2 1/2	4
11	128006	BACK SIDE CONNECTION	1
12	960007	SA OVEN DOOR	1
13	118753	MAIN BACK 36	1
14	113229	LEFT BODY SIDE PM V2	1
15	113625	LEFT SIDE TRIM PM V2	1
16	118011	TOP BACKGUARD 36"	1


RNB366BPM Burner Cavity Assembly



RNB366BPM Burner Cavity Assembly

Reference Number	Part Number	Part Name	Quantity
1	174759	FRONT FRAME PM V2 36	1
2	101359	FRENCH DOOR ROD SUPPORT RIGHT	1
3	703304	SHORT IGNITOR	1
4	101410	SHORT BURNER SUPPORT	1
5	703203	SHORT OVEN BURNER	1
6	101358	FRENCH DOOR ROD SUPPORT LEFT	1
7	187704	CAVITY STRIP 36	1
8	905320	ASM OVEN BOTTOM V2 36	1
9	620004	ASM COMBUSTION CHAMBER V2 36	1
10	501004	WA BASE 36	1
11	118773	SIDE INSULATION RETAINER	2
12	187832	CAVITY SIDE V2	2
13	600029	ASM ANGLED 2 SLOPE FLUE	1
14	620020	ASM CAVITY TOP LINER V2 36	1
15	620002	ASM CAVITY BACK V2 36	1
16	602129	SA BALL LATCH STRIKE PLATE, RNB-PM	1


Cooktop Assembly RNB364CB



RNB364CB Cooktop Assembly

Reference Number	Part Number	Part Name	Quantity
1	700801	GRATE-TOP, MATTE BLACK	4
2	700901	GRATE-RING, MATTE BLACK	4
3	600084	SA REAR 15K BURNER	1
4	600086	SA FRONT 18K 22K BURNER	2
5	905335	ASM GREASE PAN RNB RCS 36	1
6	905521	ASM CHARBROILER V2 12	1
7	603107	SA MANIFOLD 4B 36	1
8	100253	THERMOVALVE CHARBROILER BRKT	1
9	705401	Single Therموالve Y-30128-68	1
10	101215	TOP SUPPT CENTER OB	2
11	101650	GREASE PAN GUIDE	2
12	906303	ASM BURNER BOX W PATCH V2 36	1
13	101217	TOP SUPPORT SIDE OB	2
14	600083	SA REAR SIMMER BURNER	1
15	704504	S/S Burner Support	2
16	706101	Fishpaper	5
17	701805	SB op top gas valve L777MZ-82Z	5
18	701901	open top Switch 25070-44	5
19	729204	Sngl Pt Spark Module R1120A-1	5
N/S	750462	HARNESS-MANIFOLD WIRE,C-BROIL	1
N/S	750459	HARNESS-CONTROL PANEL 36	1
N/S	741910	IGNITION WIRE, RT AGL, OB, 22"	2
N/S	741901	IGNITION WIRE, OB, 12"	2

Charbroiler Assembly RNB364CB




RNB364CB Charbroiler Assembly

Reference Number	Part Number	Part Name	Quantity
1	736602	GRATE-CHARBROILER, MATTE BLACK	2
2	171721	CHARBROILER TOP FRAME 12" V2	1
3	703201	Oven Burner 1594099	1
4	502601	WA GREASE BAFFLE	1
5	703304	SHORT IGNITOR	1
6	163902	Bracket - Ignitor	1
7	500215	WA CB FLAVOR SAVOR V2	1
8	500210	WA CHARBROILER BOX 12" V2	1
9	171723	CHARBROILER SKIRT 12" V2	1

GUARANTEEDPARTS.COM




Cooktop Assembly RNB364FT



RNB364FT Cooktop Assembly

Reference Number	Part Number	Part Name	Quantity
1	700901	GRATE-RING, MATTE BLACK	4
2	700801	GRATE-TOP, MATTE BLACK	4
3	600084	SA REAR 15K BURNER	1
4	704504	S/S Burner Support	2
5	600086	SA FRONT 18K 22K BURNER	2
6	701901	open top Switch 25070-44	5
7	905335	ASM GREASE PAN RNB RCS 36	1
8	603107	SA MANIFOLD 4B 36	1
9	729204	Sngl Pt Spark Module R1120A-1	5
10	101215	TOP SUPPT CENTER OB	2
11	706101	Fishpaper	5
12	701805	SB op top gas valve L777MZ-82Z	5
13	101650	GREASE PAN GUIDE	2
14	101217	TOP SUPPORT SIDE OB	2
15	906303	ASM BURNER BOX W PATCH V2 36	1
16	600083	SA REAR SIMMER BURNER	1
17	905207	ASM FRENCH TOP V2 12	1
N/S	750461	MANIFOLD WIRE HARNESS 36 FT	1
N/S	750459	HARNESS-CONTROL PANEL 36	1
N/S	741910	IGNITION WIRE, RT AGL, OB, 22"	3
N/S	741901	IGNITION WIRE, OB, 12"	2

French Top Assembly RNB364FT




RNB364FT French Top Assembly

Reference Number	Part Number	Part Name	Quantity
1	500415	WA FRENCH TOP 12	1
2	702307	5" French Top Lid	1
3	702306	10" French Top	1
4	733803	French top venturi	1
5	304202	Screw 10-24 x 3/8 PH Truss SS	2
6	743301	36" Cooktop Base Wire Harness	1
7	122318	FRENCH TOP INSERT BOX 12	1
8	741801	Electrode SIM/15K/18K/22K	1
9	729801	18K/22K 8 Finger Star Burner	1

GUARANTEEDPARTS.COM




Cooktop Assembly RNB364G



RNB364G Cooktop Assembly

Reference Number	Part Number	Part Name	Quantity
1	700801	GRATE-TOP, MATTE BLACK	4
2	700901	GRATE-RING, MATTE BLACK	4
3	600084	SA REAR 15K BURNER	1
4	600086	SA FRONT 18K 22K BURNER	2
5	701901	open top Switch 25070-44	1
6	729204	Sngl Pt Spark Module R1120A-1	1
7	603107	SA MANIFOLD 4B 36	1
8	905522	ASM GRIDDLE V2 12	1
9	100252	THERMOVALVE GRIDDLE BRACKET	1
10	705401	Single Therموالve Y-30128-68	1
11	101215	TOP SUPPT CENTER OB	2
12	701805	SB op top gas valve L777MZ-82Z	4
13	706101	Fishpaper	4
14	905335	ASM GREASE PAN RNB RCS 36	1
15	101650	GREASE PAN GUIDE	2
16	101217	TOP SUPPORT SIDE OB	2
17	906303	ASM BURNER BOX W PATCH V2 36	1
18	600083	SA REAR SIMMER BURNER	1
19	704504	S/S Burner Support	3
N/S	750460	HARNESS-MANIFOLD WIRE, GRIDDLE	1
N/S	750459	HARNESS-CONTROL PANEL 36	1
N/S	741910	IGNITION WIRE, RT AGL, OB, 22"	2
N/S	741901	IGNITION WIRE, OB, 12"	2

Griddle Assembly RNB364G




RNB364G Griddle Assembly

Reference Number	Part Number	Part Name	Quantity
1	500401	Griddle Plate W/A 12"	1
2	303901	Rivet 3-16 x 9-16 Lo-Profile	2
3	100300	BRKT, SUPPORT, GRIDDLE BURNER	1
4	303201	Screw #10x1/2 PH Truss ZP	1
5	100277	BOX, INSERT, 12IN GRIDDLE	1
6	706201	Burner Griddle 2801G0126A	1




RNB366BPM Burner Box Assembly



RNB366BPM Burner Box Assembly

Reference Number	Part Number	Part Name	Quantity
1	303201	SCR. #10 X 1/2" PH TRUSS HD ZP	8
2	101507	BURNER BOX SIDE V2	2
3	100232	BURNER BOX FRONT 36	1
4	741201	1" SNAP BUSHING	6
5	101332	Burner Box Bottom 36	1
6	306301	RIVET, 3/16" COUNTERSINK BLIND	23
7	101507	BURNER BOX SIDE V2	2
8	100222	Burner Box Back 36	1
9	101381	WIRE WAY, BOTTOM	1
10	101382	WIRE WAY, TOP	1

Cavity Back Assembly RNB366BPM




RNB366BPM Cavity Back Assembly

Reference Number	Part Number	Part Name	Quantity
1	187820	CAVITY BACK 36	1
2	748104	Lamp Assy - 25 W Halogen - Narrow	2

GUARANTEEDPARTS.COM



Cavity Top Assembly RNB366BPM




RNB366BPM Cavity Top Assembly

Reference Number	Part Number	Part Name	Quantity
1	187804	CAVITY TOP 36	1
2	735501	INFRARED BROILER BURNER 3/8"	1
3	105202	BOILER TRIM, REAR FRAME	1
4	105301	IR TRIM SHORT 2 PT	1
5	703301	OVEN BURNER IGNITER	1
6	303201	SCR. #10 X 1/2" PH TRUSS HD ZP	15
7	105201	IR TRIM LONG 2 PT	1
8	187804	CAVITY TOP 36	1

GUARANTEEDPARTS.COM



Control Panel Assembly RNB364CBPM




RNB364CBPM Control Panel Assembly

Reference Number	Part Number	Part Name	Quantity
1	703004	SHORT HANDLE PM	2
2	728102	INDICATOR LAMP - BLUE	1
3	799487	OVEN THERMOSTAT	1
4	305201	SCREW 6-32 x PAN HEAD	12
5	732101	LARGE BEZEL	6
6	742410	BS BADGE - SMALL	1
7	735003	SWITCH - ROCKER	2
8	188560	CONTROL PANEL RNB364CBPMV2	1

GUARANTEEDPARTS.COM



Grease Pan Assembly RNB364PM




RNB364PM Grease Pan Assembly

Reference Number	Part Number	Part Name	Quantity
1	188555	GREASE PAN HANDLE RNB 36 PM	1
2	747803	Slide, Top Section	2
3	704505	Grease Pan Insert	3
4	101684	GREASE PAN 36"	1
5	306301	RIVET, 3/16" COUNTERSINK BLIND	4

GUARANTEEDPARTS.COM



Oven Bottom Assembly RNB364PM




RNB364PM Oven Bottom Assembly

Reference Number	Part Number	Part Name	Quantity
1	188804	OVEN BOTTOM V2 36	1
2	303901	Rivet 3-16 x 9-16 Lo-Profile	10
3	188904	FLAME DIVERTER V2 36	1

GUARANTEEDPARTS.COM



Oven Left Door Assembly RNB364PM




RNB364PM Left Oven Door Assembly

Reference Number	Part Number	Part Name	Quantity
1	306404	Rivnut AVK 1024	4
2	799303	GLASS PACK FRENCH DOOR	1
3	749402	BALL LATCH-DOOR MOUNT	2
4	303201	# 10 x 1-2 Phillips Truss Head	12
5	190152	DOOR FRONT 36 LEFT PM	1
6	703004	SHORT HANDLE PM	1
7	502413	WA 36" LEFT FRENCH DOOR INSL. RE	1
8	190146	DOOR LINER 36 FRENCH	1

GUARANTEEDPARTS.COM



Oven Right Door Assembly RNB364PM




RNB364PM Right Oven Door Assembly

Reference Number	Part Number	Part Name	Quantity
1	190153	DOOR FRONT 36 RIGHT PM	1
2	303201	# 10 x 1-2 Phillips Truss Head	12
3	799303	GLASS PACK FRENCH DOOR	1
4	190146	DOOR LINER 36 FRENCH	1
5	502412	WA 36" RIGHT FRENCH DOOR INSL. F	1
6	703004	SHORT HANDLE PM	1

GUARANTEEDPARTS.COM



Oven Flue




Oven Flue

Reference Number	Part Number	Part Name	Quantity
1	303201	Screw #10x1/2 PH Truss ZP	4
2	116814	ANGLED 2 SLOPE FLUE TOP	1
3	116815	ANGLED 2 SLOPE FLUE BOTTOM	1

GUARANTEEDPARTS.COM



Front 18K 22K Burner Assembly




Front 18K 22K Burner Assembly

Reference Number	Part Number	Part Name	Quantity
1	304202	SCREW 10-24 x 3/8 PH TRUSS SS	2
2	729801	18K/22K 8 FINGER STAR BURNER	1
3	733801	0029006B01 1" OD FRONT MIXER T	1
4	741801	ELECTRODE SIM/15K/18K/22K	1
5	734301	GASKET FOR VENTURI	1



Front 15K Burner Assembly




Front 15K Burner Assembly

Reference Number	Part Number	Part Name	Quantity
1	729802	15K 8 FINGER STAR BURNER	1
2	733801	0029006B01 1" OD FRONT MIXER T	1
3	741801	ELECTRODE SIM/15K/18K/22K	1
4	734301	GASKET FOR VENTURI	1
N/S	304202	SCREW 10-24 x 3/8 PH TRUSS SS	2

GUARANTEEDPARTS.COM



Rear 15K Burner Assembly




Rear 15K Burner Assembly

Reference Number	Part Number	Part Name	Quantity
1	729802	18K/22K 8 FINGER STAR BURNER	1
2	733802	0029007B01, 1" OD REAR MIXER	1
3	741801	ELECTRODE SIM/15K/18K/22K	1
4	734301	GASKET FOR VENTURI	1
N/S	304202	SCREW 10-24 x 3/8 PH TRUSS SS	2

GUARANTEEDPARTS.COM



Rear Simmer Burner Assembly



Rear Simmer Burner Assembly

Reference Number	Part Number	Part Name	Quantity
1	729803	9.5 K STAR BURNER / SIMMER	1
2	733802	0029007B01, 1" OD REAR MIXER	1
3	741801	ELECTRODE SIM/15K/18K/22K	1
4	734301	GASKET FOR VENTURI	1
N/S	304202	SCREW 10-24 x 3/8 PH TRUSS SS	2

GUARANTEEDPARTS.COM



Orifice Chart

Part Number	Description	Fuel Type	Burner Type	Sea Level	2000 ^	3000^	4000^	5000^	6000^	7000^	8000^	9000^	10000^
709512	Orifice Hood 1.25mm	Nat	Surface Simmer	1.25									
709570	Orifice Hood #70	LP	Surface Simmer	70	70	71	71	71	71	72	72	72	72
709547	Orifice Hood #47	Nat	Surface 22k BTU	47	48	48	49	49	49	50	50	51	51
709555	Orifice Hood #55	LP	Surface 22k BTU	55	55	55	55	56	56	56	56	56	57
709551	Orifice Hood #51	Nat	Surface 15k BTU	51	51	52	52	52	52	53	53	53	54
709559	Orifice Hood #59	LP	Surface 15k BTU	59	60	61	61	62	62	63	64	64	65
709548	Orifice Hood #48	Nat	Surface 18k BTU	48	49	49	49	50	50	50	51	51	52
709512	Orifice Hood 1.25mm	LP	Surface 18k BTU	1.25									
709543	Orifice Hood #43	Nat	Surface Platinum 25k BTU	43	44	44	44	45	45	46	47	47	48
709555	Orifice Hood #55	LP	Surface Platinum 25k BTU	55	55	55	55	56	56	56	56	56	57
735550	IR burner elbow & orifice #50	Nat	IR Broiler	50	51	51	51	51	52	52	52	53	53
735556	IR burner elbow & orifice #56	LP	IR Broiler	56	56	56	57	57	57	58	59	59	60
718742	Oven burner orifice #42	Nat	Bake Burner	42	42	43	43	43	44	44	45	46	47
718752	Oven burner orifice #53	LP	Bake Burner	53	54	54	54	54	54	54	55	55	55
781010	Power Burner Orifice BLANK	S.O.	Power Burner Platinum - Order to gas size, Nat - .096 / LP - .056										
		Nat	Griddle										
		LP	Griddle										
		Nat	Char Grill										
		LP	Char Grill										
		Nat	French Top										
		LP	French Top										
		Nat	Salamander										
		LP	Salamander										