




Part Number	Description	
1 82362	Burner Top Grate	
2 82361-01	Burner Head 23K	
3 82361-02	Burner Base	
4 20652	Electrode Spark Holder Assy.	
5 20268-02	Side Grate Support	
6 20587-CS	Spillage Tray Culinarian	
7 20268-03	Center Grate Support	
8 20268-02	Side Grate Support	
9 20636-F	Front Burner Top Alignment Assy.	
10 L20645-02	L/S Grease Deviation	
11 86010-02	18" Flex Tube	
12 82148-01	CG Elbow Flare W/Nut	
13 20599-03	Elbow Holder Brkt.	
14 ???????	Hex Nut of 82148-01	
15A 82101-45	Orifice For Natural Gas 23K	
15B 82101-55	Orifice For L.P. Gas 20K	
16 CS20598	Burner Hanger	
17 R20645-02	R/S Grease Deviation	
18 PSRIT-30	Island Trim W/A For Range 30"	
18 PSRIT-36	Island Trim W/A For Range 36"	
18 PSRIT-48	Island Trim W/A For Range 48"	
19 CS148-48	Back Trim 48" Culinarian	
20 20420-10	Broiler Cover W/A	
21 82363	Broiler Grate	
22 10758-04	Ceramic S/S Culinarian Radiant	
23 82325	Top Broiler Grate	
24 CGB12-14 CGB12-30	14 Broiler Box Narrow W/A	30 Broiler Box Wide W/A
25 82401-01	Surface Igniter	
26 20420-01	Griddle Cover W/A	
27 20224-12	Flue Cover Griddle	
28 20216 20216-01	Griddle Plate W/A Wide -	01 Griddle Plate W/A Narrow
29 82324	Griddle Burner	
30 20086 20130	Griddle Burner Support Brkt.	Assy of both Numbers
31 20212-CL	Griddle Box	
32 20220	Griddle Box Support	