


ComfortStar USA
Parts Breakdown
CMO28B-3
208-220V / 1-Ph / 60 Hz



ComfortStar USA

Parts Breakdown

CMO28B-3

208-220V / 1-Ph / 60 Hz

Item #	Part No.	Part Description	Comments
1	01473001	Front Grill	
2	26235253	Handle	
3	26235401	Small Handle	
4	01433011	Encloser	
5	10335253	Fan Blade	
6	15013712	Fan Motor	
7	01703087	Motor Support Sub-Assy	
8	06813401	Choke Plug	
9	06123401	Drainage Connector	
10	01203642P	Metal Base Assy	
11	01113030	Condenser Coil Assy	
12	3900028001	Sensor Kit Assembly (3 sensors together)	Ambient, Coil, Comp Discharge
13	01255013P	Top Cover	
14	01475252	Mesh Enclosure	
15	0123303901	Isolation Sheet	
16	07228741	Bidirection Accumulator	
17	07220030	Gas-liquid Separator	
18	03223654	Exit Tube Sub-Assy of Accumulator	
19	05003271	Connection Pipe	
20	03023839	4-way Valve Assy	
21	43000109	Magnetic Coil for Electronic Expansion Valve	Use 43000109F if flat top EXV or 43000109R if round top EXV
22	76518732	Electric Heater	
23	03633917	Discharge tube sub-assy 1	
24	46020006	Pressure Protect Switch	
25	00180002	Overload Protector	
26	00105204	Compressor and Fittings	
27	0130300701	Rear Side Plate	
28	07130209	Cut-off 3/8" Valve	3/8"
29	07130208	Cut-off 1/4" Valve	1/4"
30	01713081	Valve support assy	
31	03633920	Inhalation Tube Sub-Assy	
32	76710235	Compressor Gasket	
33	33010027	Capacitor CBB611A(3uF/450V)	
34	01413108	Electric Box Cover	
35	20113003	Insulating Plate of Electric box Cover	
36	2617300601	Power Module Assy IPM+PFC+Rad	
37	01403990	Electric Box Assy	
38	420111041	Terminal Block	
39	42010178	Terminal Block	
40	none	Connecting Cable	
41	4300040042	4-way Valve Fittings	
42	06643008	Tube Connector Assy	
43	01305247	Front Side Plate	
	43000411	4-way Valve	
	30038219	Main PCB	AP1
	32210057	IPM	AP3
	30111019	PFC	AP2
	43120022	Reactor	
	07130358	EXV	
	46010056	External Fuse	In line between L and P1 on Filter (FU).
	43130020	Electric Filter	110/250VAC, 50-60Hz, 30A
	32210058	Power Module	AP4

Revision C 07/24/2013