

The Dacor logo is displayed in a bold, italicized, sans-serif font. The letters are black and have a slight shadow effect, giving them a three-dimensional appearance. The logo is centered at the top of the page.

dacor.

Family-Owned. American-Made.


The background of the page is a faded, grayscale image of a kitchen. In the center is a Dacor oven with a gas cooktop. On the cooktop, there is a small white bowl and a large black pot. To the left of the oven, there are various kitchen items on the counter, including a bottle of oil, a wooden spoon, and some other containers. To the right, there is a wooden cabinet and a basket of bread. The overall scene is a typical home kitchen setting.

**PARTS
CATALOG**


DCM24 Convection Microwave

Oven and Cabinet	Control Panel	Door
Miscellaneous	Complete Parts List	

DCM - Oven & Cabinet



DCM DOOR




door parts

5-	66509S	Door full assy
5-	66509B	Door full assy
5-	66509R	Door full assy
5- 1	66512	Door panel assy
5- 2	66513	Door glass (Black, Stainless)
5- 2	66514	Door glass (Arctic)
5- 3	66515	Choke cover
5- 4	66516	Door frame (Black, Stainless)
5- 4	66517	Door frame (Arctic)
5- 5	66518B	Door decoration (Black)
5- 5	66518R	Door decoration (Arctic)
5- 5	106887	Door decoration (Stainless)
5- 6	66521	Latch angle
5- 7	66522	Latch head
5- 8	66523	Spring
5- 9	66524	Thermal plate u
5-10	66525	Thermal plate r
5-13	66526	Cushion

DCM CONTROL PANEL

CONTROL PANEL PARTS




CONTROL PANEL PARTS

3- 1	66402	Control unit
3- 2	66403S*	Panel med assy*
3- 2	66403B**	Panel med assy**
3- 2	66403R	Panel med assy
3- 2-1	66406	Key unit (Black)
3- 2-1	66407	Key unit (Arctic)
3- 2-2	66408	Open button (Black)
3- 2-2	66409	Open button (Arctic)
3- 2-3	66410	Open button spring
3- 2-4	66411S	C/p decoration

*Order P/N 106829 starting with S/N X-E-9151000

**Order P/N 106830 starting with S/N X-E-9421100

DCM MISC PARTS



6- 1	66527	Low rack assy
6- 2	66528	High rack assy
N/A		
6- 4	66530	Thermistor harness
6- 5	66531	Main wire harness
6- 6	66532	Hv wire b
6- 7	66533	Grounding wire

DCM OVEN AND CABINET PARTS

REF NO. PARTS CODE DESCRIPTION

ELECTRICAL PARTS

1- 1	103754	Power supply cord
1- 2	66372	Monitor fuse and Micro switch assy
1- 3	66373	Fuse holder
1- 4	66374	Micro switch a
1- 5	66375	Thermistor assy
1- 7	66376	Temp. fuse 150_c
1- 8	66377	Thermal cut out
1- 9	66378	Damper motor
1-10	66379	Oven light
1-11	66380	Oven lamp socket
1-13	66381	Conv m.120
1-14	66382	Fan motor 120
1-15	66383	Heater
1-16	66384	H.v. transformer
1-17	66385	High voltage capacitor
1-18	66386	Hv recti er assy
1-19	66387	Magnetron
1-20	66388	Turntable motor
1-21	66389	Ah sensor assy

CABINET PARTS

2- 1	66390B	Outer case cabinet, BLK
2- 1	106394*	Outer case cabinet, BLK *Order w/ Serial #XB06265670 and on.
2- 1	66390R	Outer case cabinet, ATC
2- 1	66390S	Outer case cabinet, SST
2- 3	66393	Bottom plate assy
2- 3-1	66394	Turntable motor cover
2- 4	66395	Foot
2- 5	66396	Back plate
2- 6	66397	Cord holder
2- 7	66398	Hv capacitor holder
2- 8	66399	Lower oven hinge
2- 9	66400	Latch hook
2-10	66401	Latch lever

PARTS LIST

Note: The parts marked "Δ" may cause undue microwave exposure.
The parts marked "*" are used in voltage more than 250V.

DCM24
DCM24
DCM24

REF NO.	PARTS CODE	DESCRIPTION
---------	------------	-------------

ELECTRICAL PARTS

1- 1	66371	Power supply cord
1- 2	66372	Monitor fuse and Micro switch assy
1- 3	66373	Fuse holder
1- 4	66374	Micro switch a
1- 5	66375	Thermistor assy
1- 7	66376	Temp. fuse 150_c
1- 8	66377	Thermal cut out
1- 9	66378	Damper motor
1-10	66379	Oven light
1-11	66380	Oven lamp socket
1-13	66381	Conv m.120
1-14	66382	Fan motor 120
1-15	66383	Heater
1-16	66384	H.v. transformer
* 1-17	66385	High voltage capacitor
* 1-18	66386	Hv rectifier assy
* 1-19	66387	Magnetron
* 1-20	66388	Turntable motor
* 1-21	66389	Ah sensor assy

CABINET PARTS

2- 1	66390B	Outer case cabinet
2- 1	66390R	Outer case cabinet
2- 1	66390S	Outer case cabinet
2- 3	66393	Bottom plate assy
2- 3-1	66394	Turntable motor cover
2- 4	66395	Foot
2- 5	66396	Back plate
2- 6	66397	Cord holder
2- 7	66398	Hv capacitor holder
2- 8	66399	Lower oven hinge
Δ 2- 9	66400	Latch hook
Δ 2-10	66401	Latch lever

CONTROL PANEL PARTS

3- 1	66402	Control unit
3- 2	66403S*	Panel med assy*
3- 2	66403B**	Panel med assy**
3- 2	66403R	Panel med assy
3- 2-1	66406	Key unit (Black)
3- 2-1	66407	Key unit (Arctic)
3- 2-2	66408	Open button (Black)
3- 2-2	66409	Open button (Arctic)
3- 2-3	66410	Open button spring
3- 2-4	66411S	C/p decoration

3-4	66416	Open Lever
3-5	66417	Open Shaft

*Order P/N 106829 starting with S/N X-E-9151000

**Order P/N 106830 starting with S/N X-E-9421100

Oven Parts

Ref #	Part #	Description
4-1	N/A	Cavity Sub Asy.
4-2	66464	Roller Asy.
4-3	102427	Turntable Tray
4-4	66466	Bearing Asy.
4-5	66467	Thermal Cover Left
4-6	66468	Bearing Mounting Plate
4-7	66469	Heater Element Holder
4-8	66470	Bearing Holder Plate
4-9	66471	Convection Fan
4-10	66472	Pully (f)
4-11	66473	Heater Duct
4-11	66474	Air Guide (a)
4-11	66475	Air Guide (b)
4-11	66476	Air Guide (c)
4-12	66477	Thermal Insulation 1
4-13	66478	Glass Mount Plate
4-14	66479	Cushion
4-15	66480	Cushion
4-16	66481	Steam Duct Asy.
4-17	66482	Damper Cam
4-18	66483	Damper Shaft
4-19	66484	Cushion
4-19	66485	Cushion
4-19	66486	Damper
4-20	66487	Damper Duct
4-21	66488	Rubber Cushion

Ref #	Part #	Description
4-22	66489	Turntable Coupling
4-22	106393*	Turntable Coupling *
4-23	66490	Wave Guide Cover
4-24	66491	Cushion
4-24	106396**	Cushion **
4-25	66492	Light Glass
4-26	66493	Thermal Insulation
4-27	66494	Thermal Cover Right
4-28	66495	Divide Plate Low
4-29	66496	Divide Plate Right
4-30	66497	C Motor Mount Angle
4-31	66498	Pully (m)
4-32	66499	Fan Blade
4-33	66500	Cooling Fan Duct
4-34	66501	Chassis Support
4-35	66502	Oven Hinge (upper)
4-36	66503	Convection Fan Belt
4-37	66504	Thermal Protection Sht.
4-38	66505	Cushion
4-38	106395***	Cushion ***
4-39	66506	Cushion
4-40	66507	Cushion
4-41	66508	Mg Rectifier Plate
4-43	106397	Cusion (Not Shown)
-	101989	Noise Filter Board (Not Shown)
*Order w/ Serial #08475000 and on.		
**Order w/ Serial #XB06265670 and on.		
***Order w/ Serial #XB06265670 and on.		

REF NO.	PARTS CODE	DESCRIPTION
---------	------------	-------------

DOOR PARTS

Δ	5-	66509B	Door full assy , Black
Δ	5-	66509S	Door full assy, Stainless
Δ	5-	66509R	Door full assy , Arctic White
Δ	5- 1	66512	Door panel assy
	5- 2	66513	Door glass (Black, Stainless)
	5- 2	66514	Door glass (Arctic)
Δ	5- 3	66515	Choke cover
Δ	5- 4	66516	Door frame (Black, Stainless)
	5- 4	66517	Door frame (Arctic)
	5- 5	106887	Door decoration (Black)
	5- 5	66518R	Door decoration (Arctic)
Δ	5- 5	66518S	Door decoration (Stainless)
Δ	5- 6	66521	Latch angle
	5- 7	66522	Latch head
	5- 8	66523	Spring
	5- 9	66524	Thermal plate u
	5-10	66525	Thermal plate r
	5-13	66526	Cushion

MISCELLANEOUS

	6- 1	66527	Low rack assy
	6- 2	66528	High rack assy
	6- 3	66529	Cook book
	6- 4	66530	Thermistor harness
	6- 5	66531	Main wire harness
*	6- 6	66532	Hv wire b
	6- 7	66533	Grounding wire
	6- 8	66534	Screw caution
	6- 9	66536	Dhhs caution label
	6-11	66537	Instruction book

SCREWS NUTS AND WASHERS

7-4	66423	Screw, 4mm x 8mm
7- 5	66536	Special screw
7-6	66424	Special Screw
7- 7	66539	Special washer
7- 8	66540	Special screw
7-9	66428	Screw; 3mm x 14mm
7-10	66429	Screw; 4mm x 25mm
7-11	66775	Screw; 4mm x 6mm
7-12	66431	Screw; 4mm x 8mm
7-13	66432	Screw; 4mm x 10mm
7-14	66433	Screw; 4mm x 6mm
7-15	66541	Washer
7-16	66435	Screw; 4mm x 8mm
7-17	66436	Screw; 3mm x 6mm

DCM24B
DCM24R
DCM24S

SCREWS NUTS AND WASHERS

7-4	66423	Screw, 4mm x 8mm
7- 5	66536	Special screw
7-6	66424	Special Screw
7- 7	66539	Special washer
7- 8	66540	Special screw
7-9	66428	Screw; 3mm x 14mm
7-10	66429	Screw; 4mm x 25mm
7-11	66430	Screw; 4mm x 6mm
7-12	66431	Screw; 4mm x 8mm
7-13	66432	Screw; 4mm x 10mm
7-14	66433	Screw; 4mm x 6mm
7-15	66541	Washer
7-16	66435	Screw; 4mm x 8mm
7-17	66436	Screw; 3mm x 6mm
7-18	66542	Special Screw
7-19	66437	Screw; 4mm x 8mm
7-20	66438	Screw; 4mm x 12mm
7-21	66439	Screw; 3mm x 6mm
7-22	66440	Screw; 4mm x 8mm
7-23	66441	Screw; 6mm x 14mm
7-24	66442	Screw; 4mm x 12mm
7-25	66443	Screw; 3mm x 8mm
7-26	66444	Nut; 4mm x 3.2mm
7-27	66445	Nut; 4mm x 3.2mm
7-28	66446	Washer; 4mm x 1mm