


CABINET PARTS

For Model: EF42NBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: EF42NBSS


(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	9	2005783	Cam, Door Closer	28		Skirt-Grille, Bottom
	W10159566	Use & Care Guide	10	2209022	Housing, Water Filter		2209025B	Black
	W10165113	Energy Guide	11	3400525	Screw	29		Extension Arm, Door Closer
	W10180102	Service & Wiring Sheet	12	W10168990	Filter, Water		2266882	Right
	2306337	Icemaker and Ingredient Care Center	13	489399	Screw		2266881	Left
		Service Sheet	14	3400230	Screw, Door Stop	30		Grille Bottom, Front
	W10180891	Main Control Service Sheet	15	2257644	Hinge (Top)		2209428B	Black
	W10159564	Installation Instructions	16	2307582	Bracket, Mount (Water Filter)	31	2005921	Screw
2		Cabinet (Not A Serviceable Part)	17	489464	Screw	32		Bracket, Support Base (Front)
3	2209090	Clamp, Filter Housing	18	2004994	Lock, Adjustable Bushing		2006616	Left
4	W10138054	Roller, Front & Rear (4)	19	2300082	Bushing		2006556	Right
5		Support, Leveler Assembly	20		Spring, Door Closure	33	1157158	Screw
	2318194	Refrigerator Side		2221242	Right Side	34	2006617	Bracket, Support Base (Rear) (2)
	2318193	Freezer Side		2004517	Left Side	35	2006346	Washer
6		Cap, Water Filter	21	486194	Screw	36	2266880	Bushing, Extension Arm
	2186494B	Black	22	2005008	Retaining Ring, Adjustable Bushing	37	1163283	Screw
7	2325157	Bracket, Grill Mounting	23	W10129069	Wire Clip (5)	38	8281163	Screw
8	2307584	Grommet, Crossover Tube	24	2006342	Gap, Cover Assembly (Bottom)	40		Switch, Rocker Arm
			25		Hinge (Bottom)		1118894	Refrigerator Door Side
				2006780	Freezer Side		1115373	Freezer Door Side
				2006779	Refrigerator Side	41	2215938	Cover, Switch (2)
			26	2302876	Bushing, Adjustable	42	487415	Screw (2)
			27	8533913	Screw 1/4-20 x 5/8	43		Bracket, Switch
							2221097	Right
							2221096	Left
						44	2215612	Cover, Rear

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET TRIM PARTS

For Model: EF42NBSS
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	W10132472	Cabinet, Trim (Right Side)
3	1163283	Screw
4	2316687	Cabinet, Trim (Bottom)
5	486194	Screw
6	2314017	Cabinet, Trim Top
7	W10132541	Cabinet Trim (Left Side)
8	W10121451	Nutsert (4)
9	2005925	Seal-Trim, Side
10	489464	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER SHELF PARTS

For Model: EF42NBSS
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2302868	Wire, Shelf (2)
2	2302871	Cover, Shelf
3	2302883	Shelf, Fixed (2)
4	2259082	Basket
5	2256270	Front, Basket
6		Slide, Basket
	2259317	Right Side
	2259318	Left Side
7	8533928	Screw
8	2266934	Door, Ice
9	2266931	Bucket, Ice
10	2266955	Spacer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Model: EF42NBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS


For Model: EF42NBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2306010	Thermistor
3	2208970	Air Duct
4	2003577	Guard, Air Return
5	2259077	Ladder, Shelf (2)
6	520965	Screw Support, Ladder (8)
7	2006475	Screw
8	487539	Screw
9	2302937	Thermistor
10	2302986	Lid, Air Baffle
11	W10169528	Baffle, Control Assembly
12	2171846	Release Valve
13	2310205	Jumper, Air Baffle
14	488357	Screw
15	486194	Screw
16	2221296	Air Baffle Assembly
17	2309222	Diffuser Assembly
18	2317105	Cover, Thermistor
19	2188820	Thermistor
20	2302992	Spacer, Air-Baffle
21	2309087	Cover, Diffuser
22	2259412	Seal, Air Duct (Round Hole)
23	2259398	Seal, Air Duct (Square Hole)
24	W10159487	Diverter, Crisper Cover

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Model: EF42NBSS
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2302772	Control Box
2	2215670	Insert, Control Box
3	2310197	Wire Assembly
4	W10165120	Circuit Board, Housing Control Box
5	2221121	Support, Control Box
6	487539	Screw (2)
7	W10151210	Display Board, Ingredient Care Center
8	2162085	Socket, Light
9	2255743	Light Bulb
10	8281185	Screw
11	W10165030	Overlay, Control Box
12	2302717	Shield, Light
13	486194	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP GRILLE AND UNIT COVER PARTS

For Model: EF42NBSS
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	W10162620	Panel, Decorative
2	W10161693	Cover, Unit
3	486194	Screw
4	2256466	Back Panel
5	W10121229	Cover, Unit Front
6	487415	Screw
7	2310194	Wire Assembly RC/FC Light Switch
8	12989001	Nameplate
9	489348	Clamp
10	489399	Screw (5)
12	2215910	Grommet

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Model: EF42NBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS


For Model: EF42NBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10165103	Shelf Assy (4)
2	2256250	Trim, Glass Side Meat Pan
4	W10165091	Meat Pan Cover Assembly
5	W10165085	Crisper Cover Assembly
6	2257582	Trim, Glass Rear
7	2252412	Crisper Pan (2)
8		Slide, Meat Pan
	2302954	Left Side
	2302955	Right Side
9	2302831	Trim, Glass Front
10	2256254	Trim, Glass Rear
11	2256248	Front, Crisper Pan
12	2252255	Trim, Glass Side
13		Spacer, Crisper
	2256222	Right Side (2)
	2256223	Left Side (2)
14		Slide, Crisper
	2302957	Right Side (2)
	2302956	Left Side (2)
15		Spacer, Meat Pan
	2256243	Left Side
	2256244	Right Side
16	8533929	Screw
17	2256369	Pan Assembly Meat
18	2256366	Front, Meat Pan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER AND AIR FLOW PARTS

For Model: EF42NBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER AND AIR FLOW PARTS

For Model: EF42NBSS
(Stainless Steel)


Illus. No.	Part No.	DESCRIPTION
1	2259385	Fan Motor
2	2169142	Fan Blade
3	2223733	Retainer, Fan Motor
4	2302817	Gasket, Cover
5	2223986	Grommet
6	486194	Screw
7	2259464	Wedge, Air Duct
8	488500	Screw, Ground
9	2223857	Socket, Light (2)
10	488937	Clamp, Nylon
11	2326255	Light Bulb
12	2182120	Scroll, Fan
13	2259465	Wedge, Air Duct
14	2266801	Deflector, Air
15	2307777	Air Duct
16		Block, Fan Scroll
	2209480	Right
	2209066	Left
17		Liner (Not A Serviceable Part)
18	2259025	Cover, Air Outlet
19	2307751	Light Shield
20	W10158003	Cover, Evaporator
21	8281163	Screw
22	2302850	Support, Air Duct
23	2309283	Deflector, Air Duct
24	1112260	Support, Evaporator
25	2196483	Shelf, Stud (20)
26	8281158	Screw
27		Evaporator, Cover Rail
	2221107	Left Side
	2259355	Right Side
28	2220904	Gasket (2) Evaporator Cover
29	W10139189	Harness, Evap Fan (Includes Item 36)
30	2220241	Insulation (4)
31	2188820	Thermistor
32	2317105	Cover, Thermistor
33	2006475	Screw
34	2259032	Ladder, Shelf
35	2259445	Support, Screw
36	W10160570	Defrost, Bi-Metal
37	8281185	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Model: EF42NBS\$

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS


For Model: EF42NBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2252330	Refrigerator Door (Includes #9)
2	2258951	Brace, Door Corner
3	2266854	Hinge Assembly, Top
4	2316804	Spacer-Door, Top & Bottom
5	489282	Screw
6	2302878	Hinge Assembly, Bottom
7	2222796	Rail, Lid
8	2222982	Gasket, Utility Bin
9	2222811	Door Gasket, Magnetic
10	W10144969	Skin, Door
11	W10127710	Plate, Door Handle (4)
12	2309060	Spacer, Door (Handle Side)
13	488568	Screw
14		Screw, 8-15 x .500
	8281250	Stainless Steel
15	2005433	Spacer, Door-Skin (Top)
16	2005030	Spacer, Door (Hinge Side)
17	2004934	Spacer, Door-Skin (Bottom)
18	2005326	Filler, Door
19		End Cap
		End Cap
	2222919	Right Side
	2222920	Left Side
20	2222922	Bin, Utility Center
21	2257616	Door, Utility Bin
22	2222773	Bin, Door (3)
23	2222770	Bin, Door Door
24	W10153450	Stud, Handle (4)
25	308544	Screw (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Model: EF42NBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS


For Model: EF42NBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2252327	Freezer Door (Includes #13)
2	2302879	Hinge, Bottom
3	489282	Screw
4	2266854	Hinge, Top
5	2316804	Spacer-Door, Top & Bottom
6	2222814	Door Gasket, Magnetic
7	W10127710	Plate, Door Handle (4)
8	2309056	Spacer, Door-Skin (Handle Side)
9	W10144966	Skin, Door
10		Screw
	8281250	Stainless Steel
11	2005433	Spacer, Door-Skin (Top)
12	488568	Screw
13	2004932	Spacer, Door-Skin (Bottom)
14	2005030	Spacer, Door-Skin (Hinge Side)
15	W10127978	Filler, Door
16	2258951	Brace, Door Corner
17	2222776	Bin, Door (6)
18	W10153450	Stud, Handle (4)
19	308544	Screw (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER UNIT PARTS

For Model: EF42NBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER UNIT PARTS


For Model: EF42NBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10133449	Inverter Box	18	2317030	Arm, Vibration Condenser	39	W10167450	Wiring Harness, Unit Compartment
2	489373	Screw, Compressor Mounting (4)	19	439399	Screw	Following Parts Not Illustrated and Optional Parts Not Included		
3	2223393	Compressor (Includes Items 6 & 9)(Also Order 876765 Tube Kit)	20	2155774	Wire Tie			
4	2318087	Housing, Control Board	21	2317982	Drier	978025	Valve, Access (1/4")	
5	W10136614	Bracket, Fan Motor	22	2310207	Wire Assembly (Condenser Fan)	978026	Valve, Access (5/16")	
6	1100826	Grommet, Mounting	23	2188875	Motor, Fan	978027	Valve, Access (3/8")	
7	2309002	Support, Condenser (Right)	24	W10139483	Blade, Fan	978028	Valve, Access (1/2")	
8	2307684	Bracket, Switch	25	2003169	Orifice, Fan	978029	Valve, Access (5/8")	
9	2215676	Terminal Cover	26	2307566	Tube, Drier Transition	978030	Valve, Access (3/4")	
10	2309001	Support, Condenser (Left)	27	8533993	Screw	876764	Valve, Access (3/16")	
11	2307028	Control Board, Gemini	28	2307693	Tube, Heat Loop Transition	REFRIGERANT CHARGE		
12	2203075	Spacer (5)	30	2309432	Gasket, Condenser			
13	2256328	Bracket, Inverter Box	31	2259350	Power Supply, Ingredient Care Center	7.50 oz. (R-134A)		
14	2317031	Bracket, Vibration Condenser	32	2194319	Process, Tube			
15	1157158	Screw	33	2309000	Cover, Condenser			
16	2307998	Condenser	34	2310251	Service Cord			
17	2309431	Grommet (4)	35	486194	Screw			
			36	2266802	Switch, Power Disconnect			
			37	487294	Screw, Ground			
			38	549193	Clamp, Cord			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER UNIT AND TUBE PARTS

For Model: EF42NBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER UNIT AND TUBE PARTS


For Model: EF42NBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	486194	Screw
2	W10157752	Bracket
3	2309076	Suction Tube
4	2309070	Tube, Connect (Drier/Restrictor)
5	2320615	Drain Pan Assembly
6	W10151288	Cover, Wiring
7	W10153595	Cover, Box
8	W10121371	Tube, Discharge
9	2306093	Evaporator
10	W10140161	Heater, Defrost
11	1113048	Clamp, Heater (2)
12	W10139908	Seal, Return Air
13	2220832	Gasket, Evaporator
14	4389107	Wire Tie
15	W10169509	Clip, Heat Exchanger
16	2320554	Support, Drain Pan
17	9791833	Clip, Thermistor
18	W10160981	Bracket Assembly, Air Return
19	2215648	Dampener

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Model: EF42NBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

**For Model: EF42NBSS
(Stainless Steel)**

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST