


# CABINET PARTS

For Model: EF42DBSS03

(Stainless Steel)

42" BUILT IN  
REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

For Model: EF42DBSS03

(Stainless Steel)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	10	2209022	Housing, Water Filter	31		Extension Arm, Door Closer
	W10303784	Use & Care Guide					2266882	(RH)
	W10205631	Energy Guide	11	2209090	Clamp, Filter Housing		2266881	(LH)
	W10180103	Service & Wiring Sheet	12	3400525	Screw	32		Grille Bottom, Front
	2306424	Icemaker and Ingredient Care Center Service Sheet	13	W10168990	Filter, Water		2209428B	Black
	W10180893	Main Control Service Sheet	14	489399	Screw	33	W10004850	Screw
	W10379135	Installation Instructions	15	W10406423	Screw, Door Stop	34		Bracket, Support Base (Front)
2		Cabinet (Not A Serviceable Part)	16	2257644	Hinge (Top)		2006616	(LH)
3	W10167456	Wire Assembly	17	W10348781	Bracket, Mtg (Water Filter)		2006556	(RH)
4	W10138054	RC/FC Light Switch	18	W10001250	Screw	35	1157158	Screw
5		Roller, Front & Rear	19	W10451421	Lock, Adjustable Bushing	36	2006617	Bracket, Support Base (Rear)
		Support, Leveler Assembly	20	2300082	Bushing	37	2006346	Washer
	W10138423	Refrigerator Side	21	2004514	Clip, Conduit	38	2316859	Bushing, Extension Arm
	W10279275	Freezer Side	22	2221242	Spring, Door Closure	39	1163283	Screw
6	2186494B	Cap, Water Filter	23	486194	Screw	40	W10271540	Connector, Water Tube
7	2325157	Bracket, Grill Mounting	24	2005008	Retaining Ring, Adjustable Bushing	41	8281163	Screw
8	2307584	Grommet, Crossover Tube	25	W10129069	Wire Clip	42		Switch, Rocker Arm
9	2005783	Cam, Door Closer	26	W10406421	Gap, Cover Assembly (Bottom)		1118894	Refrigerator Door Side
			27		Hinge (Bottom)		1115373	Freezer Door Side
				W10424756	Freezer Side	43	2215938	Cover, Switch
				W10424754	Refrigerator Side	44	487415	Screw
			28	2302876	Bushing, Adjustable	45		Bracket, Switch
			29	8533913	Screw 1/4-20 x 5/8		2221097	(RH)
			30		Skirt-Grille, Bottom		2221096	(LH)
				2209025B	Black	46	2215612	Cover, Rear
						47	2005032	Leveler Assy
						48	2006841	Ring Retainer
						49	2307857	Cam Assembly

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET TRIM PARTS

For Model: EF42DBSS03

(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1		Cabinet, Trim (Right Side)
	W10132472	Stainless Steel
2		Screw
	1163283	Stainless Steel
3	2316687	Cabinet, Trim (Bottom)
4	486194	Screw
5	2314017	Cabinet, Trim Top
6		Cabinet Trim (Left Side)
	W10132541	Stainless Steel
7	W10121451	Nutsert
8	2005925	Seal-Trim, Side
9	W10001250	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER SHELF PARTS

For Model: EF42DBSS03

(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	W10175905	Wire, Shelf
2	2302883	Shelf, Fixed
3	2259082	Basket
4	2256270	Front, Basket
5	2259317 (RH) 2259318 (LH)	Slide, Basket
6	8533928	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR LINER PARTS

For Model: EF42DBSS03

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR LINER PARTS

For Model: EF42DBSS03

(Stainless Steel)


<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1		Liner (Not A Serviceable Part)
2	2306010	Thermistor
3	2208970	Air Duct
4	2259077	Ladder, Shelf
5	520965	Screw Support, Ladder
6	2006475	Screw
7	487539	Screw
8	2302937	Thermistor
9	2302986	Lid, Meat Pan Baffle
10	W10169528	Baffle Control Assembly
11	2317844	Thermistor Assy
12	2310205	Jumper, Air Baffle
13	487539	Screw
14	486194	Screw
15	2221296	Air Baffle Assembly
16	2327509	Water Reservoir
17	W10141518	Screw
18	2309222	Diffuser Assembly
19	2317105	Cover, Thermistor
20	2188820	Thermistor
21	2302992	Spacer, Air- Baffle
22	2309087	Cover, Diffuser
23	2259412	Seal, Air Duct (Round Hole)
24	2259398	Seal, Air Duct (Square Hole)
25	2003577	Guard, Return Air
26	W10159487	Diverter, Crisper Cover

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Model: EF42DBSS03

(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2302772	Control Box
2	2215670	Insert, Control Box
3	2310197	Wire, Jumper
4	W10165120	Circuit Board, Housing Control
5	2221121	Support, Control Box
6	487539	Screw
7	W10151210	Display, Ingredient Care Center
8	2162085	Socket, Light
9	W10311505	Light Bulb
10	W10142283	Screw
11	W10165030	Overlay, Control Box
12	2302717	Shield, Light
13	486194	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP GRILLE AND UNIT COVER PARTS

For Model: EF42DBSS03

(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	W10162620	Panel, Decorative Assembly Stainless Steel
2	W10161693	Cover, Unit
3	486194	Screw
4	2256466	Back Panel
5	W10185625	Cover, Unit Front
6	12989001	Badge, Dacor
7	2215910	Grommet-Flexible


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# REFRIGERATOR SHELF PARTS

For Model: EF42DBSS03

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR SHELF PARTS

For Model: EF42DBSS03


(Stainless Steel)

<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1	W10165103	Shelf Assembly
2	W10165091	Assembly, Meat Pan Cover
3	W10165085	Assembly, Crisper Cover
4	W10407624	Crisper Pan
5		Slide, Meat Pan
	2302954	(LH)
	2302955	(RH)
6	2256248	Front, Crisper Pan
7		Spacer, Crisper
	2256222	(RH)
	2256223	(LH)
8		Slide, Crisper
	2302956	(RH)
	2302957	(LH)
9		Spacer, Meat Pan
	2256243	(LH)
	2256244	(RH)
10		Screw
	8533929	Right Side– (8–18 x 1.375)
	8533928	Left Side– (8–18 x .750)
11	W10407627	Pan Assembly Meat
12	2256366	Front, Meat Pan

# FREEZER LINER AND AIR FLOW PARTS

For Model: EF42DBSS03

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER LINER AND AIR FLOW PARTS

For Model: EF42DBSS03

(Stainless Steel)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	2259385	Fan Motor	19	W10151205	Cover, Emitter	32	2220904	Gasket
2	2198665	Tube, P.C. Board	20		Liner (Not A			Evaporator Cover
3	2169142	Fan Blade			Serviceable Part)	33	W10151208	Cover, Receiver
4	2223733	Retainer,	21	2259025	Cover, Air Outlet	34	W10139189	Harness, Evap Fan
		Fan Motor	22	2307751	Light Shield			(Includes Item 45)
5	2302817	Gasket, Cover	23	W10428000	Cover, Evaporator	35	2306010	Thermistor
6	W10449920	Grommet	24	2302850	Support, Air Duct	36	2317105	Cover, Thermistor
7	486194	Screw	25	487539	Screw	37	2006475	Screw
8	2259464	Wedge, Air Duct	26	2198635	Spring	38	2259032	Ladder, Shelf
9	W10141604	Screw, Ground	27	2309283	Deflector, Air	39	2259445	Support, Screw
10	W10191429	Socket, Light			Duct	40	2198634	Pin
11	2317844	Thermistor Assy	28	1112260	Support,	41	W10193840	P.C. Board
12	2326255	Light Bulb			Evaporator			Emitter
13	489214	Screw	29	W10173127	Shelf, Stud	42	2198633	Flipper
14	2182120	Scroll, Fan	30	W10191952	Screw	43	2315398	Slide, Icemaker
15	2259465	Wedge, Air Duct	31		Evaporator,			Shut Off
16	2307774	Air Duct			Cover Rail	44	W10290817	P.C. Board,
17	2198643	Lens		2221107	(LH)			Receiver
18		Block, Fan Scroll		2259355	(RH)	45	W10160570	Defrost, Bi-Metal
	2209480	(RH)				46	W10142283	Screw
	2209066	(LH)				47	W10267707	Insulation, Sound

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MOTOR AND ICE CONTAINER PARTS

For Model: EF42DBSS03

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MOTOR AND ICE CONTAINER PARTS

For Model: EF42DBSS03

(Stainless Steel)


<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1	2222965	Ice Bin
2	W10395653	Ice Container Assembly
3	W10254073	Washer, Rubber
4	2266800	Button, Bin
5	W10134783	Latch, Bin
6	2198608	Spring, Latch
7	2198671	Screw
8	8281163	Screw
9	2188919	Holder
10	2198628	Seal
11	2318082	Drive Shaft
12	2318011	Enclosure, Motor
13	2315546	Dispenser, Motor
14	2318028	Cover
15	2315559	Sleeve. Coupling

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR DOOR PARTS

For Model: EF42DBSS03

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR DOOR PARTS

For Model: EF42DBSS03

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10193490	Refrigerator Door Panel (Includes Item #9)
3	2266854	Hinge Assembly, Top
4	2316804	Spacer-Door, Top & Bottom
5	W10162602	Screw
6	2302878	Hinge Assembly, Bottom
7	2222796	Rail, Lid
8	2222982	Gasket, Utility Bin
9	2222811	Door Gasket, Magnetic
10		Skin, Door
	W10159605	Stainless Steel
11	W10127710	Plate, Door Handle
12		Spacer, Door-Skin (Handle Side)
	2309060	For Stainless Steel Model
13	488568	Screw
14		Screw, 8-15 x .500
	8281250	Stainless Steel
15	2005433	Spacer, Door-Skin (Top)
16	308544	Screw, Handle
17	W10142296	Spacer, Door-Skin (Hinge Side)
18	2004934	Spacer, Door-Skin (Bottom)
19	W10127977	Filler, Door
20		End Cap (RH)
	W10323172	(RH)
	W10323173	(LH)
21	W10323036	Bin, Utility Center
22	2257616	Door, Utility Bin
23	W10323599	Bin, Door
24	W10323747	Bin, Gallon
25	W10168981	Stud, Mounting


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# FREEZER DOOR PARTS

For Model: EF42DBSS03

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER DOOR PARTS

For Model: EF42DBSS03

(Stainless Steel)


Illus. No.	Part No.	DESCRIPTION
1		Freezer Door
	W10292774	Stainless
2	2302879	Hinge, Bottom
3	W10162602	Screw
4	2266854	Hinge, Top
5	2316804	Spacer-Door, Top & Bottom
6	2222814	Door Gasket, Magnetic
7	W10127710	Plate, Door Handle
8		Spacer, Door-Skin (Handle Side)
	2309060	For Stainless Steel Model
9		Skin, Door
	W10165044	Stainless Steel
10		Screw
	8281250	Stainless Steel
11	2005433	Spacer, Door-Skin (Top)
12	3400091	Screw
13	2257385	Spacer, Door-Skin (Bottom)
14	W10142296	Spacer, Door-Skin (Hinge Side)
15	308544	Screw, Handle
16		Filler, Door
	W10159585	Top
	W10159582	Bottom
18	W10323602	Bin, Door
19	W10168981	Stud, Mounting
20	2252354	Spacer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DISPENSER FRONT PARTS

For Model: EF42DBSS03

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DISPENSER FRONT PARTS

For Model: EF42DBSS03

(Stainless Steel)


<u>Illus.</u>	<u>Part</u>	<u>DESCRIPTION</u>
<u>No.</u>	<u>No.</u>	
1		Housing, Dispenser (Not Serviced)
2	2195051	Strain Relief
3	W10139147	Wire Assembly
4		Cover, Dispenser (Not Serviced)
5	W10224328	Spring, Torsion
6	2196195	Pin
7	2304355	Ice Door Mechanism
8	2180353	Door, Ice
9	W10141632	Screw
10	2259396B	Lever, Ice Dispenser
11		Switch Assembly (Not Available Order #25)
12	2259395B	Lever, Water Dispenser
13	2194719	Spring, Lever
14	2205686	Delay Mechanism
15	W10282667	Bracket, Control
16	2162361	Switch
17	2259209	Bracket, Anti Drip Valve
18	2180200	Lamp Holder
19	W10141604	Screw
20		Harness, Switch (Not Available Order #25)
21	2180224	Guide, Ice
22	3406124	Light Bulb
23	2302944B	Grill, Overflow
24		Overlay, Cover (Not Serviced)
25		Front Cover Assembly (Includes Items 4,11,20 & 24)
26	2306077	Spacer, Dispenser Cover
27	2320669	Valve, Anti Drip
28	2252127	Sleeve, Delay Mechanism

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UPPER UNIT PARTS

For Model: EF42DBSS03

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UPPER UNIT PARTS

For Model: EF42DBSS03

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10133449	Inverter Box
2	489373	Screw, Compressor Mounting
3	W10173296	Compressor (Includes Items 6 & 9)(Also Order 876765 Tube Kit)
4	2318087	Housing, Control Board
5	2169104	Insulation, Sound
6	1100826	Grommet, Mounting
7	W10415668	Support, Condenser (Right)
8	W10234131	Tube, Transiton (Cond/Ht Loop)
9	2215676	Terminal Cover
10	W10415666	Support, Condenser (Left)
11	W10219463	Control Board, Gemini
12	2203075	Spacer
13	2256328	Bracket, Inverter Box
15	1157158	Screw
16	2307998	Condenser
18	2310207	Wire, Jumper

Illus. No.	Part No.	DESCRIPTION
19	489399	Screw
20	2155774	Wire Tie
21	W10175593	Drier
22	W10414681	Bracket, Fan Motor (Condenser Fan)
23	2188875	Motor, Fan
24	W10139483	Blade, Fan
25	W10415670	Orifice, Fan
26	8533993	Screw
27	2317031	Bracket, Vibration (Condenser)
28	2317030	Arm, Vibration (Condenser)
29	2307566	Tube, Transition (Condenser/Drier)
30	2194319	Tube, Process
31	486194	Screw
32	2309000	Cover, Condenser
33	2310251	Service Cord
34	W10185556	Bracket, Mounting (Power Switch)
35	549193	Clamp, Cord
36	2266802	Switch, Power Disconnect
37	487294	Screw, Ground
38	W10178883	Wiring Harness, Unit Compartment

Illus. No.	Part No.	DESCRIPTION
39	2309432	Gasket, Condenser
40	2259350	Power Supply, Ingredient Care Center

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")


## REFRIGERANT CHARGE

7.50 oz.  
(R-134A)

# LOWER UNIT AND TUBE PARTS

For Model: EF42DBSS03

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# LOWER UNIT AND TUBE PARTS

For Model: EF42DBSS03

(Stainless Steel)

<u>Illus.</u> <u>No.</u>	<u>Part</u> <u>No.</u>	<u>DESCRIPTION</u>
1	2215648	Dampener
2	486194	Screw
3	W10157752	Bracket
4	W10431124	Suction Tube Oil Trap
5	W10388653	Tube, Connect (Drier/Restrictor)
6	W10281063	Drain Pan Assy.
7	W10309012	Cover, Wiring
8	W10321048	Cover, Box
9	W10412488	Tube, Discharge
10	2188820	Thermistor
11	W10427992	Evaporator
12	W10140161	Heater, Defrost
13	1113048	Clamp, Heater
14	W10139908	Cover Seal, Evaporator Tubes
15	W10432308	Gasket, Evaporator
16	2155774	Wire Tie
17	W10169509	Clip, Heat Exchanger
18	2320554	Support, Drain Pan
20	W10160981	Bracket Assembly, Air Return


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# ICEMAKER PARTS

For Model: EF42DBSS03

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# ICEMAKER PARTS

For Model: EF42DBSS03

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10129655	Shield, Valve
2	W10377185	Wire Assembly, Icemaker
3	628379	Clip, Fuse
4	W10296807	Tube, Filter Inlet
5	2320658	Water Tube
6	2302758	Seal Gasket
7	2317912	Tube, Filter Outlet
8	2317883	Valve, Solenoid
9	2221070	Clamp, Tube
10	2320559	Support, Valve
11	2198641	Bracket, Icemaker Cover
12	2208136	Clamp, Nylon Valve
13	W10296807	Tube, Water Inlet
14	W10377172	Cover

Illus. No.	Part No.	DESCRIPTION
15	W10141604	Screw
16	W10122527	Mold & Heater (Also Order 542638 Silicone Grease)
18	W10272168	Cup-Water Fill
19	627843	Ejector
20	W10272161	Ice Stripper Thermostat
23	W10290336	Thermostat (Also Order 542639 Cement Alumilastic)
25	W10279389	Wire Assembly, Water Valve
27	W10151255	Cover, Icemaker
28	W10280888	Module & Motor Assembly
30	W10141645	Screw

Illus. No.	Part No.	DESCRIPTION
31	486194	Screw
32	2252228	Bracket, Icemaker Mounting
100	W10435671	Complete Icemaker Assembly

Following Parts Not Illustrated (Optional Parts Only)

W10355016	Affresh Stainless Steel Cleaner
W10355010	Affresh Kitchen Appliance Cleaner
W10355049	Affresh Stainless Steel Wipes
REFDEODOR	Deodorizer Pack