


CABINET PARTS

For Model: EF42DBSS02
(Stainless Steel)

42" BUILT IN
REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Model: EF42DBSS02
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	12	3400525	Screw	31		Extension Arm,
	W10159566	Use & Care Guide	13	W10168990	Filter, Water			Door Closer
	W10205631	Energy Guide	14	489399	Screw		2266882	Right
	W10180103	Service & Wiring Sheet	15	3400230	Screw, Door Stop		2266881	Left
	2306424	Icemaker and Ingredient Care Center Service Sheet	16	2257644	Hinge (Top)	32		Grille Bottom, Front
	W10180893	Main Control Service Sheet	17	W10348781	Bracket, Mtg (Water Filter)		2209428B	Black
	W10291430	Installation Instructions	18	489464	Screw	33	2005921	Screw
2		Cabinet (Not A Serviceable Part)	19	2004994	Lock, Adjustable Bushing	34		Bracket, Support Base (Front)
4	W10138054	Roller, Front & Rear (4)	20	2300082	Bushing		2006616	Left
5		Support, Leveler Assembly	21	2004514	Clip, Conduit		2006556	Right
	W10138423	Refrigerator Side	22	2221242	Spring, Door Closure	35	1157158	Screw
	W10279275	Freezer Side	23	486194	Screw	36	2006617	Bracket, Support Base (Rear) (2)
6	2186494B	Cap, Water Filter Black	24	2005008	Retaining Ring, Adjustable Bushing	37	2006346	Washer
7	2325157	Bracket, Grill Mounting	25	W10129069	Wire Clip (5)	38	2316859	Bushing, Extension Arm
8	2307584	Grommet, Crossover Tube	26	2006342	Gap, Cover Assembly (Bottom)	39	1163283	Screw
9	2005783	Cam, Door Closer	27		Hinge (Bottom)	40	2209709	Connector, Water Tube
10	2209022	Housing, Water Filter		2006780	Freezer Side	41	8281163	Screw
11	2209090	Clamp, Filter Housing		2006779	Refrigerator Side	42		Switch, Rocker Arm
			28	2302876	Bushing, Adjustable		1118894	Refrigerator Door Side
			29	8533913	Screw 1/4-20 x 5/8		1115373	Freezer Door Side
			30		Skirt-Grille, Bottom	43	2215938	Cover, Switch (2)
				2209025B	Black	44	487415	Screw (2)
						45		Bracket, Switch
							2221097	Right
							2221096	Left
						46	2215612	Cover, Rear

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET TRIM PARTS

For Model: EF42DBSS02
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1		Cabinet, Trim (Right Side)
	W10132472	Stainless Steel
2		Screw
	1163283	Stainless Steel
3	2316687	Cabinet, Trim (Bottom)
4	486194	Screw
5	2314017	Cabinet, Trim Top
6		Cabinet Trim (Left Side)
	W10132541	Stainless Steel
7	W10121451	Nutsert (4)
8	2005925	Seal-Trim, Side
9	489464	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER SHELF PARTS

For Model: EF42DBSS02
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	W10175905	Wire, Shelf
2	2302883	Shelf, Fixed (2)
3	2259082	Basket
4	2256270	Front, Basket
5		Slide, Basket
	2259317	Right Side
	2259318	Left Side
6	8533928	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Model: EF42DBSS02
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


REFRIGERATOR LINER PARTS

For Model: EF42DBSS02
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2306010	Thermistor
3	2208970	Air Duct
4	2259077	Ladder, Shelf (2)
5	520965	Screw Support, Ladder (8)
6	2006475	Screw
7	487539	Screw
8	2302937	Thermistor
9	2302986	Lid, Meat Pan Baffle
10	W10169528	Baffle Control Assembly
12	2310205	Jumper, Air Baffle
13	488357	Screw
14	486194	Screw
15	2221296	Air Baffle Assembly
16	2327509	Reservoir
17	488280	Screw
18	2309222	Diffuser Assembly
19	2317105	Cover, Thermistor
20	2188820	Thermistor
21	2302992	Spacer, Air-Baffle
22	2309087	Cover, Diffuser
23	2259412	Seal, Air Duct (Round Hole)
24	2259398	Seal, Air Duct (Square Hole)
25	2003577	Guard, Return Air
26	W10159487	Diverter, Crisper Cover

CONTROL PANEL PARTS

For Model: EF42DBSS02
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2302772	Control Box
2	2215670	Insert, Control Box
3	2310197	Wire, Jumper
4	W10165120	Circuit Board, Housing Control
5	2221121	Support, Control Box
6	487539	Screw (2)
7	W10151210	Display, Ingredient Care Center
8	2162085	Socket, Light
9	W10311505	Light Bulb
10	8281185	Screw
11	W10165030	Overlay, Control Box
12	2302717	Shield, Light
13	486194	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP GRILLE AND UNIT COVER PARTS

For Model: EF42DBSS02
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1		Panel, Decorative Assembly
	W10162620	Stainless Steel
2	W10161693	Cover, Unit
3	486194	Screw
4	2256466	Back Panel
5	W10185625	Cover, Unit Front
6	487415	Screw
7	W10167456	Wire Assembly
		RC/FC Light Switch
8	12989001	Badge, Dacor
9	489348	Clamp
11	2215910	Grommet-Flexible

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Model: EF42DBSS02
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


REFRIGERATOR SHELF PARTS

For Model: EF42DBSS02
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10165103	Shelf Assembly
3	W10165091	Assembly, Meat Pan Cover
4	W10165085	Assembly, Crisper Cover
5	2257582	Trim, Glass Rear
6	2252412	Crisper Pan (2)
7		Slide, Meat Pan
	2302954	Left Side
	2302955	Right Side
8	2302831	Trim, Glass Front
9	2256254	Trim, Glass Rear
10	2256248	Front, Crisper Pan
11	2252255	Trim, Glass Side Crisper Pan
12	2256250	Trim, Glass Side Meat Pan
13		Spacer, Crisper
	2256222	Right Side (2)
	2256223	Left Side (2)
14		Slide, Crisper
	2302956	Right Side
	2302957	Left Side
15		Spacer, Meat Pan
	2256243	Left Side
	2256244	Right Side
16		Screw
	8533929	Right Side— (8-18 x 1.375)
	8533928	Left Side— (8-18 x .750)
17	2256369	Pan Assembly Meat
18	2256366	Front, Meat Pan

FREEZER LINER AND AIR FLOW PARTS

For Model: EF42DBSS02
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


FREEZER LINER AND AIR FLOW PARTS

For Model: EF42DBSS02
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	2259385	Fan Motor	19	W10151205	Cover, Emitter	32	2220904	Gasket (2)
2	2198665	Tube, P.C. Board	20		Liner (Not A			Evaporator Cover
3	2169142	Fan Blade			Serviceable Part)	33	W10151208	Cover, Receiver
4	2223733	Retainer, Fan Motor	21	2259025	Cover, Air Outlet	34	W10139189	Harness, Evap Fan (Includes Item 55)
5	2302817	Gasket, Cover	22	2307751	Light Shield	35	2306010	Thermistor
6	2223986	Grommet	23	W10158003	Cover, Evaporator	36	2317105	Cover, Thermistor
7	486194	Screw	24	2302850	Support, Air Duct	37	2006475	Screw
8	2259464	Wedge, Air Duct	25	487539	Screw	38	2259032	Ladder, Shelf
9	488500	Screw, Ground	26	2198635	Spring	39	2259445	Support, Screw
10	2223857	Socket, Light (2)	27	2309283	Deflector, Air Duct	40	2198634	Pin
11	489348	Clamp, Nylon	28	1112260	Support, Evaporator	41	W10193840	P.C. Board
12	2326255	Light Bulb	29	W10173127	Shelf, Stud	42	2198633	Flipper
13	489214	Screw	30	8281158	Screw	43	2315398	Slide, Icemaker Shut Off
14	2182120	Scroll, Fan	31		Evaporator, Cover Rail	44	W10290817	P.C. Board, Receiver
15	2259465	Wedge, Air Duct		2221107	Left Side	45	W10160570	Defrost, Bi-Metal
16	2307774	Air Duct		2259355	Right Side	46	8281185	Screw
17	2198643	Lens						
18		Block, Fan Scroll						
	2209480	Right						
	2209066	Left						

MOTOR AND ICE CONTAINER PARTS

For Model: EF42DBSS02
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Model: EF42DBSS02


(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2222965	Ice Bin
2	W10151247	Crusher Bin
3	W10140642	Auger
4	2258220	Washer, Auger
5	1119007	Spacer, Flat (6)
6	2317248	Cover, Crusher
7	W10341944	Blade, Rotary
8	1119005	Spacer, Step (2)
9	2257020	Blade, Fixed
10	W10341943	Blade, Rotary
11	2317239	Block, Blade
12	489229	Roll Pin
13	W10341942	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2188918	Coupling, Top
17	8281164	Screw
18	3400065	Screw
19	2266800	Button, Bin
20	W10134783	Latch, Bin
21	2198608	Spring, Latch
22	2198671	Screw (2)
23	8281163	Screw
24	2188919	Holder
25	2198628	Seal
26	2318030	Drive Shaft
27	2318011	Enclosure, Motor
28	2315546	Dispenser, Motor
29	2318028	Cover
30	2315559	Sleeve, Coupling
31	2317250	Divider-Chamber
32	2317243	Wiper

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Model: EF42DBSS02
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


REFRIGERATOR DOOR PARTS

For Model: EF42DBSS02
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10193490	Refrigerator Door Panel (Includes Item #9)
3	2266854	Hinge Assembly, Top
4	2316804	Spacer–Door, Top & Bottom
5	W10162602	Screw
6	2302878	Hinge Assembly, Bottom
7	2222796	Rail, Lid
8	2222982	Gasket, Utility Bin
9	2222811	Door Gasket, Magnetic
10	W10159605	Skin, Door Stainless Steel
11	W10127710	Plate, Door Handle (4)
12		Spacer, Door–Skin (Handle Side)
	2309060	For Stainless Steel Model
13	488568	Screw
14		Screw, 8–15 x .500
	8281250	Stainless Steel
15	2005433	Spacer, Door–Skin (Top)
16	308544	Screw, Handle
17	W10142296	Spacer, Door–Skin (Hinge Side)
18	2004934	Spacer, Door–Skin (Bottom)
19	W10127977	Filler, Door
20		End Cap
	W10323172	Right Side
	W10323173	Left Side
21	W10323036	Bin, Utility Center
22	2257616	Door, Utility Bin
23	W10323599	Bin, Door
24	W10323747	Bin, Gallon
25	W10168981	Stud, Mounting (4)

FREEZER DOOR PARTS

For Model: EF42DBSS02
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS


For Model: EF42DBSS02

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10292774	Freezer Door Stainless
2	2302879	Hinge, Bottom
3	W10162602	Screw
4	2266854	Hinge, Top
5	2316804	Spacer-Door, Top & Bottom
6	2222814	Door Gasket, Magnetic
7	W10127710	Plate, Door Handle (4)
8		Spacer, Door-Skin (Handle Side)
	2309060	For Stainless Steel Model
9	W10165044	Skin, Door Stainless Steel
10		Screw
	8281250	Stainless Steel
11	2005433	Spacer, Door-Skin (Top)
12	488568	Screw
13	2257385	Spacer, Door-Skin (Bottom)
14	W10142296	Spacer, Door-Skin (Hinge Side)
15	308544	Screw, Handle
16		Filler, Door
	W10159585	Top
	W10159582	Bottom
18	W10323602	Bin, Door
19	W10168981	Stud, Mounting (4)
20	2252354	Spacer

DISPENSER FRONT PARTS

For Model: EF42DBSS02
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


DISPENSER FRONT PARTS

For Model: EF42DBSS02
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	2195051	Strain Relief
3	W10139147	Wire Assembly
4		Cover, Dispenser (Not Serviced)
5	W10224328	Spring, Torsion
6	2196195	Pin
7	2304355	Ice Door Mechanism
8	2180353	Door, Ice
9	489000	Screw
10	2222558	Lever, Ice Dispenser
11		Switch Assembly (Not Available Order #25)
12	2222559	Lever, Water Dispenser
13	2194719	Spring, Lever
14	2205686	Delay Mechanism
15	W10282667	Bracket, Control
16	2162361	Switch (2)
17	2259209	Bracket, Anti Drip Valve
18	2180200	Lamp Holder
19	488500	Screw
20	W10279375	Harness, Switch
21	2180224	Guide, Ice
22	3406124	Light Bulb
23	2302944B	Grill, Overflow
24		Overlay, Cover (Not Serviced)
25		Front Cover Assembly (Includes Items 4,11,20 & 24)
26	2306077	Spacer, Dispenser Cover
27	2320669	Valve, Anti Drip
28	2252127	Sleeve, Delay Mechanism

UPPER UNIT PARTS

For Model: EF42DBSS02
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER UNIT PARTS

For Model: EF42DBSS02

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10133449	Inverter Box
2	489373	Screw, Compressor Mounting (4)
3	W10173296	Compressor (Includes Items 6 & 9)(Also Order 876765 Tube Kit)
4	2318087	Housing, Control Board
6	1100826	Grommet, Mounting
7	2309002	Support, Condenser
8	W10234131	Tube, Transiton (Cond/Ht Loop) (Right)
9	2215676	Terminal Cover
10	2309001	Support, Condenser (Left)
11	W10219463	Control Board, Gemini
12	2203075	Spacer (5)
13	2256328	Bracket, Inverter Box
15	1157158	Screw
16	2307998	Condenser
17	2309431	Grommet (2)
18	2310207	Wire, Jumper
19	489399	Screw
20	2155774	Wire Tie
21	W10175593	Drier

Illus. No.	Part No.	DESCRIPTION
22	W10136614	Bracket, Fan Motor (Condenser Fan)
23	2188875	Motor, Fan
24	W10139483	Blade, Fan
25	2003169	Orifice, Fan
26	8533993	Screw
27	2317031	Bracket, Vibration (Condenser)
28	2317030	Arm, Vibration (Condenser)
29	2307566	Tube, Transition (Condenser/Drier)
30	2194319	Tube, Process
31	486194	Screw
32	2309000	Cover, Condenser
33	2310251	Service Cord
34	W10185556	Bracket, Mounting (Power Switch)
35	549193	Clamp, Cord
36	2266802	Switch, Power Disconnect
37	487294	Screw, Ground
38	W10178883	Wiring Harness, Unit Compartment
39	2309432	Gasket, Condenser
40	2259350	Power Supply, Ingredient Care Center


Illus. No.	Part No.	DESCRIPTION
Following Parts Not Illustrated and Optional Parts Not Included		
	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978028	Valve, Access (1/2")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")

REFRIGERANT CHARGE

7.50 oz.
(R-134A)

LOWER UNIT AND TUBE PARTS

For Model: EF42DBSS02
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


LOWER UNIT AND TUBE PARTS

For Model: EF42DBSS02
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2215648	Dampener
2	486194	Screw
3	W10157752	Bracket
4	2309076	Suction Tube
5	W10388653	Tube, Connect (Drier/Restrictor)
6	W10281063	Drain Pan Assy.
7	W10151288	Cover, Wiring
8	W10153595	Cover, Box
9	W10121371	Tube, Discharge
10	2188820	Thermistor
11	W10205101	Evaporator
12	W10140161	Heater, Defrost
13	1113048	Clamp, Heater (2)
14	W10139908	Cover Seal, Evaporator Tubes
15	2220832	Gasket, Evaporator
16	2155774	Wire Tie
17	W10169509	Clip, Heat Exchanger
18	2320554	Support, Drain Pan
19	9791833	Clip, Thermistor
20	W10160981	Bracket Assembly, Air Return

ICEMAKER PARTS

For Model: EF42DBSS02
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Model: EF42DBSS02
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10129655	Shield, Valve
2	2310191	Wire Assembly, Ice maker
3	628379	Clip, Fuse
4	2325170	Tube, Filter Inlet
5	2320658	Water Tube
6	2302758	Seal Gasket
7	2317912	Tube, Filter Outlet
8	2317883	Valve, Solenoid
9	2221070	Clamp, Tube
10	2320559	Support, Valve
11	2198641	Bracket, Ice maker Cover
12	2305274	Clamp, Nylon Valve
13	W10296807	Tube, Water Inlet
14	2257538	Cover
15	488500	Screw

Illus. No.	Part No.	DESCRIPTION
16	W10122527	Mold & Heater (Also Order 542638 Silicone Grease)
17		Motor, (Not Serviceable Order Item 28)
18	628356	Cup-Water Fill
19	627843	Ejector
20	2198598	Ice Striper
21	2194712	Support
22	2315522	Retainer
23	628397	Thermostat (2) (Also Order 542639 Cement Alumilastic)
24	8533917	Screw
25	W10139193	Wire Assembly, Water Valve
26	489276	Screw
27	W10151255	Cover, Ice maker

Illus. No.	Part No.	DESCRIPTION
28	W10223929	Module Assembly (Includes Items 17 & 29)
29	489136	Screw (2)
30	489464	Screw
31	486194	Screw
32	2252228	Bracket, Ice maker Mounting
100	2320636	Complete Ice maker Assembly

Following Parts Not Illustrated (Optional Parts Only)

8537055	Cleaner, Stainless Steel
W10395653	Ice Container Assembly