

(Stainless Steel)

This exploded view diagram illustrates the assembly of a refrigerator cabinet. The main components are the top panel (1), the front panel (2), and the side panel (3). The diagram shows the following parts and their assembly sequence:

- Top Panel (1):** The main top surface, which is attached to the side panel (3) using screws (16, 17, 18, 22, 24, 26, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48).
- Front Panel (2):** The main front surface, which is attached to the side panel (3) using screws (16, 17, 18, 22, 24, 26, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48).
- Side Panel (3):** The main side surface, which is attached to the front panel (2) using screws (16, 17, 18, 22, 24, 26, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48).
- Door Assembly:** The door is attached to the front panel (2) using a hinge (4) and a latch (5). The door is also attached to the side panel (3) using a hinge (6) and a latch (7). The door is also attached to the front panel (2) using a hinge (8) and a latch (9). The door is also attached to the side panel (3) using a hinge (10) and a latch (11).
- Internal Components:** The internal components, including the evaporator (12), condenser (13), and compressor (14), are shown in their relative positions within the cabinet.

The diagram includes a legend for "Literature Parts" and a list of part numbers (1 through 48) corresponding to the various components and fasteners shown.

Part No. W10404403 Rev. A

CABINET PARTS

For Model: EF48DBSS02

(Stainless Steel)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	10	2307584	Grommet, Crossover Tube	32		Skirt-Grille, Bottom
	W10159566	Use & Care Guide	11	2005783	Cam, Door Closer		2209026B	Black
	W10205632	Energy Guide	12	2209022	Housing, Water Filter	33		Extension Arm, Door Closer
	W10180103	Service & Wiring Sheet	13	2209090	Clamp, Filter Housing		2266882	Right
	2306424	Icemaker and Ingredient Care Center Service Sheet	14	3400525	Screw		2266881	Left
	W10180893	Main Control Service Sheet	15	W10168990	Filter, Water	34		Grille Bottom, Front
	W10291430	Installation Instructions	16	489399	Screw		2209431B	Black
2		Cabinet (Not A Serviceable Part)	17	3400230	Screw, Door Stop	35	2005921	Screw
4	W10138054	Roller, Front & Rear (4)	18	2257644	Hinge (Top)	36		Bracket, Support Base (Front)
5		Support, Leveler Assembly	19	W10348781	Bracket, Mtg (Water Filter)		2006616	Left
	W10138423	Refrigerator Side	20	489464	Screw		2006556	Right
	W10279275	Freezer Side	21	2004994	Lock, Adjustable Bushing	37	1157158	Screw
6	2005032	Leveler, Adjustable (2)	22	2300082	Bushing	38	2006617	Bracket, Support Base (Rear) (2)
7	2006841	Ring, Retaining (2) Flexible	24	2221242	Spring, Door Closure	39	2006346	Washer
8		Cap, Water Filter	25	486194	Screw	40	2316859	Bushing, Extension Arm
	2186494B	Black	26	2005008	Retaining Ring, Adjustable Bushing	41	1163283	Screw
9	2325157	Mounting Stud, Grille	27	W10129069	Wire Clip (5)	42	2209709	Connector, Water Tube
			28	2006342	Gap, Cover Assembly (Bottom)	44		Switch, Rocker Arm
			29		Hinge (Bottom)		1118894	Refrigerator Door Side
				2006780	Freezer Side		1115373	Freezer Door Side
				2006779	Refrigerator Side	45	2215938	Cover, Switch (2)
			30	2302876	Bushing, Adjustable	46	487415	Screw (2)
			31	8533913	Screw 1/4-20 x 5/8	47		Bracket, Switch
							2221097	Right
							2221096	Left
						48	2215612	Cover, Rear

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET TRIM PARTS

For Model: EF48DBSS02

(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1		Cabinet, Trim (Right Side)
	W10132472	Stainless Steel
3		Screw
	1163283	Stainless Steel
4	2316688	Cabinet, Trim (Bottom)
5	486194	Screw
6	2314018	Cabinet, Trim Top
7		Cabinet Trim (Left Side)
	W10132541	Stainless Steel
8	W10121451	Nutsert (4)
9	2005925	Seal-Trim, Side
10	489464	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER SHELF PARTS

For Model: EF48DBSS02

(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	W10175906	Wire, Shelf (4)
3	2302884	Shelf, Fixed (2)
4	2259083	Basket
5	2256271	Front, Basket
6		Slide, Basket
	2259317	Right Side
	2259318	Left Side
7	8533928	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Model: EF48DBSS02
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Model: EF48DBSS02


(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2306010	Thermistor
3	2208970	Air Duct
4	2003577	Guard, Air Return
5	2259077	Ladder, Shelf (2)
6	520965	Screw Support, Ladder (8)
7	2006475	Screw
8	487539	Screw
9	2302937	Thermistor
10	2302986	Lid, Meat Pan Baffle
11	W10169528	Baffle Control Assembly
13	2310205	Jumper, Air Baffle
14	488357	Screw
15	486194	Screw
17	2221296	Air Baffle Assembly
18	2327509	Reservoir
19	488280	Screw
21	2309222	Diffuser Assembly
22	2317105	Cover, Thermistor
23	2188820	Thermistor
24	2302992	Spacer, Air-Baffle
25	2309087	Cover, Diffuser
27	2259412	Seal, Air Duct (Round Hole)
28	2259398	Seal, Air Duct (Square Hole)

CONTROL PANEL PARTS

For Model: EF48DBSS02

(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2302773	Control Box
2	2215670	Insert, Control Box
3	2310197	Wire Assembly, UI Control
4	W10165120	Circuit Board, Control Box
5	2221121	Housing Control Support, Control Box
6	489006	Screw (2)
7	W10151210	Display, Ingredient Care Center
8	2162085	Socket, Light
9	W10311505	Light Bulb (2)
10	8281185	Screw
11	W10165031	Overlay, Control Box
12	2302716	Shield, Light
13	486194	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP GRILLE AND UNIT COVER PARTS

For Model: EF48DBSS02

(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1		Panel, Decorative Assembly
	W10162621	Stainless Steel
2	W10161693	Cover, Unit
3	486194	Screw
4	2256466	Back Panel
5	W10185625	Cover, Unit Front
6	487415	Screw
7	W10167456	Wire Assembly
		RC/FC Light Switch
8	12989001	Badge, Dacor
9	489348	Clamp
11	2215910	Grommet, Flexible

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Model: EF48DBSS02

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Model: EF48DBSS02


(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10165104	Shelf Assembly (4)
3	W10165092	Assembly, Meat Pan Cover
4	W10165086	Assembly, Crisper Cover
5	2257583	Trim, Glass Rear
6	2252413	Crisper Pan (2)
7		Slide, Meat Pan
	2302954	Left Side
	2302955	Right Side
8		Trim, Glass Front (Not Serviceable)
9	2256255	Trim, Glass Rear
10	2256249	Front, Crisper Pan
11	2252255	Trim, Glass Side Crisper Pan
12	2256250	Trim, Glass Side Meat Pan
13		Spacer, Crisper
	2256222	Right Side (2)
	2256223	Left Side (2)
14		Slide, Crisper
	2302956	Right Side
	2302957	Left Side
15		Spacer, Meat Pan
	2256243	Left Side
	2256244	Right Side
16		Screw
	8533929	Right Side- (8-18 x 1.375)
	8533928	Left Side- (8-18 x .750)
17	2256370	Pan Assembly Meat
18	2256367	Front, Meat Pan

FREEZER LINER AND AIR FLOW PARTS

For Model: EF48DBSS02

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER AND AIR FLOW PARTS


For Model: EF48DBSS02

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	2259385	Fan Motor	18		Block, Fan Scroll	32	2220904	Gasket (2)
2	2198665	Tube, P.C. Board		2209482	Right			Evaporator Cover
3	2169142	Fan Blade		2209066	Left	33	W10151208	Cover, Receiver
4	2223733	Retainer, Fan Motor	19	W10151205	Cover, Emitter	34	W10139189	Harness, Evap Fan (Includes Item 45)
5	2302817	Gasket, Cover	20		Liner (Not A Serviceable Part)	35	2306010	Thermistor
6	2223986	Grommet	21	2259025	Cover, Air Outlet	36	2317105	Cover, Thermistor
7	486194	Screw	22	2307751	Light Shield	37	2006475	Screw
8	2259464	Wedge, Air Duct	23	W10158005	Cover, Evaporator	38	2259032	Ladder, Shelf
9	488500	Screw, Ground	24	2302851	Support, Air Duct	39	2259445	Support, Screw
10	2223857	Socket, Light (2)	25	487539	Screw	40	2198634	Pin
11	488937	Clamp, Nylon	26	2198635	Spring	41	W10193840	P.C. Board
12	2326255	Light Bulb	27	2309284	Deflector, Air Duct	42	2198633	Flipper
13	489214	Screw	28	1112260	Support, Evaporator	43	2315398	Slide, Icemaker Shut Off
14	2182120	Scroll, Fan	29	W10173127	Shelf, Stud	44	W10290817	P.C. Board, Receiver
15	2259465	Wedge, Air Duct	30	8281158	Screw	45	W10160570	Defrost, Bi-Metal
16	2307775	Air Duct	31		Evaporator, Cover Rail	46	8281185	Screw
17	2198643	Lens		2221107	Left Side			
				2259355	Right Side			

MOTOR AND ICE CONTAINER PARTS

For Model: EF48DBSS02
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Model: EF48DBSS02

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2222970	Ice Bin
2	W10151248	Crusher Bin
3	W10140642	Auger
4	2258220	Washer, Auger
5	1119007	Spacer, Flat (6)
6	2317248	Cover, Crusher
7	W10278731	Blade, Rotary
8	1119005	Spacer, Step (2)
9	2257020	Blade, Fixed
10	W10278732	Blade, Rotary
11	2317239	Block, Blade
12	489229	Roll Pin
13	W10278733	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2188918	Coupling, Top
17	8281164	Screw
18	3400065	Screw
19	2266800	Button, Bin
20	W10134785	Latch, Bin
21	2198608	Spring, Latch
22	2198671	Screw (2)
23	8281163	Screw
24	2188919	Holder
25	2198628	Seal
26	2318030	Drive Shaft
27	2318011	Enclosure, Motor
28	2315546	Dispenser, Motor
29	2318028	Cover
30	2315559	Sleeve, Coupling
31	2317250	Divider, Chamber
32	2317243	Wiper

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

(Stainless Steel)



REFRIGERATOR DOOR PARTS

For Model: EF48DBSS02


(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10193491	Refrigerator Door Panel (Includes Item #9)
3	2266854	Hinge Assembly, Top
4	2316804	Spacer-Door, Top & Bottom
5	W10162602	Screw
6	2302878	Hinge Assembly, Bottom
7	2222797	Rail, Lid
8	2222983	Gasket, Utility Bin
9	2222812	Door Gasket, Magnetic
10		Skin, Door
	W10121043	Stainless Steel
12		Spacer, Door-Skin (Handle Side)
	2309060	For Stainless Steel Model
13	W10168981	Stud, Handle
14	488568	Screw
15		Screw, 8-15 x .500
	8281250	Stainless Steel
16	2005433	Spacer, Door-Skin (Top)
17	308544	Screw, Handle
18	W10142296	Spacer, Door-Skin (Hinge Side)
19	2004935	Spacer, Door-Skin (Bottom)
20	W10127980	Filler, Door
21		End Cap
	W10323172	Right Side
	W10323173	Left Side
22	W10127710	Plate, Door-Handle
23	W10323037	Bin, Utility Center
24	2257617	Door, Utility Bin
25	W10323600	Bin, Door
26	W10323748	Bin, Gallon

FREEZER DOOR PARTS

For Model: EF48DBSS02

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Model: EF48DBSS02


(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10292777	Freezer Door (Includes #6)
2	2302879	Hinge, Bottom
3	W10162602	Screw
4	2266854	Hinge, Top
5	2316804	Spacer-Door, Top & Bottom
6	2222812	Door Gasket, Magnetic
7	W10168981	Stud, Handle
8		Spacer, Door-Skin (Handle Side)
	2309060	For Stainless Steel Model
9		Skin, Door
	W10165045	Stainless Steel
10		Screw
	8281250	Stainless Steel
11	2005433	Spacer, Door-Skin (Top)
12	488568	Screw
13	2257386	Spacer, Door-Skin (Bottom)
14	W10142296	Spacer, Door-Skin (Hinge Side)
15	308544	Screw, Handle
16		Filler, Door
	W10159586	Top
	W10159583	Bottom
18	W10323603	Bin, Door (3)
19	W10127710	Plate, Door Handle

DISPENSER FRONT PARTS

For Model: EF48DBSS02

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER AND FRONT PARTS

For Model: EF48DBSS02


(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	2195051	Strain Relief
3	W10139147	Wire Assembly
4		Cover, Dispenser (Not Serviced)
5	W10224328	Spring, Torsion
6	2196195	Pin
7	2304355	Ice Door Mechanism
8	2180353	Door, Ice
9	489000	Screw
10	2259396B	Lever, Ice
11		Switch Assembly (Not Available, Order #25)
12	2259395B	Lever, Water
13	2194719	Spring, Lever
14	2205686	Delay Mechanism
15	W10282667	Bracket, Control
16	2162361	Switch (2)
17	2259209	Bracket, Anti Drip Valve
18	2180200	Lamp Holder
19	488500	Screw
20	W10279375	Harness, Switch
21	2180224	Guide, Ice
22	3406124	Light Bulb
23	2302944B	Grill, Overflow
24		Overlay, Cover (Not Serviced)
25	W10165055	Front Cover Assembly (Includes 4,11,20, & 24)
26	2306077	Spacer, Dispenser Cover
27	2320669	Valve, Anti Drip
28	2252127	Sleeve, Delay Mechanism

UPPER UNIT PARTS

For Model: EF48DBSS02

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER UNIT PARTS

For Model: EF48DBSS02

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10133449	Inverter Box
2	489373	Screw, Compressor Mounting (4)
3	W10173296	Compressor (Includes Items 6 & 9)(Also Order 876765 Tube Kit)
4	2318087	Housing, Control Board
6	1100826	Grommet, Mounting
7	2309002	Support, Conenser
8	W10234133	Tube, Tranisiton (Cond/Ht Loop) (Right)
9	2215676	Terminal Cover
10	2309001	Support, Condenser (Left)
11	W10219463	Control Board
12	2203075	Spacer (5)
13	2256328	Bracket, Inverter Box
14	486194	Screw
15	1157158	Screw
16	2307998	Condenser
17	2309431	Grommet (2)
18	2310207	Wire, Jumper

Illus. No.	Part No.	DESCRIPTION
19	489399	Screw
20	2155774	Wire Tie
21	W10175593	Drier
22	W10136614	Bracket, Fan Motor (Condenser Fan)
23	2188875	Motor, Fan
24	W10139483	Blade, Fan
25	2003169	Orifice, Fan
27	8533993	Screw
28	2317031	Bracket, Vibration (Condenser)
29	2317030	Arm, Vibration (Condenser)
30	2307566	Tube, Transition (Condenser/Drier)
31	2194319	Tube, Process
32	486194	Screw
33	2309000	Cover, Condenser
34	2310251	Service Cord
35	W10185556	Bracket, Mounting (Power Switch)
36	549193	Clamp, Cord
37	2266802	Switch, Power Disconnect
38	487294	Screw, Ground
39	W10178883	Wiring Harness, Unit Compartment
40	2309432	Gasket, Condenser

Illus. No.	Part No.	DESCRIPTION
41	2259350	Power Supply, Ingredient Care Center

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

7.75 oz.
(R-134A)

(Stainless Steel)



LOWER UNIT AND TUBE PARTS

For Model: EF48DBSS02


(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	9791833	Clip
2	486194	Screw
3	W10157752	Bracket
4	2309076	Suction Tube
5	2309070	Tube, Connect (Drier/Restrictor)
6	W10281063	Drain Pan Assy.
7	W10151288	Cover, Wiring
8	W10153595	Cover, Box
9	W10121374	Tube, Discharge
10	2188820	Thermistor
11	W10205102	Evaporator
12	W10140162	Heater, Defrost
13	1113048	Clamp, Heater (2)
14	W10139908	Seal, Return Air
15	2220832	Gasket, Evaporator
16	2155774	Wire Tie
17	W10169509	Clip, Heat Exchanger
18	2320554	Support, Drain Pan
19	2215648	Dampener
20	W10160981	Bracket Assembly, Air Return
21	489464	Screw

ICEMAKER PARTS

For Model: EF48DBSS02

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

**For Model: EF48DBSS02
(Stainless Steel)**

Following Parts Not Illustrated
(Optional Parts Only)

8537055 Cleaner,
Stainless Steel
W10151246 Ice Container
Assembly