

# Location of Rating Plate







## Sealed Burner

\*The rating plate is **under the griddle or storage drawer area.**

## Open Burner

\*The rating plate is located **under the cooktop** which can be accessed by removing grates and lifting top portion of cooktop or **under Right Front burner.**