

 **Garland**[®]

 **U.S. Range**[®]

Product Identification Plate Locations

Choose a product category:

Electric Counter Top Equipment

Gas Counter Top Equipment

Electric Medium Duty Equipment, (Restaurant ranges, etc.)

Gas Medium Duty Equipment, (Restaurant ranges, etc.)

Electric Heavy Duty Equipment

Gas Heavy Duty Equipment

Electric Oven Products

Gas Oven Products

[Click here to return to the category list.](#)

Electric Counter Top Equipment

Brand	Description	Models	Rating Plate Location
Garland ED Series	ED Series Hot Plate	ED-15H ED15-15HSE EDU-15HSE	Accessible by opening the enameled door located below the control panel.
	ED Series Griddles	ED-15G ED-24G ED-36G EDU-15G EDU-24G EDU-36G	
	ED Series Broilers	ED-15B ED-30B ED-42B EDU-15B EDU-30B EDU-42B	
	ED Series Food Warmer	ED15W ED15WP EDU15W ED15WP	
	ED Series Super Fryer	ED15SF ED30SFT EDU18SF EDU36SF	
Garland	Electric Counter Pizza oven Bake ovens	CPO-ES-12H CPO-ED-22 CPO-ES-22H CPO-ED-24H CBO-ED-12H CBO-ES-11 CBO-ED-11	Affixed to the main back panel
		CHO-22-24H	Affixed on the lower left front
	Counter Conveyor Oven	CVO-E-12H	
	Product Holding Drawer	PHD	Affixed to the back above power cord entrance
Garland E22 Series	E22 Series Hotplate	E22-12H	Affixed to bottom below rear element
	E22 Series Fryers	E22-14F E22-28F	Affixed to inside back (remove fryer tank)
	E22 Series Food Warmers	E22-15W E22-15WP	Affixed to left top corner of front panel
	E22 Series Char-Broilers	E22-12B E22-24B E22-36B E22-36M	Affixed to side of grease drawer (remove drawer)
	E22 Series Griddles	E22-18G E22-24G E22-36G	
	E22 Series Sandwich Griddle	E22-18SG	
	E22 Series Japanese Steak Griddles	E22-36-36GM E22-36-45GM E22-36-48GM E22-56GM E22-36-56GM E22-36-60GM E22-36-68GM E22-36-72GM	Affixed to main front panel above control
	E22 Series Drop-In Hot Food Wells	HW1000 HW1000D HW1300 HW1300D	Affixed to main bottom left front corner
	E22 Series Pizza Oven	E22-22P E22-22PP	Affixed to main top
Garland E24 Series	E24 Series Hot Plates and Griddles	E24-12H E24-24G E24-36G E24-48G E24-60G E24-72G	Affixed to back exterior panel
	E24 Series Food warmer	E24-32W E24-32WP	Affixed to main bottom (remove lower front panel)
	E24 Series Griddles	E24-24/36/48/60/72G	Affixed to side of grease drawer (remove drawer)
	E24 Series Heavy Duty Fryer	E24-31F E24-31SF	Affixed to switch cover (remove fryer tank)
Garland Induction	Single, Dual & Wok Table Top Models	GIU 2.5/3.5/5.0 GIU3.5/5.0DUAL GIWOK3.5/5.0	Affixed to the right rear near where line cord enters
	Single, Multi-Functional Table Top Units	GMIU3.5/5.0	

[Click here to return to the category list.](#)

[Click here to return to the category list.](#)

Gas Counter Top Equipment

Brand	Description	Models	Rating Plate Location
US Range Regal Series	Counter Griddle Manually Controlled	RGM2424/36/48/60/72-1	Affixed to griddle frame, front center, against the grease trough. Accessible by removing the knobs and valve panel.
	Counter Griddle Manually Controlled With Open Burners	RGM2424/36/48/60/72-1-2	
	RGTA Series Thermostatically Controlled Griddle	RGTA2424/36/48/60/72-1	Affixed to front of the frame, left or right side.
	RGTA Series Thermostatically Controlled Griddle With Open Burners	RGTA2424/36/48/60/72-1	
	Hot Plates	RPHA112/212/224/336/424/636/ RPHA848/1060	Affixed to the front frame. Can be viewed by tilting unit up and looking underneath.
	Char Broilers	RBA24/30/36/48/60/72	Affixed to the right side of the appliance
Garland GX Series	GX Series Counter Griddle Manually Controlled	GXM2424/36/48/60/72-1	Affixed to griddle frame, front center, against the grease trough. Accessible by removing the knobs and valve panel.
	GX Series Counter Griddle Manually Controlled With Open Burners	GXM2424/36/48/60/72-1-2	
	GX Series Thermostatically Controlled Griddle	GTX2/3/4/5/6	
	GX Series Thermostatically Controlled Griddle With Open Burners	GX12/13/14/15/16T2	
	GX Series Hot Plates	GXHP11/12/22/33/42/63/84/105	Affixed to the front frame. Can be viewed by tilting unit up and looking underneath.
	GXCM Series Cheese Melter	GXC24/36/48/60/72/96/120	Affixed the frame behind the valve cover. Visible through the air intake above the cheesemelter cavity.
	GX series Radiant Char Broilers	GXRN24/30/36/48/60/72	Affixed to the inside of the landing ledge. Accessible after removing the knobs and valve panel.
	GX Series Char Broilers Char Glo Series	GXC24/30/36/48/60 GXR24/30/36/48/60 GXRJR21/30	Affixed to the Char- Broiler's body, on the left hand inside wall at the lower front. It is accessible after opening the front apron door.
Garland GD Series	All Gas Designer Series Counter Units	GD-152/302/304H[FF] GD-15G GD15-G[FF] GD-15TH GD-24G[FF.] GD-24GTH GD-36G[FF.] GD36GTH GD-18B[FF.] GD-24B[FF.] GD30-RB[FF] GD-36RB[FF]	Accessible by opening the enameled door located below the control panel.

[Click here to return to the category list.](#)

[Click here to return to the category list.](#)

Electric Medium Duty Equipment

Brand	Description	Models	Rating Plate Location
Garland	All Garland 680 Series Restaurant Ranges	S/SS/SU684/686 S/SS/SU684/686/RC	Affixed to the front edge of the chassis bottom, behind the front kick panel
	All Garland 680 Series Salamander Broilers	SERC/SUERC SER-68 SUER-680	Affixed to the inside rear of the cabinet, accessible by removing the drip tray

Gas Medium Duty Equipment

Brand	Description	Models	Rating Plate Location
Garland	Fryer	35-280, H35-280	Affixed to the frypot inside the cabinet
	Cheesemelters	GCM24-280, GCM36-280, GCM48-280, GCM60-280, GCM72-280, GCM2/3C/W	Affixed to lower cross member directly under the drip tray
	Salamander Broilers	IR36-280L/C/W, IR48-280L, IR60-280L, IR72-280L	
	All Garland Gas Medium Duty Ranges	All "280" and "380" Series with prefixes: G, GV, H, P, S, ST All G34 and G30A/GV30A	Affixed to the front edge of the chassis bottom, behind the front kick panel
US Range	Performer Series Ranges	All with prefixes: P, PX, PS	
	SunFire Series Ranges	All with prefixes: S, SX	
	Regal Series Stock Pot Range	SP-1844	Affixed inside the cabinet body, accessible by removing the control knobs and panel
	Regal Salamander Broilers	BS-WX/RX/CX	Affixed to body behind the upper stainless steel trim. To view remove trim, [two screws at each end]
	Regal Cheesemelters	IMRCA24/36/48/60/72/96/120	Affixed to frame behind the valve cover; visible through the air intake above the cheesemelter cavity
Performer Series Fryer	PSM-35	Affixed to inner side panel	

Electric Heavy Duty Equipment

Brand	Description	Models	Rating Plate Location
Garland	36E and 10 Series Heavy Duty Electric Ranges	All oven-base models with suffix R	Affixed to the front edge of the chassis bottom, behind the front kick panel
		All modular top models with suffix T	Affixed behind the fuse cover
		All storage-base models with suffix S	Affixed to upper right, front corner of cabinet liner
	10 Series Fryers	10-31, 10-70	
	36E and 10 Series Attachments	36ES15, 36ES16, 10-28, 10-29	Affixed to the frypot inside the cabinet
	36E Series Fryers	36ES/11/11SF/11BL/11SFBL 36ET11 36ST11SF 36ES21 36ET21 680-31F/SF/FBL/SFBL	
	Range-Mount Broilers	ER36, ER10, ERC	Affixed to the bottom of broiler; accessible by removing the drip tray
	10 Series Broilers	10-33	Affixed to the left side drip tray guide

[Click here to return to the category list.](#)

[Click here to return to the category list.](#)

Gas Heavy Duty Equipment

Brand	Description	Models	Rating Plate Location
Garland	Master Series Ranges and Attachments	All 2, 4, 5, 6, 7, 8, 17, 24, 34, 42, 43, 44, 45, 46, 47, 48, 54 with prefixes: M, MS, MST, with suffixes: R, RC	Affixed to the front edge of the chassis bottom, behind the front kick panel
		All 4, 5, 6, 7, 8, 17, 24, 34, 42, 43, 44, 45, 46, 47, 48, 54 with prefixes: M, MS, MST, with suffixes: S, B	Affixed to the inside left of the cabinet
		All 4, 5, 6, 7, 8, 17, 24, 34, 42, 43, 44, 45, 46, 47, 48, 54 with prefixes: M, MS, MST, with suffix T	Affixed to the front panel
	Master Series Gas Fryers	M35SS, MST35SS, M70SS, MST70SS	Affixed to the frypot inside the cabinet
	Master Series Upright Broilers	M60X, M76R/RC, M78R/RC, M100XR/RC	Affixed to the front edge of the chassis bottom, behind the front kick panel
		M67, M110	Affixed to top of unit, front, center
		M60/67/78S/T	Affixed to the front panel
		M60/100X/T	Affixed to the lower front panel
	Master Series Cheesemelter	MCM	Affixed to lower cross member directly under the drip tray
	Master Series Range-Mount Broiler	MIR34	
	40-50 Series Gas Broilers	60-40R, 6-40R, 76-40R, 78-40R	Affixed behind the lower front panel
		IR-67, IR77	Affixed to top of unit, front, center
		6-40S/T, 7-40S/T, 8-40S/T	Affixed to the front panel
		G80	Affixed to the inside of the bottom pan
		80B-40S	Affixed to the inside of the cabinet
		80B-40SD	Affixed to the inside of the cabinet door
40-50 Series Range-Mount Broiler	IR34-40	Affixed to lower cross member directly under the drip tray	
40-50 Series Cheesemelter	GCM34-40		
US Range	Cuisine Series Ranges	All 836, C836, C0836 Series	Affixed to the front edge of the chassis bottom, behind the front kick panel
	Cuisine Series Fryers	836/841-1414-1, 2	Affixed to the inside of the cabinet door
	Cuisine Infra-Red Broiler	1100, C2100M	Affixed to body behind upper stainless steel trim; viewed through air intake slot above the broiler cavity on right side

[Click here to return to the category list.](#)

[Click here to return to the category list.](#)

Electric Ovens			
Brand	Description	Models	Rating Plate Location
Garland	All Deck Ovens	All Air-Deck models with prefix: E56	Affixed to left outside of control enclosure
		All E2000 Series	Affixed to left inside of control enclosure behind the control panel
		APO1, APO4	
	All Master Series and Trendsetter Convection Ovens	All models with prefixes: MCO-E, MCOE, ECO-E. ICO-E, TE	Affixed to inside of lower front cover
US Range	All SunFire and Summit Series Convection Ovens	All with prefixes: SEM, SUM-E, ICO-E	

Gas Ovens			
Brand	Description	Models	Rating Plate Location
Garland	All Deck Ovens	All Air-Deck models with prefix: G56	Affixed to left outside of control enclosure
		All G2000 Series	Affixed to the inside of combustion chamber front access door
		All GPD Series	
	All Garland and Trendsetter Convection Ovens	All models with prefixes: ECO-G. ICO-G, TG	Affixed to inside of lower front cover
Master Series Convection Ovens	All models with prefixes: MCO-G. MCOG		
US Range	All Summit Series Convection Ovens	All with prefixes: SGM, SUM-G	Affixed to the inside of combustion chamber front access door
	All SunFire Series Convection Ovens	All with prefix: SDG	

[Click here to return to the category list.](#)