

RESIDENTIAL POWER DIRECT VENT GAS WATER HEATERS MODELS

UG40-38TFPDV-N2U

UG50-38TFPDV-N2U, UG50-41TFPDV-N2U/UG50-41TFPDV-P2U

UG50-60(-54)-LFPDV-N1U/UG50-65(-59)LFPDV-N1U

UG60-38MFPDV-N1U, UG60-41MFPDV-N1U/UG60-41MFPDV-P1U

I.D.	Part #	Description	For Use With Models
1	56000152-A	Gas control valve	All natural gas
2	56001004-A	Flammable vapor sensor	All
3	14000006-A	Protective cover	All
4	58000155-A	Ignitor assembly	All
5	06000822-A 06001241-A 06001217-A 06001223-A 06001223-A 06001231-A 06001229-A 06001526-A 06001520-A	Burner assembly Burner assembly Burner assembly Burner assembly Burner assembly Burner assembly Burner assembly Burner assembly Burner assembly	UG40-38TFPDV-N2U UG50-38TFPDV-N2U UG50-41TFPDV-N2U UG50-60LFPDV-N1U UG50-59LFPDV-N1U UG50-54LFPDV-N1U UG50-65LFPDV-N1U UG60-38MFPDV-N1U UG60-41MFPDV-N1U
6	KITPV001 KITPV002	Inner access door kit1 Inner access door kit1	UG40, UG50-38(-41) UG50-60(-54), UG50-65(-59), UG60
7	99000155-A	Outer access door	All
8	15000028-A	Brass drain valve	All
9	19000006-A 19000005-A	Overflow tube Overflow tube	UG40, UG50-38(-41), UG60 UG50-60(-54), UG50-65(-59)
10	22000414-A 22000415-A 22000404-A 22000405-A 22000406-A	Diptube with heat trap Diptube with heat trap Diptube Diptube Diptube	UG40-38 UG50-38 UG50-41, UG60-41 UG60-38 UG50-60(-54), UG50-65(-59)
11	MS145410 MS145320	Magnesium anode rod Magnesium anode rod	UG40, UG50-38(-41), UG60 UG50-60(-54), UG50-65(-59)
12	SV0Z4220 18G0022	T&P relief valve T&P relief valve	UG40, UG50-38(-41) UG50-60(-54), UG50-65(-59), UG60
13	99000063-A 99000064-A 99000065-A	Baffle Baffle Baffle	UG40, UG50-38(-41), UG60 UG50-65(-59) UG50-60(-54)
14	84000003-A 84000004-A	Inlet rubber adaptor 3" Inlet rubber adaptor 2"	UG50-41(-54)(-59)(-60)(-65), UG60-41 UG40-38, UG50-38, UG60-38
15	60000013-A* 60000004-A 60000007-A	Vacuum switch - Inlet Vacuum switch - Inlet Vacuum switch - Inlet	UG50-38* UG50-41, UG60-41 UG50-60(-54), UG50-65(-59), UG40-38, 50-38, 60-38
16	60000012-A 60000009-A 60000008-A	Vacuum switch - Outlet Vacuum switch - Outlet Vacuum switch - Outlet	UG40-38, UG50-38, UG60-38 UG50-41, UG60-41 UG50-60(-54), UG50-65(-59)
17	56001010-A	High limit switch 165° F	All
18	84000017-A 84000002-A	Outlet rubber adaptor 2" Outlet rubber adaptor 3"	UG40-38, UG50-38, UG60-38 All (except 38 000 BTU)
19	06801701-A 06801701-A-A 80000006-A 80000007-A 80000007-1A	Blower assembly (until April 12, 2011) Blower assembly (starting April 13, 2011) Blower assembly Blower assembly (until Jan. 23, 2011) Blower assembly (starting Jan. 24, 2011)	UG50-38 UG40-38, UG50-38, UG60-38 UG50-41, UG60-41 UG50-60(-54), UG50-65(-59) UG50-60(-54), UG50-65(-59)
20	NP022241 16001110-A 16000014-A	Outlet nipple Outlet nipple with heat trap Outlet nipple	UG50-38, UG50-41, UG60-41 UG40-38, UG50-38, UG60-38 UG50-60(-54), UG50-65(-59)
21	14010002-A 14010003-A	Restrictor screen 2" Restrictor screen 3"	UG40-38, UG50-38, UG60-38 UG40-38, UG50-38, UG60-38

¹ (includes both door and All gasket)


* (Until April 13, 2011)

RESIDENTIAL POWER DIRECT VENT GAS WATER HEATERS (CONTINUED)

For PROPANE models substitute the following:

I.D.	Part #	Description	For Use With Models
1	56000153-A	Gas control valve	All propane
5	06001230-A	Burner assembly	UG50-41TFPDV-P2U
	06001521-A	Burner assembly	UG60-41MFPDV-P1U

All propane burner manifolds are LEFT HAND THREAD



REPLACEMENT PARTS LIST

