

RESIDENTIAL POWER VENT GAS WATER HEATERS

MODELS PV1

UG40-40LFPV1-N1U/UG40-38LFPV1-P1U

UG50-40LFPV1-N1U/UG50-38LFPV1-P1U

UG60-40MFPV1-N2U/UG60-38MFPV1-P2U

I.D.	Part #	Description	For Use With Models
1	56000152-A	Gas control valve	All
2	56001004-A	Flammable vapour sensor	All
3	14000006-A	Protective cover	All
4	58000155-A	Igniter assembly	All
5	06000820-A 06001237-A 06001522-A	Burner assembly Burner assembly Burner assembly	UG40-40LFPV1 UG50-40LFPV1 UG60-40MFPV1
6	KITPV001 KITPV002	Inner access door kit Inner access door kit	UG40 UG50, 60
7	99000155-A	Outer access door	All
8	56001001-A	Resettable high limit 270°F	All
9	15000028-A	Brass drain valve	All
10	19000005-A 19000006-A	Overflow tube Overflow tube	UG40, 50 UG60
11	22000407-A 22000417-A 22000408-A 22000418-A 22000415-A	Dip tube Dip tube with heat trap Dip tube Dip tube with heat trap Dip tube with heat trap	UG40-N1U UG40-N2U UG50-N1U UG50-N2U UG60
12	MS145320 MS145410	Magnesium anode rod Magnesium anode rod	UG40, 50 UG60
13	18G0022 SV0Z4220	T&P relief valve T&P relief valve	UG40, 50(N1U) UG40, 50, 60(N2U)
14	99000066-A 99000063-A	Flue baffle Flue baffle	UG40, UG50 UG60
15	60000010-A 60000011-A 60000014-A	Vacuum switch -0.50" w.c. Vacuum switch -0.55" w.c. Vacuum switch -0.65" w.c.	UG40-PV1 UG50-PV1 UG60-PV1
16	56001011-A	High limit switch 155°F	All PV1
17	84000017-A	Rubber adaptor	All PV1
18	06801501/A-A 06801502-A 80000012-A	Blower assembly Blower assembly Blower assembly	UG40-PV1 UG50-PV1 UG60-PV1
19	NP022302 16001111-A NP022241 16001110-A	Outlet nipple Outlet nipple with heat trap Outlet nipple Outlet nipple with heat trap	UG40(N1U) UG40(N2U) UG50, 60(N1U) UG50, 60(N2U)
20	14010001-A	Restrictor screen	All N2U

For PROPANE models substitute the following:

I.D.	Part #	Description	For Use With Models
1	56000153-A	Gas control valve	All
5	06000821-A 06001238-A 06001523-A	Burner assembly Burner assembly Burner assembly	UG40-38LFPV1-P1U UG50-38LFPV1-P1U UG60-38MFPV1-P2U

All propane burner manifolds are LEFT HAND THREAD

