




Model 6120 / 8120 Electric Range Parts Chart Model 6130 / 8130 Electric Self Clean Range Parts Chart



Model 6120 / 8120 / 6130 /8130 Range Parts Chart

1110 Oven Door Handle Stanchion
1115 Hardwood Oven Door Handle
1120 Outer Oven Door Panel
1125 Oven Door Thermometer (Non Functional)
1302 Fire Door Panel
1307 Fire Door Frame
1311 Ash Pan Door - Complete
H-306 Ash Door Hinge Pin (not shown)
1320 Wire Spring Handle
1325 Bell Damper Handle
1330 Bell Damper
1521 Splash Back
1545 Cresting Panel
1546 Heartland nameplate/Clips
1551 Right Cabinet Bracket
1556 Left Cabinet Bracket
1570 Lower Cabinet Strip
1575 Upper Cabinet Strip
1588 Right Cabinet Corner
1592 Left Cabinet Corner
1596 Right Cresting Corner
1599 Left Cresting Corner
1607 Front Cabinet Door Panel
1610 Cabinet Door Handle
1660 Reservoir Insert Panel
4523 Splash back
4545 Cresting Panel
4570 Lower Cabinet Strip
4575 Upper Cabinet Strip
4607 Cabinet Door
2455 Base Rail - Front
2456 Base Rail - Rear
4012 Base Leg
5203 Reservoir Front
6029 Ash Catch
6162 Burner Control Knob
6163 Bake/Broil Knob
6161 Pan Sensor Knob
6171 Indicator Light - Red
6176 Ash Door Hinge (not shown)
6177 Ash Door Catch
6183 6" Ultra Temp Solid Element
6184 7" Ultra Temp Solid Element
6185 9" Ultra Temp/Pan Sensor Solid element
6197 2 Speed Blower Control Switch

6198 Range Light Switch
6202 Oven Light Bulb - 40W
6313 Front Band
6345 Pan Sensor Element Control Switch
6246 Solid Element Switch
6347 Oven/Broiler Control Switch
6348 Self Clean Oven/Broiler Control Switch
6384 Self Clean Rocker Switch
6387 Self Clean Oven Door Gasket
6462 Control Cover Plate (not shown)
6460 Stove Top
6437 Oven Door Hinges L & R (not shown)
6455 Broiler Pan & Cover
6522 Exhaust Deflector
6536 Cabinet Wrap Weldment
6675 Exhaust Filter (30")
6676 Exhaust Filter (48")
6677 3 1/2" x 10" Exhaust Adaptor
6679 Exhaust Blower
6740 Installation and Operating Instruction Manual
6914 Drawer Assembly
8200 Light Socket & Housing
8204 Oven Lens
8432 Control Cover Plate (not shown)
8313 Front Band
8430 Stove Top
8455 Base Rail Front / Sides
8456 Base Rail Rear
8536 Cabinet Wrap
9105 Drawer - Front Panel
9106 Utility Drawer Frame
9141 Oven Door Frame Weldment
9142 Oven Door Gasket
9143 Lower Oven Door Gasket
9234 Self Clean Electronic Timer
9235 Electronic Timer
9239 Broiler Element
9241 Oven Element
9449 Oven Rack Support (4 position)
9452 Oven Rack
H-692 Easy Glide Castor 1" Diameter

**NOTE: WHEN ORDERING PORCELAIN PANELS,
PLEASE SPECIFY COLOR**