

INSTRUCTION MANUAL

INSTALLATION / OPERATIONS / PARTS & SERVICE

MONTAGUE REFRIGERATION AND FREEZER BASES



MODEL(S):

RB36SC—RB108SC

RB36R—RB108R


RB36 FREEZER—RB108 FREEZER

**These instructions should be read thoroughly before attempting installation.
Set up and installation should be performed by qualified installation personnel.**

**PLEASE RETAIN THIS MANUAL
FOR FUTURE REFERENCE.**




EXPLODED VIEW #1



EXPLODED VIEW #1 PARTS LIST

ITEM #	PART #	DESCRIPTION	MODELS USED FOR
1	70030-4RA	FAN HOUSING	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
2	70031-2RA	CONDENSING GUARD	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
3	70032-0RA	CONDENSER SHELF	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
4	70044-4RA	CC BOTTOM SHELF	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
5	70045-2RA	CC EXTERIOR TOP	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
6	70046-0RA	CC EXTERIOR BOTTOM	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
7	70047-9RA	CC BOTTOM & TOP CHANNEL SUPPORT	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
8	70061-4RA	CC EXTERIOR, SIDE RIGHT	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
9	70084-2RA	CC EXTERIOR, INNER SIDE	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
10	70085-1RA	LOUVER, TOP RAIL	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
11	70087-8RA	LOUVER, PANEL	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
12	70148-3RA	INNER LOUVER, TOP RAIL	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
13	70190-4RA	CC SLIDING SHELF	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
14	70191-2RA	SHELF, SLIDER LEFT & RIGHT	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
15	70228-5RA	CC EXTERIOR, SIDE COVER	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
16	59682-5	1/3 COMPRESSOR	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC
	59681-7	1/3+ COMPRESSOR	RB-84-SC, RB-96-SC, RB-108-SC
17	59667-1	AXIAL FAN, 4"	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
18	19118-3	CASTER WITH LOCK	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
19	19119-1	CASTER WITHOUT LOCK	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
20	33604-1	NUT SCREW	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC

EXPLODED VIEW #2



EXPLODED VIEW #2 PARTS LIST

ITEM #	PART #	DESCRIPTION	MODEL/S USED WITH
1	70002-9RA	LINER SIDE, LEFT & RIGHT	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
2	70023-1RA	DRAWER TRACK, LEFT	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
3	70025-8RA	DRAWER TRACK, RIGHT	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
4	70026-6RA	TRACK MOUNT, LEFT	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
5	70027-4RA	TRACK MOUNT, RIGHT	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
6	70028-2RA	TRACK MOUNT, FRONT LEFT	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
7	70029-0RA	TRACK MOUNT, FRONT RIGHT	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
8	70006-1RA 70111-4 70165-3RA 70268-4RA 70269-2RA 70270-6RA 70271-4RA 70483-0RA	LINER, BACK LINER, BACK LINER, BACK LINER, BACK LINER, BACK LINER, BACK LINER, BACK LINER, BACK	RB-36-SC RB-48-SC,RB-36-R RB-60-SC,RB-48-R RB-72-SC,RB-60-R RB-84-SC,RB-72-R RB-96-SC,RB-84-R RB-108-SC,RB-96-R RB-108-R
9	70009-6RA 70112-2 70155-6RA 70272-2RA 70273-0RA 70274-9RA 70275-7RA 70481-4RA	LINER, BOTTOM LINER, BOTTOM LINER, BOTTOM LINER, BOTTOM LINER, BOTTOM LINER, BOTTOM LINER, BOTTOM LINER, BOTTOM	RB-36-SC RB-48-SC,RB-36-R RB-60-SC,RB-48-R RB-72-SC,RB-60-R RB-84-SC,RB-72-R RB-96-SC,RB-84-R RB-108-SC,RB-96-R RB-108-R
10	70012-6RA 70113-0 70156-4RA 70276-5RA 70277-3RA 70278-1RA 70280-3RA 70482-2RA	LINER, TOP LINER, TOP LINER, TOP LINER, TOP LINER, TOP LINER, TOP LINER, TOP LINER, TOP	RB-36-SC RB-48-SC,RB-36-R RB-60-SC,RB-48-R RB-72-SC,RB-60-R RB-84-SC,RB-72-R RB-96-SC,RB-84-R RB-108-SC,RB-96-R RB-108-R

PARTS LIST CONTINUED ON NEXT PAGE

EXPLODED VIEW #2 PARTS LIST CONTINUED


11		TURBO COIL	SEE "ADDITIONAL INFORMATION" TABLE FOR DETAILS
12	59676-0	HEX JAM NUT	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
13	59630-2	SKATE WHEEL	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
14	59675-2	SPACER	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
15	59683-3	DIGITAL THERMOSTAT	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
16	19118-3	CASTER WITH LOCK	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
17	60516-6	DIGITAL THERMOSTAT TEMPERATURE PROBE	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC

ADDITIONAL INFORMATION

ITEM #	PART #	DESCRIPTION	MODEL/S USED WITH
11	59690-6	TC-800 SLAVE, TXV ONLY	RB-48-R,RB-60-SC
11	59694-9	TC-1200 SLAVE, TXV ONLY	RB-60-R,RB-72-SC,RB-72-R,RB-84-SC,RB-84-R,RB-96-SC,RB-96-R, RB-108-SC,RB-108-R
11	59693-0	TC-1200 HALF-PREP, TXV, SOLENOID VALVE, SOLENOID COIL, NO T-STAT	RB-36-SC,RB-36-R,RB-48-SC
*11	59692-2	TC-1200 MASTER HALF-PREP, TXV, SOL- ENOID VALVE, SOLENOID COIL, NO T-STAT, EXTRA 1/4" LIQUID LINE TO FEED ADDITIONAL SLAVE COIL/S	RB-48-R,RB-60-SC,RB-60-R,RB-72-SC,RB-72-R,RB-84-SC,RB-84-R RB-96-SC,RB-96-R,RB-108-SC,RB-108-R

* PART # 59692-2 IS LOCATED IN ALL NOTATED MODELS. WHEN LOOKING AT THE FRONT OF THE UNIT, IT IS THE EVAPORATOR COIL LOCATED ON THE FURTHEST RIGHT HAND SIDE.

EXPLODED VIEW #3



EXPLODED VIEW #3 PARTS LIST


ITEM #	PART #	DESCRIPTION	MODELS USED FOR
1	70014-2RA	DRAWER SLIDE RIGHT	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
2	70015-0RA	DRAWER SLIDE LEFT	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
3	70018-5RA	DRAWER STOP	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
4	70022-3RA	HANDLE ENDS	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-36-SC,RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
5	70042-8RA	PAN DIVIDER	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
6	70020-7RA	DRAWER FACE	RB-48-R,RB-36-SC,RB-60-SC
	70160-2RA	DRAWER FACE	RB-48-R,RB-60-R,RB-84-R,RB-108-R,RB-60-SC,RB-72-SC,RB-96-SC
	70106-8RA	DRAWER FACE	RB-36-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-48-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
7	70021-5RA	DRAWER HANDLE	RB-48-R,RB-36-SC,RB-60-SC
	70107-6RA	DRAWER HANDLE	RB-36-R,RB-48-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-48-SC,RB-60-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
8	70199-8RA	BACK COVER(BOTTOM DRAWER)	RB-48-R,RB-36-SC,RB-60-SC
	70019-3RA	BACK COVER(TOP DRAWER)	RB-48-R,RB-36-SC,RB-60-SC
	70161-0RA	BACK COVER(BOTTOM DRAWER)	RB-48-R,RB-60-R,RB-84-R,RB-108-R,RB-60-SC,RB-72-SC,RB-96-SC
	70162-9RA	BACK COVER(TOP DRAWER)	RB-48-R,RB-60-R,RB-84-R,RB-108-R,RB-60-SC,RB-72-SC,RB-96-SC
	70108-4RA	BACK COVER(BOTTOM DRAWER)	RB-36-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-48-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC
	70110-6RA	BACK COVER(TOP DRAWER)	RB-36-R,RB-60-R,RB-72-R,RB-84-R,RB-96-R,RB-108-R RB-48-SC,RB-72-SC,RB-84-SC,RB-96-SC,RB-108-SC

PARTS LIST CONTINUED ON NEXT PAGE

EXPLODED VIEW PARTS LIST #3 CONTINUED

9	70016-9RA	PAN BACK DIVIDER	RB-48-R, RB-36-SC, RB-60-SC
	70164-5RA	PAN BACK DIVIDER	RB-48-R, RB-60-R, RB-84-R, RB-108-R, RB-60-SC, RB-72-SC, RB-96-SC
	70114-9RA	PAN BACK DIVIDER	RB-36-R, RB-60-R, RB-72-R, RB-84-R, RB-96-R, RB-108-R RB-48-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
10	70017-7RA	PAN FRONT DIVIDER	RB-48-R, RB-36-SC, RB-60-SC
	70163-7RA	PAN FRONT DIVIDER	RB-48-R, RB-60-R, RB-84-R, RB-108-R, RB-60-SC, RB-72-SC, RB-96-SC
	70115-7RA	PAN FRONT DIVIDER	RB-36-R, RB-60-R, RB-72-R, RB-84-R, RB-96-R, RB-108-R RB-48-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
11	70200-5RA	DRAWER SUPPORT	RB-36-R, RB-48-R, RB-60-R, RB-72-R, RB-84-R, RB-96-R, RB-108-R RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
12	59630-2	SKATE WHEEL	RB-36-R, RB-48-R, RB-60-R, RB-72-R, RB-84-R, RB-96-R, RB-108-R RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
13	59675-2	SPACER	RB-36-R, RB-48-R, RB-60-R, RB-72-R, RB-84-R, RB-96-R, RB-108-R RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
14	60784-3	TOP DRAWER GASKET WITH SWEEP GASKET, 15.875" x 9.125"	RB-48-R, RB-36-SC, RB-60-SC
	60783-5	BOTTOM DRAWER GASKET, NO SWEEP GASKET, 15.875" x 9.125"	RB-48-R, RB-36-SC, RB-60-SC
	60785-1	TOP DRAWER GASKET WITH SWEEP GASKET, 23.875" x 9.125"	RB-48-R, RB-60-R, RB-84-R, RB-108-R, RB-60-SC, RB-72-SC, RB-96-SC
	60787-8	BOTTOM DRAWER GASKET, NO SWEEP GASKET, 23.875" x 9.125"	RB-48-R, RB-60-R, RB-84-R, RB-108-R, RB-60-SC, RB-72-SC, RB-96-SC
	60788-6	TOP DRAWER GASKET WITH SWEEP GASKET, 28.750" x 9.125"	RB-36-R, RB-60-R, RB-72-R, RB-84-R, RB-96-R, RB-108-R RB-48-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
	60789-4	BOTTOM DRAWER GASKET, NO SWEEP GASKET, 28.750" x 9.125"	RB-36-R, RB-60-R, RB-72-R, RB-84-R, RB-96-R, RB-108-R RB-48-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC

EXPLODED VIEW #4



EXPLODED VIEW #4 PARTS LIST

ITEM #	PART #	DESCRIPTION	MODELS USED FOR
1	60513-1	SIGHT GLASS	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
2	60535-2	LOW PRESSURE SWITCH	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC
3	60524-7	LIQUID LINE FILTER DRIER	RB-36-SC, RB-48-SC, RB-60-SC, RB-72-SC, RB-84-SC, RB-96-SC, RB-108-SC