


Parts Breakdown

Model CE-CN-0021 43217

Model CE-CN-0047 43218

Model CE-CN-0066 45599





Parts Breakdown

Model CE-CN-0021 43217

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
62243	Shell for FD-21	1	62256	Connection Plate for FD-21	17	62270	Tray Grid for FD-21	31
62244	Hinge Wheels for FD-21	2	62257	Middle Board for FD-21	18	62271	Left and Right Door Trim for FD-21	32
62245	Insulation for FD-21	3	62258	Heating Element for FD-21	19	62272	Inner Glass for FD-21	33
62246	Exhaust Pipe for FD-21	4	62259	Fan Blade for FD-21	20	62273	Hinge Assembly for FD-21	34
62247	Power Cord for FD-21	5	62260	Connection Pole for FD-21	21	62274	Outer Glass for FD-21	35
62248	Terminal for FD-21	6	62261	Wind Board for FD-21	22	62275	Front Door Frame for FD-21	36
66166	Heat Insulation Board for FD-21	7	62262	Sensor Fixture for FD-21	23	62276	Handle for FD-21	37
62249	Space Holder for FD-21	8	62263	Interior for FD-21	24	62278	Thermostat for FD-21	39
62250	Wire Buckle for FD-21	9	62264	Grid Screws for FD-21	25	62279	Control Panel for FD-21	40
62251	Rear Board for FD-21	11	62265	Feet for FD-21	26	62280	Heating Light for FD-21	41, 44
62252	Temperature Cut-Out for FD-21	12, 38	62266	Bottom Board for FD-21	27	62281	Knob Spring Plate for FD-21	42
62253	Motor for FD-21	13	62267	Up and Bottom Door Clip for FD-21	28	62282	Thermostat Knob for FD-21	43, 45
62254	Motor Base for FD-21	14	62268	Door Seal for FD-21	29	62285	Insulation Ties for FD-21	46
62255	Motor Insulation for FD-21	16	62269	Tray for FD-21	30	62286	Switch for FD-21	47

Model CE-CN-0047 43218

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
62287	Shell for FD-47	1	62256	Connection Plate for FD-47	17	62298	Tray Grid for FD-47	31
62288	Hinge Wheels for FD-47	2	62292	Middle Board for FD-47	18	62299	Left and Right Door Trim for FD-47	32
62289	Insulation for FD-47	3	62293	Heating Element for FD-47	19	62300	Inner Glass for FD-47	33
62246	Exhaust Pipe for FD-47	4	62259	Fan Blade for FD-47	20	62301	Hinge Assembly for FD-47	34
62290	Power Cord for FD-47	5	62260	Connection Pole for FD-47	21	62302	Outer Glass for FD-47	35
62248	Terminal for FD-47	6	62261	Wind Board for FD-47	22	62303	Front Door Frame for FD-47	36
66166	Heat Insulation Board for FD-47	7	62262	Sensor Fixture for FD-47	23	66169	Handle for FD-47	37
62249	Space Holder for FD-47	8	62295	Interior for FD-47	24	62278	Thermostat for FD-47	39
62250	Wire Buckle for FD-47	9	62264	Grid Screws for FD-47	25	62304	Control Panel for FD-47	40
62291	Rear Board for FD-47	11	62265	Feet for FD-47	26	62280	Heating Light for FD-47	41, 44
62252	Temperature Cut-Out for FD-47	12, 38	62296	Bottom Board for FD-47	27	62281	Knob Spring Plate for FD-47	42
62253	Motor for FD-47	13	66167	Up and Bottom Door Clip for FD-47	28	62282	Thermostat Knob for FD-47	43, 45
62254	Motor Base for FD-47	14	62297	Door Seal for FD-47	29	62285	Insulation Ties for FD-47	46
62255	Motor Insulation for FD-47	16	66168	Tray for FD-47	30	62286	Switch for FD-47	47

Parts Breakdown

Model CE-CN-0066 45599

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
63901	Shell for FD-66B	1	62256	Connection Plate for FD-66B	17	62298	Tray Grid for FD-66B	31
63902	Hinge Wheels for FD-66B	2	63915	Middle Board for FD-66B	18	63929	Left and Right Door Trim for FD-66B	32
63903	Insulation for FD-66B	3	63916	Heating Element for FD-66B	19	63930	Inner Glass for FD-66B	33, 35
62246	Exhaust Pipe for FD-66B	4	62259	Fan Blade for FD-66B	20	63931	Hinge Assembly for FD-66B	34
63905	Power Cord for FD-66B	5	63918	Connection Pole for FD-66B	21	63933	Front Door Frame for FD-66B	36
62248	Terminal for FD-66B	6	62261	Wind Board for FD-66B	22	66169	Handle for FD-66B	37
66166	Heat Insulation Board for FD-66B	7	62262	Sensor Fixture for FD-66B	23	62278	Thermostat for FD-66B	39
62249	Space Holder for FD-66B	8	63921	Interior for FD-66B	24	62304	Control Panel for FD-66B	40
62250	Wire Buckle for FD-66B	9	62264	Grid Screws for FD-66B	25	63938	Heating Light for FD-66B	41, 44
63909	Rear Board for FD-66B	11	62265	Feet for FD-66B	26	62281	Knob Spring Plate for FD-66B	42
62252	Temperature Cut-Out for FD-66B	12, 38	63924	Bottom Board for FD-66B	27	62282	Thermostat Knob for FD-66B	43, 45
63911	Motor for FD-66B	13	66167	Up and Bottom Door Clip for FD-66B	28	62285	Insulation Ties for FD-66B	46
62254	Motor Base for FD-66B	14	63926	Door Seal for FD-66B	29	62286	Switch for FD-66B	47
62255	Motor Insulation for FD-66B	16	66168	Tray for FD-66B	30			