







Qty	Part Name	Part Code	Qty	Wholesale
1	Back splash	2.120.21.01001	1	30
2	Cook top grill, 6 in	1.851.0.011	1	30
3	Cooking panel support	2.120.21.01002	1	30
4	Anti-toxic base	2.120.21.01003	1	30
5	Cooking panel support R	2.120.21.01004	1	30
6	Use modification support	2.120.21.01005	1	30
7	Big size cabinet L	2.120.21.01006	1	30
8	Big size cabinet R	2.120.21.01007	1	30
9	Front support (R)	2.120.21.01008	1	30
10	Front support (L)	2.120.21.01009	1	30
11	Bottom plate	2.120.21.01010	1	30
12	Legs	2.120.21.01011	4	30
13	Door	2.120.21.01012	2	30
14	Door-hinge	2.120.21.01013	2	30
15	Door handle	2.120.21.01014	2	30
16	Lock for cooking burner	2.120.21.01015	1	30
17	Lock for burner	2.120.21.01016	1	30
18	Lock for burner	2.120.21.01017	1	30
19	Lock for burner	2.120.21.01018	1	30
20	Lock for burner	2.120.21.01019	1	30
21	Lock for burner	2.120.21.01020	1	30
22	Lock for burner	2.120.21.01021	1	30
23	Lock for burner	2.120.21.01022	1	30
24	Lock for burner	2.120.21.01023	1	30
25	Lock for burner	2.120.21.01024	1	30
26	Lock for burner	2.120.21.01025	1	30
27	Lock for burner	2.120.21.01026	1	30
28	Lock for burner	2.120.21.01027	1	30
29	Lock for burner	2.120.21.01028	1	30
30	Lock for burner	2.120.21.01029	1	30
31	Lock for burner	2.120.21.01030	1	30
32	Lock for burner	2.120.21.01031	1	30
33	Lock for burner	2.120.21.01032	1	30
34	Lock for burner	2.120.21.01033	1	30
35	Lock for burner	2.120.21.01034	1	30
36	Lock for burner	2.120.21.01035	1	30
37	Lock for burner	2.120.21.01036	1	30
38	Lock for burner	2.120.21.01037	1	30
39	Lock for burner	2.120.21.01038	1	30
40	Lock for burner	2.120.21.01039	1	30
41	Lock for burner	2.120.21.01040	1	30
42	Lock for burner	2.120.21.01041	1	30
43	Lock for burner	2.120.21.01042	1	30
44	Lock for burner	2.120.21.01043	1	30
45	Lock for burner	2.120.21.01044	1	30
46	Lock for burner	2.120.21.01045	1	30
47	Lock for burner	2.120.21.01046	1	30
48	Lock for burner	2.120.21.01047	1	30
49	Lock for burner	2.120.21.01048	1	30
50	Lock for burner	2.120.21.01049	1	30
51	Lock for burner	2.120.21.01050	1	30
52	Lock for burner	2.120.21.01051	1	30
53	Lock for burner	2.120.21.01052	1	30
54	Lock for burner	2.120.21.01053	1	30
55	Lock for burner	2.120.21.01054	1	30
56	Lock for burner	2.120.21.01055	1	30
57	Lock for burner	2.120.21.01056	1	30
58	Lock for burner	2.120.21.01057	1	30
59	Lock for burner	2.120.21.01058	1	30
60	Lock for burner	2.120.21.01059	1	30
61	Lock for burner	2.120.21.01060	1	30
62	Lock for burner	2.120.21.01061	1	30
63	Lock for burner	2.120.21.01062	1	30
64	Lock for burner	2.120.21.01063	1	30
65	Lock for burner	2.120.21.01064	1	30
66	Lock for burner	2.120.21.01065	1	30
67	Lock for burner	2.120.21.01066	1	30
68	Lock for burner	2.120.21.01067	1	30
69	Lock for burner	2.120.21.01068	1	30
70	Lock for burner	2.120.21.01069	1	30
71	Lock for burner	2.120.21.01070	1	30
72	Lock for burner	2.120.21.01071	1	30
73	Lock for burner	2.120.21.01072	1	30
74	Lock for burner	2.120.21.01073	1	30
75	Lock for burner	2.120.21.01074	1	30
76	Lock for burner	2.120.21.01075	1	30
77	Lock for burner	2.120.21.01076	1	30
78	Lock for burner	2.120.21.01077	1	30
79	Lock for burner	2.120.21.01078	1	30
80	Lock for burner	2.120.21.01079	1	30
81	Lock for burner	2.120.21.01080	1	30
82	Lock for burner	2.120.21.01081	1	30
83	Lock for burner	2.120.21.01082	1	30
84	Lock for burner	2.120.21.01083	1	30
85	Lock for burner	2.120.21.01084	1	30
86	Lock for burner	2.120.21.01085	1	30
87	Lock for burner	2.120.21.01086	1	30
88	Lock for burner	2.120.21.01087	1	30
89	Lock for burner	2.120.21.01088	1	30
90	Lock for burner	2.120.21.01089	1	30
91	Lock for burner	2.120.21.01090	1	30
92	Lock for burner	2.120.21.01091	1	30
93	Lock for burner	2.120.21.01092	1	30
94	Lock for burner	2.120.21.01093	1	30
95	Lock for burner	2.120.21.01094	1	30
96	Lock for burner	2.120.21.01095	1	30
97	Lock for burner	2.120.21.01096	1	30
98	Lock for burner	2.120.21.01097	1	30
99	Lock for burner	2.120.21.01098	1	30
100	Lock for burner	2.120.21.01099	1	30
101	Lock for burner	2.120.21.01100	1	30
102	Lock for burner	2.120.21.01101	1	30
103	Lock for burner	2.120.21.01102	1	30
104	Lock for burner	2.120.21.01103	1	30
105	Lock for burner	2.120.21.01104	1	30
106	Lock for burner	2.120.21.01105	1	30
107	Lock for burner	2.120.21.01106	1	30
108	Lock for burner	2.120.21.01107	1	30
109	Lock for burner	2.120.21.01108	1	30
110	Lock for burner	2.120.21.01109	1	30
111	Lock for burner	2.120.21.01110	1	30
112	Lock for burner	2.120.21.01111	1	30
113	Lock for burner	2.120.21.01112	1	30
114	Lock for burner	2.120.21.01113	1	30
115	Lock for burner	2.120.21.01114	1	30
116	Lock for burner	2.120.21.01115	1	30
117	Lock for burner	2.120.21.01116	1	30
118	Lock for burner	2.120.21.01117	1	30
119	Lock for burner	2.120.21.01118	1	30
120	Lock for burner	2.120.21.01119	1	30



	A	B	C	D	E	F	G	H	I	J	K	L	M	N
1	No.	Part Name	Part code	QTY										
2	1	Door silicone	1. 5. 05. 26	2										
3	2	Inner hinge support L	2. 1. 28. 28	1										
4	3	Inner hinge support R	2. 1. 28. 29	1										
5	4	Oven side panel L	1. 2. 01. 2. 01. 11	2										
6	5	Oven burner support	2. 1. 28. 7	2										
7	6	Oven burner	1. 3. 07. 40	2										
8	7	Oven burner flame fener plate	1. 2. 11. 34	2										
9	8	Fan front cover	1. 2. 01. 2. 13. 01	1										
10	9	Oven upper plate	1. 2. 01. 2. 02. 22	1										
11	10	Gas pipe fix support	2. 1. 28. 33	2										
12	11	Oven upper plate cover	2. 1. 28. 12	1										
13	12	Oven back plate	1. 2. 01. 2. 04. 3. 30	1										
14	13	Flue up cover	2. 1. 28. 17	1										
15	14	Flue bottom cover	2. 1. 28. 18	1										
16	15	Oven back plate support	2. 1. 28. 8	2										
17	16	Oven back plate cover	2. 1. 28. 11	1										
18	17	Fan cover	2. 1. 28. 22	1										
19	18	Insulated cotton for oven back plate	1. 8. 4. 33	1										
20	19	Wire for fixed the cotton	1. 8. 2. 3	2										
21	20	Plate for keeping apart the insulated cotton-oven burner	2. 1. 28. 20	2										
22	21	Insulated cotton	1. 8. 4. 32	1										
23	22	Motor of fan	1. 4. 12. 15	1										
24	23	Plate for keeping apart the insulated cotton-fan	2. 1. 28. 19	1										
25	24	Oven back plate bottom support	2. 1. 18. 18. 083201	1										
26	25	Fan	1. 4. 12. 15	1										
27	26	Oven side panel R	1. 2. 01. 2. 01. 12	1										
28	27	Oven bottom plate	1. 2. 01. 2. 07. 08	1										
29	28	Zinc bottom plate	2. 1. 28. 1	1										
30	29	Zinc bottom flat plate	2. 1. 28. 2	1										
31	30	Inner hinge	1. 2. 03. 02. 12	2										
32	31	Oven front plate support	2. 1. 28. 27	2										
33	32	Door seal	1. 5. 06. 11	1										
34	33	Oven front plate	1. 2. 01. 2. 03. 20	1										
35	34	Fire guard plate	1. 2. 01. 2. 05. 08	1										
36	35	Up oven burner aluminum tube	1. 3. 05. 3. 1. 3. 99	1										
37	36	Thermocouple 1200mm	1. 4. 18. 22	1										
38	37	Oven burner ignition needle 800mm	1. 4. 07. 1. 3. 14	1										
39	38	Oven burner ignition needle fix clip	1. 4. 07. 3. 04	2										
40	39	Down oven burner aluminum tube	1. 3. 05. 3. 1. 3. 100	1										
41	40	Junction box	1. 4. 10. 6	1										
42	41	Thermocouple 1600mm	1. 4. 18. 23	1										
43	42	Oven burner ignition needle 1200mm	1. 4. 07. 1. 3. 27	1										

	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S
1	No.	Part Name	Part code	QTY															
2	1	Handle+screw	1. 2. 02. 3. 1. 20	1															
3	2	Handle buckle	1. 2. 11. 31	2															
4	3	Door frame	2. 1. 09. 24. 083201	1															
5	4	Oven outer glass	1. 6. 03. 03. 1. 20	1															
6	5	Oven inner plate	2. 1. 28. 32	1															
7	6	Oven inner glass	1. 6. 04. 3. 12	2															
8	7	Door plate beam (L)	2. 1. 28. 34	1															
9	8	Door plate beam (R)	2. 1. 28. 35	1															
10	9	Door plate	1. 2. 01. 2. 06. 3. 07	1															
11	10	Inner glass fix clip	2. 1. 28. 31	2															
12	11	Outer hinge	1. 2. 03. 02. 24	2															
13																			
14																			
15																			
16																			
17																			
18																			
19																			
20																			
21																			
22																			
23																			
24																			
25																			



	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S
1	No.	Part Name	Part code	QTY															
2	1	BTU9000 burner cap	1. 3. 02. 2. 1. 18	3															
3	2	BTU18000 burner inner cap	1. 3. 01. 2. 29	1															
4	3	BTU18000 burner outer cap	1. 3. 01. 2. 30	1															
5	4	BTU9000 burner	1. 3. 01. 2. 03	3															
6	5	BTU18000 burner	1. 3. 01. 2. 28	1															
7	6	BTU5000 burner cap	1. 3. 02. 2. 1. 17	1															
8	7	BTU5000 burner	1. 3. 01. 2. 02	1															
9	8	Burner ignition needle 22.5x300mm+fix clip	1. 4. 07. 1. 3. 03	2															
10	9	BTU9000 burner support	1. 3. 03. 2. 21	3															
11	10	BTU18000 burner support	NA	1															
12	11	Burner ignition needle 23.5x730mm+fix clip	1. 4. 07. 1. 3. 28	1															
13	12	BTU5000 burner support	1. 3. 03. 2. 22	1															
14	13	Aluminum tube for BTU9000 burner	1. 3. 01. 2. 03	1															
15	14	Aluminum tube for BTU5000 burner	1. 3. 01. 2. 02	1															
16	15	Inner wire	1. 4. 01. 3. 65	1															
17	16	Valve for BTU5000 burner+Valve fixed support	1. 3. 09. 10	1															
18	17	Valve for BTU9000 burner+Valve fixed support	1. 3. 09. 11	2															
19	18	Valve for BTU18000 burner+Valve fixed support	1. 3. 09. 9	1															
20	19	Valve for oven burner +Fixed support	1. 3. 09. 8	1															
21	20	Gas pipe	1. 3. 06. 1. 050707	1															
22	21	Aluminum tube for BTU9000 burner	1. 3. 05. 3. 1. 3. 105	1															
23	22	Aluminum tube for BTU9000 burner	1. 3. 05. 3. 1. 3. 94	1															
24	23	Bellows	4. 1. 165	1															
25	24	Connector for gas pressure regulator	1. 3. 09. 7	1															
26	25	Gas pressure regulator	1. 3. 09. 6	1															
27	26	Aluminum tube 2 for BTU18000 burner	1. 3. 05. 3. 1. 3. 106	1															
28	27	Aluminum tube 1 for BTU18000 burner	1. 3. 05. 3. 1. 3. 107	1															
29	28	Burner ignition needle 22.5x730mm+fix clip	1. 4. 07. 1. 3. 07	1															
30																			