




cooktop




cavity top



door



oven cavity



FFSGS6277-30

No.	Material Name	Material Code	Qty.	No.	Material Name	Material Code	Qty.
1	Handle G30R04	G30R04-101900	1	32	thermocouple G30R09 1400mm	G30R09-072400	1
2	door outside cover component G30R03	0307003000003	1	33	oven burner nozzle mount plate G30R09	G30R09-080101	1
3	outer door glass G30R03	G30R03-101100	1	34	oven burner cup with nozzle kit 1.9	0707203000016	1
4	door heat insulate plate G30X03	G30X03-101401	1	35	cavity down plate preinstalled part G30R09	0307105000037	1
5	door hinge G30R03 left	G30R03-110000	1	36	down tray G30R09	G30R09-210100	1
6	door hinge G30R03 right	G30R03-110010	1	37	kick plate fixed screw G36X03	G36X03-130100	2
7	inner door glass R/L strip G36X03	G36X03-101601	2	38	baking rack G30X03	G30X03-071900	2
8	inner door glass top/down strip G30X03	G30X03-101501	2	39	oven lamp	G36X03-180100	2
9	inner door glass G30R03	G30R03-100500	2	40	side rack G36X03	G36X03-073800	2
10	door black enameled component G30R03	G30R03-100600-Z	1	41	cavity top left side plate G36X04	G36X04-070505	1
11	knob G36R09 single gas outlet	G30R09-030100	4	42	left outside plate inside component G30R09	G30R09-071101	1
12	Knob for thermostate G30R09	G30R09-030102	1	43	left outside plate G30R09	G30R09-071001	1
13	temperature gauge G36R07	G36R07-190600	1	44	cavity top right side plate G36X04	G36X04-070504	1
14	switch with lock-red G48X03	G48X03-170200	1	45	right outside plate inside component G30R09	G30R09-071100	1
15	control panel G30R09	G30R09-030301	1	46	right outside plate G30R09	G30R09-071000	1
16	control panel inner plate G30R09	G30R09-032300-Z	1	47	thermo-sensor fixed part G20A01	G20A01-031100	2
17	Kick plate G30X03	G30X03-120102	1	48	grill burner front support G30R09	G30R09-073502	1
18	Front plate G30R09	G30R09-070100	1	49	grill burner component Sabaf G30R09	G30R09-0900	1
19	control panel gas manifold G30R09	G30R09-0307001	1	50	grill burner support G30R09	G30R09-073501	1
20	Valve 0.55	G20C02-030402	1	51	oven burner cup with nozzle kit 1.43	0707203000020	1
21	Valve 0.80	G20C02-030407	1	52	cavity top plate component G30R09	G30R09-070600	1
22	Valve 0.76	G20C02-030406	2	53	cavity insulation plate	G30R09-074500	1
23	Thermostat G30R09	G30R09-030600	1	54	cooktop front support G30R09 L	G30R09-022100	1
24	door hinge mount G36X03	G36X03-110000-1	2	55	cooktop front support G30R09 R	G30R09-022101	1
25	legs G20C01	G20C01-071500	4	56	fan cover G36X03	G36X03-091700	1
27	left/right foot installed part	G30R09-071102	2	57	fan motor-1 G20A01	G20A01-091501	1
28	oven burner insulation plate G30R09	G30R09-200800	2	58	cavity structure frame glass wool	G30R09-070800	1
29	oven burner fixed plate G30R09	G30R09-072100	1	59	cavity black enameled back plate G30R09	G30R09-070300	1
30	oven burner component Sabaf G30R09	G30R09-0800	1	60	cavity back plate glass wool	G30R09-072900	1
31	oven burner spark plug 850mm	G30R09-170500	1	61	cavity back insulation plate	G30R09-072200	1

No.	Material Name	Material Code	Qty.
62	power cord fixed part	G20A01-160200	1
63	regulator fixed plate G30R09	G30R09-072201	1
64	regulator G36X03	G36X03-034000	1
65	regulator adapter G30R09	G30R09-034200	1
66	baffle plate	G30R09-072000	1
67	ignition 1 to 8	G20C01-170106-02	1
68	ignition fixed support	G30R09-212300	1
69	Wind board G30R09 (1)	G30R09-075004	1
70	Wind board G36R03 (2)	G30R09-075005	1
71	Al. pipe L/R G30R09	G30R09-020500	1
72	Al. pipe L/F G30R09	G30R09-020501	1
75	Al. pipe R/R G30R09	G30R09-020502	1
76	Al. pipe R/F G30R09	G30R09-020503	1
77	grill burner Al. pipe	G30R09-020505	1
78	oven burner Al. pipe	G30R09-020504	1
79	15/16" corrugated pipe 1000mm	0707209000169	1
80	cooling fan	G30R09-200900	1
81	cooling fan fixed support G30R09	G30R09-075400	1
82	Wind board	G30R09-075003	1
83	Chimney outside plate G30R09	G30R09-074001	1
84	Chimney inside plate G30R09	G30R09-074000	1
85	cooktop back support G30R09	G30R09-022000	2
86	cooktop plate G30R09	G30R09-020101	1

No.	Material Name	Material Code	Qty.
87	cooktop burner component 15000btu	G20A01-040200	1
88	Large burner	G20A02-040201	1
89	Large burner cover	G20A02-040202	1
90	cooktop burner component 9000btu	G20A01-040100	2
91	Mid burner	G20A02-040101	2
92	Mid burner cover	G20A02-040102	2
93	cooktop burner component 4000btu	G20A01-040000	1
94	Small burner	G20A01-040001	1
95	Small burner cover	G20A02-040002	1
97	top burner spark plug 660mm	G20B01-170401	4
99	cast iron grates	G36R05-021500	2
100	cast iron grates middle	G30R09-021400	1
101	backsplash component G30R03	G30R03-011500-Z	1
102	backsplash board cover	G30R09-073500	2
106	handle rubber mat G36R03	G36R03-100700	2
107	knob ring for main gas valve	G36R03-030200	5
108	door outer glass black pressing plate G30R03	G30R03-101400-02	2
109	grill burner spark plug 350	G30R09-170501	1
110	glass wool for door G30X03	G30X03-103500	1
111	door strengthen part L	G36X03-101003	1
112	door strengthen part R	G36X03-101002	1
113	power cord #7	G20A07-160105	1